




**SEW**  
**EURODRIVE**

# Assembly and Operating Instructions



Industrial Gear Units

**P.002 – P.102 Series Planetary Gearmotors**

Torque Classes from 24 – 631 kNm



## Contents

<b>1</b>	<b>General information.....</b>	<b>6</b>
1.1	About this documentation .....	6
1.2	Other applicable documentation .....	6
1.3	Structure of the safety notes .....	6
1.4	Decimal separator in numerical values .....	8
1.5	Rights to claim under limited warranty .....	8
1.6	Product names and trademarks .....	8
1.7	Copyright notice .....	8
<b>2</b>	<b>Safety notes .....</b>	<b>9</b>
2.1	Preliminary information .....	9
2.2	Duties of the user .....	9
2.3	Target group .....	10
2.4	Designated use .....	10
2.5	Symbols on the gear unit .....	11
2.6	Symbols on the dimension sheet .....	14
2.7	Symbols on the packaging .....	15
2.8	Transport .....	16
2.9	Storage and transport conditions .....	26
<b>3</b>	<b>Gear unit structure .....</b>	<b>28</b>
3.1	Planetary gear unit nameplates .....	28
3.2	DRN.. gearmotor nameplates .....	30
3.3	Type designations for gear units and options .....	32
3.4	Planetary gear unit with primary gear unit combination .....	35
3.5	Mounting position .....	36
3.6	Pivoted mounting position: Fixed and variable mounting positions .....	37
3.7	Mounting positions of primary gear units .....	38
3.8	Mounting position sheets .....	41
3.9	Output shaft variants .....	46
3.10	Components on the input side .....	48
3.11	Sealing system .....	49
3.12	Coating and surface protection systems .....	50
3.13	Types of lubrication .....	52
3.14	Extended warranty .....	55
<b>4</b>	<b>Structure of options and additional features .....</b>	<b>56</b>
4.1	Oil expansion tank /ET .....	56
4.2	Oil drain .....	56
4.3	Torque arm /T .....	57
4.4	Breather /BPG .....	58
4.5	Temperature sensor /Pt100 .....	61
<b>5</b>	<b>Installation/assembly .....</b>	<b>62</b>
5.1	Required tools/resources .....	62
5.2	Tolerances .....	62
5.3	Important information .....	63

5.4	Prerequisites for installation .....	66
5.5	Installing the gear unit .....	67
5.6	Mounting the oil expansion tank .....	71
5.7	Filling the gear unit with oil .....	75
5.8	Gear units delivered with oil fill (option) .....	77
5.9	Gear unit with splash guard adapter (option) .....	78
5.10	Gear units with solid shaft .....	79
5.11	Output shaft as hollow shaft with shrink disk .....	81
5.12	Gear unit in foot-mounted design with hollow output shaft with shrink disk .....	88
5.13	Gear unit with splining .....	89
5.14	Torque arm .....	92
5.15	Flange-mounted gear units .....	96
5.16	Couplings .....	97
5.17	AMS.. adapter .....	99
5.18	AQS.. adapter .....	107
5.19	AD input shaft assembly .....	112
5.20	Breather for RF../KF../K... primary gear units .....	116
5.21	Temperature sensor /Pt100 .....	116
<b>6</b>	<b>Startup .....</b>	<b>118</b>
6.1	Important information .....	118
6.2	Startup of gear units with long-term protection .....	120
6.3	Desiccant breather filter /DC .....	121
6.4	Limit temperature for gear unit start .....	121
6.5	Backstop .....	122
6.6	Measuring the oil temperature .....	122
6.7	Gear unit shutdown / gear unit conservation .....	123
<b>7</b>	<b>Inspection/maintenance .....</b>	<b>125</b>
7.1	Preliminary work regarding inspection/maintenance .....	125
7.2	Inspection and maintenance intervals .....	127
7.3	Lubricant change intervals .....	129
7.4	Checking the oil level at the planetary gear unit .....	130
7.5	Checking the oil consistency .....	133
7.6	Changing the oil at planetary gear units .....	134
7.7	Refilling sealing grease .....	140
7.8	Breather /BPG .....	141
<b>8</b>	<b>Permitted lubricants .....</b>	<b>142</b>
8.1	Lubricant selection .....	142
8.2	Structure of the tables and abbreviations .....	143
8.3	Explanation of the various lubricants .....	144
8.4	Lubricant tables .....	145
8.5	Lubricant fill quantities .....	148
8.6	Lubricant compatibility with oil seal .....	151
8.7	Sealing greases/bearing greases: Planetary gear unit .....	152
8.8	Sealing grease: RF../KF../K... primary gear units and motors .....	153



<b>9</b>	<b>Malfunctions/remedy .....</b>	<b>154</b>
9.1	Troubleshooting information .....	154
9.2	Service .....	154
9.3	Malfunctions of P.. planetary gear units .....	155
9.4	Malfunctions of primary RF../KF../K.. primary gear units .....	156
9.5	Malfunctions of AMS/AQS adapters .....	157
9.6	Malfunctions of AD input shaft assembly .....	157
9.7	Motor malfunctions.....	158
9.8	Brake malfunctions .....	160
9.9	Disposal .....	161
<b>10</b>	<b>Address list .....</b>	<b>162</b>
	<b>Index .....</b>	<b>173</b>

## 1 General information

### 1.1 About this documentation

**The documentation at hand is the original.**

This documentation is an integral part of the product. The documentation is intended for all employees who perform work on the product.

Make sure this documentation is accessible and legible. Ensure that persons responsible for the systems and their operation as well as persons who work on the product independently have read through the documentation carefully and understood it. If you are unclear about any of the information in this documentation or if you require further information, contact SEW-EURODRIVE.

### 1.2 Other applicable documentation

The following documentation and documents should also be observed:

- When operating gearmotors, also observe the safety notes for motors and primary gear units in the accompanying operating instructions.
- Operating instructions of any attached options
- Order-specific documents, such as dimension sheet and order confirmation
- P.002 – P.102 series catalog

### 1.3 Structure of the safety notes

#### 1.3.1 Meaning of signal words

The following table shows the grading and meaning of the signal words for safety notes:

Signal word	Meaning	Consequences if disregarded
<b>▲ DANGER</b>	Imminent hazard	Severe or fatal injuries
<b>▲ WARNING</b>	Possible dangerous situation	Severe or fatal injuries
<b>▲ CAUTION</b>	Possible dangerous situation	Minor injuries
<b>NOTICE</b>	Possible damage to property	Damage to the product or its environment
<b>INFORMATION</b>	Useful information or tip: Simplifies handling of the product.	

### 1.3.2 Structure of section-related safety notes

Section-related safety notes do not apply to a specific action but to several actions pertaining to one subject. The hazard symbols used either indicate a general hazard or a specific hazard.

This is the formal structure of a safety note for a specific section:



#### SIGNAL WORD

Type and source of hazard.

Possible consequence(s) if disregarded.

- Measure(s) to prevent the hazard.

### Meaning of the hazard symbols

The hazard symbols in the safety notes have the following meaning:

Hazard symbol	Meaning
	General hazard
	Warning of hot surfaces
	Warning about suspended load
	Warning of automatic restart

### 1.3.3 Structure of embedded safety notes

Embedded safety notes are directly integrated into the instructions just before the description of the dangerous action.

This is the formal structure of an embedded safety note:

**⚠ SIGNAL WORD!** Type and source of hazard. Possible consequence(s) if disregarded. Measure(s) to prevent the hazard.

**1.4 Decimal separator in numerical values**

In this document, a period is used to indicate the decimal separator.

Example: 30.5 kg

**1.5 Rights to claim under limited warranty**

Read the information in this documentation. This is essential for fault-free operation and fulfillment of any rights to claim under limited warranty. Read the documentation before you start working with the product.

**1.6 Product names and trademarks**

The brands and product names in this documentation are trademarks or registered trademarks of their respective titleholders.

**1.7 Copyright notice**

© 2022 SEW-EURODRIVE. All rights reserved. Unauthorized reproduction, modification, distribution or any other use of the whole or any part of this documentation is strictly prohibited.

## **2 Safety notes**

### **2.1 Preliminary information**

The following general safety notes serve the purpose of preventing injury to persons and damage to property. They primarily apply to the use of products described in this documentation. If you use additional components, also observe the relevant warning and safety notes.

### **2.2 Duties of the user**

As the user, you must ensure that the basic safety notes are observed and complied with. Make sure that persons responsible for the machinery and its operation as well as persons who work on the device independently have read through the documentation carefully and understood it.

As the user, you must ensure that all of the work listed in the following is carried out only by qualified specialists:

- Setup and installation
- Installation and connection
- Startup
- Maintenance and repairs
- Shutdown
- Disassembly

Ensure that the persons who work on the product pay attention to the following regulations, conditions, documentation, and information:

- National and regional safety and accident prevention regulations
- Warning and safety signs on the product
- All other relevant project planning documents, installation and startup instructions, and wiring diagrams
- Do not assemble, install or operate damaged products
- All system-specific specifications and conditions

Ensure that systems in which the product is installed are equipped with additional monitoring and protection devices. Observe the applicable safety regulations and legislation governing technical work equipment and accident prevention regulations.

### 2.3 Target group

Specialist for mechanical work	<p>Any mechanical work may be performed only by adequately qualified specialists. Specialists in the context of this documentation are persons who are familiar with the design, mechanical installation, troubleshooting, and maintenance of the product, and who possess the following qualifications:</p> <ul style="list-style-type: none"> <li>• Qualifications in the field of mechanics in accordance with the national regulations</li> <li>• Familiarity with this documentation</li> </ul>
Specialist for electrotechnical work	<p>Any electrotechnical work may be performed only by electrically skilled persons with a suitable education. Electrically skilled persons in the context of this documentation are persons who are familiar with electrical installation, startup, troubleshooting, and maintenance of the product, and who possess the following qualifications:</p> <ul style="list-style-type: none"> <li>• Qualifications in the field of electrical engineering in accordance with the national regulations</li> <li>• Familiarity with this documentation</li> </ul>
Additional qualifications	<p>In addition to that, these persons must be familiar with the valid safety regulations and laws, as well as with the requirements of the standards, directives, and laws specified in this documentation.</p> <p>The persons must have the express authorization of the company to operate, program, parameterize, label, and ground devices, systems, and circuits in accordance with the standards of safety technology.</p>
Instructed persons	<p>All work in the areas of transport, storage, installation, operation and waste disposal may only be carried out by persons who are trained and instructed appropriately. These instructions must enable the persons to carry out the required activities and work steps safely and in accordance with regulations.</p>

### 2.4 Designated use

The industrial gear units are gear units run by motors for industrial and commercial systems. The units may only be run at the speeds and powers shown in the technical data or on the nameplate. Implementing gear unit loads other than the permitted values or operating the gear units in areas of application other than industrial and commercial systems is only permitted after consultation with SEW-EURODRIVE.

Using these products in potentially explosive atmospheres is prohibited, unless specifically designated otherwise.













In compliance with the EC Machinery Directive 2006/42/EC, the industrial gear units are partly completed machinery for installation in machinery and systems. In the scope of the EC directive, you must not take the machinery into operation in the designated fashion until you have established that the end product complies with Machinery Directive 2006/42/EC.










## 2.5 Symbols on the gear unit


Symbols, nameplates, or information signs can become dirty or otherwise illegible over time. Always make sure that safety, warning, and operating notes are legible. Replace damaged symbols, nameplates, and information signs.

Observe the symbols on the gear unit. They have the following meaning:

Symbol	Meaning
	Indicates the <b>oil filling location</b> . Also serves as proper venting during the oil change.
	Indicates the <b>oil drain</b> .
	Indicates the position of the <b>breather</b> . Serves to avoid mistaking the oil measuring position for the venting position.
	Helps avoid errors caused by lack of understanding. Read the information in the operating instructions.
	Indicates the <b>oil sight glass</b> .
	Indicates the <b>oil dipstick</b> .
	Indicates the <b>magnetic oil drain plug</b> .
	Indicates the positions for <b>relubrication</b> and makes it easier to find the locations to be lubricated. Helps avoid bearing damage.
	Indicates the <b>water supply</b> and serves to locate the connection option.
	Indicates the <b>water return</b> and serves to locate the connection option.
	Indicates the <b>oil supply</b> and serves to locate the connection option.
	Indicates the <b>oil return</b> and serves to locate the connection option.

Symbol	Meaning
	For pivoted mounting positions, this symbol on the information sign indicates the mounting position of the gear unit for <b>checking the oil</b> .
	Indicates the position of the <b>temperature sensor/temperature switch</b> .
	Indicates the <b>grease drain plug</b> and serves to locate the grease drain. Helps avoid bearing damage.
	Indicates the <b>air outlet screw</b> .
	Caution: Risk of burns due to hot surface.
	Caution: Removing the dipstick during operation may result in damage to the gear unit.
	Caution: Risk of burns due to hot gear oil.



After startup, you may remove the following labels from the gear unit.

Meaning	
The coupling is delivered without grease.	
 18977405	<b>VORSICHT NOTICE ATTENTION PRECAUCIÓN VOORZICHTIG OSTROŻNIE</b> <b>DE</b> Kupplung wird ohne Fett geliefert. Mögliche Sachschäden! • Vor der Inbetriebnahme Kupplung mit Fett befüllen.
	<b>EN</b> Coupling delivered without grease Possible damage to property. • Fill coupling with grease prior to startup.
	<b>F</b> L'accouplement est livré sans graisse. Risque de dommages matériels ! • Avant la mise en service, remplir l'accouplement de graisse.
	<b>ES</b> El acoplamiento se suministra sin grasa. ¡Posibles daños materiales! • Llenar el acoplamiento con grasa antes de la puesta en marcha.
	<b>NL</b> Koppeling wordt zonder vet geleverd. Mogelijke materiële schade! • Koppeling vóór de inbedrijfstelling met vet vullen.
	<b>PL</b> Sprzęgło jest dostarczane bez smaru. Możliwe szkody materialne! • Przed uruchomieniem należy naplnić sprzęgło smarem.

### Meaning



The coupling is delivered without oil.

#### VORSICHT NOTICE ATTENTION PRECAUCIÓN VOORZICHTIG OSTROŻNIE

  <p>18977413</p>	<p><b>DE</b> Kupplung wird ohne Öl geliefert. Mögliche Sachschäden! • Vor der Inbetriebnahme Kupplung mit Öl befüllen.</p>	<p><b>EN</b> Coupling delivered without oil Possible damage to property. • Fill coupling with oil prior to startup.</p>
	<p><b>F</b> L'accouplement est livré sans huile. Risque de dommages matériels ! • Avant la mise en service, remplir l'accouplement d'huile.</p>	<p><b>ES</b> El acoplamiento se suministra sin aceite. ¡Posibles daños materiales! • Llenar el acoplamiento con aceite antes de la puesta en marcha.</p>
	<p><b>NL</b> Koppeling wordt zonder olie geleverd. Mogelijke materiële schade! • Koppeling vóór de inbedrijfstelling met olie vullen.</p>	<p><b>PL</b> Sprzęgło jest dostarczane bez oleju. Możliwe szkody materialne! • Przed uruchomieniem należy napelnić sprzęgło olejem.</p>



The gear unit is protected against corrosion with VCI.

#### VORSICHT NOTICE ATTENTION PRECAUCIÓN VOORZICHTIG OSTROŻNIE

  <p>18977421</p>	<p><b>DE</b> Getriebe ist mit VCI rostgeschützt. Nicht öffnen! Mögliche Sachschäden! • Vor der Inbetriebnahme Vorarbeiten gemäß Betriebsanleitung durchführen. • Keine offene Flamme!</p>	<p><b>EN</b> Gear unit with VCI corrosion protection. Do not open! Potential damage to property! • Prior to startup, perform preliminary work according to operating instructions. • No open flames!</p>
	<p><b>F</b> Réducteur protégé contre la corrosion avec VCI. Ne pas ouvrir Risque de dommages matériels ! • Avant la mise en service, réaliser les travaux préliminaires indiqués dans la notice d'exploitation. • Pas de flammes ouvertes !</p>	<p><b>ES</b> Reductor está protegido con VCI contra la corrosión. ¡No abrir! ¡Posibles daños materiales! • Antes de la puesta en marcha, efectuar los trabajos preparatorios según las instrucciones de funcionamiento. • No debe haber fuego abierto.</p>
	<p><b>NL</b> Tandwielkast is met VCI tegen corrosie beschermd. Niet openen! Mogelijke materiële schade! • Vóór de inbedrijfstelling voorbereidingen conform technische handleiding uitvoeren. • Geen open vuur!</p>	<p><b>PL</b> Przekładnia zabezpieczona jest przed korozją za pomocą środka VCI. Nie otwierać! Możliwe szkody materialne! • Przed uruchomieniem należy przeprowadzić czynności przygotowawcze zgodnie z informacjami zawartymi w instrukcji obsługi! • Unikać otwartych płomieni!</p>













The gear unit is delivered without oil.

#### VORSICHT NOTICE ATTENTION PRECAUCIÓN VOORZICHTIG OSTROŻNIE

  <p>18977383</p>	<p><b>DE</b> Getriebe wird ohne Öl geliefert. Mögliche Sachschäden! • Vor der Inbetriebnahme Ölbefüllung gemäß Betriebsanleitung durchführen.</p>	<p><b>EN</b> Gear unit is delivered without oil. Potential damage to property! • Prior to startup, fill in oil according to operating instructions.</p>
	<p><b>F</b> Le réducteur est livré sans huile. Risque de dommages matériels ! • Avant la mise en service, effectuer le remplissage d'huile conformément à la notice d'exploitation.</p>	<p><b>ES</b> El reductor se suministra sin aceite. ¡Posibles daños materiales! • Antes de la puesta en marcha, efectuar el llenado de aceite según las instrucciones de funcionamiento.</p>
	<p><b>NL</b> Tandwielkast wordt zonder olie geleverd. Mogelijke materiële schade! • Vóór de inbedrijfstelling olie conform technische handleiding bijvullen.</p>	<p><b>PL</b> Przekładnia jest dostarczana bez oleju. Możliwe szkody materialne! • Przed uruchomieniem należy wlać olej zgodnie z informacjami zawartymi w instrukcji obsługi.</p>

## 2.6 Symbols on the dimension sheet

The safety symbols on the dimension sheet must be observed. They have the following meaning:


Safety symbol	Meaning
	Indicates the <b>oil filling location</b> .
	Indicates the <b>oil drain</b> .
	Indicates the position of the <b>breather</b> .
	Indicates the position of the attachment points for <b>transport</b> .
	Indicates the position of the <b>oil dipstick</b> .
	Indicates the position of the <b>oil sight glass</b> .
	Indicates the position(s) that need to be <b>lubricated</b> .
	Indicates the position of the <b>grease nipples</b> on the gear unit.
	Indicates the position of the <b>grease outlet</b> .
	Indicates the position of the <b>magnetic screw plug</b> .
	Indicates the position of the <b>oil heater</b> .
	Indicates the oil level plug.

## 2.7 Symbols on the packaging

The symbols on the packaging must be observed. They have the following meaning:



Fragile



Protect  
from heat



Fasten  
here



Hand hooks  
prohibited



Up



Keep dry



Center of gravity

1811486091

## 2.8 Transport

### 2.8.1 Notes on transport

Observe the following notes during transport.



#### ⚠ WARNING

Suspended loads can fall.

Severe or fatal injuries.

- Do not stand under the suspended load.
- Secure the danger zone.
- Use suitable, sufficiently rated, and undamaged handling equipment.
- Consider the gear unit dimensions, the center of gravity, and the weight that has to be moved when selecting lifting equipment or crane (see dimension drawing). The weight to be moved is the total weight of the drive package including mount-on components (not only the weight of the gear unit).



#### ⚠ WARNING

Lifted loads may fall over.

Severe or fatal injuries.

- Secure the gear unit against falling over during the lifting process.
- Secure the danger zone.
- Use suitable, sufficiently rated, and undamaged handling equipment.
- Consider the gear unit dimensions, the center of gravity, and the weight that has to be moved when selecting lifting equipment or crane (see order documents). The weight to be moved is the total weight of the drive package including mount-on components (not only the weight of the gear unit).



#### ⚠ CAUTION

Risk of slipping of unsecured mount-on components, such as keys.

Potential risk of crushing due to falling parts.

- Secure the mount-on components.



#### ⚠ CAUTION

Danger due to lubricant leaking from damaged seals and the breather.

Minor injuries.

- Check the gear unit and mount-on components for leaking lubricant.
- The seals must not come in contact with cleaning agent as this may damage the seals.
- Protect the breather against damage.
- Make sure that there is not too much oil in the gear unit. If the oil level is too high and the temperature rises, lubricant may escape from the breather.




## NOTICE

Improper transport may cause damage to the gear unit.

Possible damage to property.

- Observe the following information.
- 
- Inspect the shipment for any possible transport damage as soon as you receive the delivery. Inform the shipping company immediately about any damage. In the event of damage, do not start up the gear unit.
  - The weight of the gear unit (without oil) is indicated on the nameplate or on the order documents. Observe the loads and specifications given on the nameplate.
  - If possible, transport the gear unit without oil fill. If this is not possible, note that the weight indicated on the nameplate refers only to the no-load weight of the gear unit, and replace the breather with a screw plug.
  - The gear unit must be transported in a manner that prevents damage to the gear unit and to attached components. For example, impacts against exposed shaft ends can damage the gear unit.
  - Use only the prescribed attachment points [1] to transport the gear unit (see order documents). The load suspensions of the motor or attached components are provided for stabilization purposes only.
  - The figures on the following pages are exemplary.
  - Note that the load ring must be screwed in completely and must be flush to the contact surface. Tighten the load rings at least hand-tight. The following type of freely rotatable load ring is suitable for gear unit transport.



9007215322651019

### 2.8.2 Horizontal mounting positions (M1/M3/M5/M6)

#### Preliminary work for transport

Transport in the horizontal mounting positions (M1/M3/M5/M6) does not require preliminary work.

#### Transport

##### NOTICE

Danger due to improper transport protection.

Possible damage to property.

- The gear unit must not be attached using only the lifting eyes [2]. Always use the main attachment points [1] for transport.
  - The tethers shown as dotted lines must only be used for stabilization purposes and do not replace the tethers attached to the attachment points.
- 


#### Required resources

- Straps that are dimensioned according to the load's mass.
- Proper lifting equipment such as a crane.

#### Procedure

1. Choose the sling according to the load's mass.
2. Check the sling for damage. Do not use any damaged slings.

3. Install the sling on the gear unit as shown in the following figures.



9007215665479947

4. Slowly and carefully lift the gear unit.
5. **▲ DANGER!** Lifted loads can fall over or severely swing. Severe or fatal injuries. To prevent severe swinging, transport the gear unit at a slow speed.
6. Slowly lower the gear unit at the destination. Place the gear unit on an even, slip-resistant, and load-bearing surface.
7. Remove the sling.

### 2.8.3 Transporting in vertical mounting position M2


SEW-EURODRIVE recommends the following procedure.

#### Preliminary work for transport

This chapter describes the preparatory steps for transporting the gear unit in vertical mounting position M2.

#### Required resources

- 3 load rings that are dimensioned according to the load's mass. For the required thread size, refer to chapter "Gear units with flange-mounted design" (→ 96).
- 3 nuts according to the thread size of the load ring.
- Straps that are dimensioned according to the load's mass.
- Proper lifting equipment such as a crane.



9007215665461131

#### Procedure

1. Check the sling for damage. Do not use any damaged slings.
2. Insert 3 load rings with a distance of approx. 120° into the through holes on the output shaft side.
3. Screw one nut to each load ring on the other side. Tighten the nuts by hand.

#### Transporting



#### ▲ WARNING


Danger due to insufficient transport protection.

Severe or fatal injuries.

- Consider the center of gravity of the gear unit.
- Select strap lengths that ensure the stability of the gear unit during transport. The diagonal pull on the load rings may not exceed 45°.

### Procedure

1. Install the straps on the load rings as shown in the following figure.




9007215665772939

2. Slowly and carefully lift the gear unit in the horizontal mounting position until there is enough free space below the gear unit to rotate it into the vertical mounting position without touching the ground.
3. **⚠ DANGER!** Lifted loads can fall over or severely swing. Severe or fatal injuries. To prevent severe swinging, transport the gear unit at a slow speed.
4. Do not place the gear unit in the vertical mounting position on the motor.
5. Remove the straps after transport.

**Work steps after transport**

Perform the following tasks after transport.



9007215982344203

**Procedure**

1. Remove the 3 load rings.




## 2.8.4 Transporting in vertical mounting position M4

### Preliminary work for transport

This chapter describes the preparatory steps for transporting the gear unit in vertical mounting position M4.

#### Required resources

- 3 threaded rods that are dimensioned according to the load's mass. The threaded rods must be sufficiently long so that the center of gravity of the load is below the load ring. For the required thread size, refer to chapter "Gear units with flange-mounted design" (→ 96).
- 6 nuts according to the thread size of the threaded rods.
- 3 load rings according to the thread size of the threaded rods.
- Straps that are dimensioned according to the load's mass.
- Proper lifting equipment such as a crane.



9007215982291083

#### Procedure

1. Check the sling for damage. Do not use any damaged slings.
2. Screw a nut onto each threaded rod.
3. Insert the threaded rods at a distance of approx. 120° into the through holes on the mounting flange.
4. Screw one nut to each threaded rod on the output shaft side.
5. Tighten the nuts.
6. Screw one load ring to each threaded rod.

## Transporting

**▲ WARNING**


Danger due to insufficient transport protection.

Severe or fatal injuries.

- Consider the center of gravity of the gear unit.
- Select strap lengths that ensure the stability of the gear unit during transport. The diagonal pull on the load rings may not exceed 45°.

**Procedure**

1. Install the straps on the load rings as shown in the following figure. The gear unit must not be attached using only the lifting eyes [2]. The load suspensions of the motor or attached components are provided for stabilization purposes only. Use only the provided attachment points [1] to transport the gear unit.




9007216181171595

2. Slowly and carefully lift the gear unit in the horizontal mounting position until there is enough free space below the gear unit to rotate it into the vertical mounting position without touching the ground.
3. **▲ DANGER!** Lifted loads can fall over or severely swing. Severe or fatal injuries. To prevent severe swinging, transport the gear unit at a slow speed.
4. Do not place the gear unit in the vertical mounting position on the output shaft.
5. Remove the straps.

## Work steps after transport

Perform the following tasks after transport.



9007216181404683

## Procedure

1. Remove the 3 load rings and threaded rods.

## 2.9 Storage and transport conditions

The gear units can be shipped with the following protection and packaging types depending on the storage and transport conditions.

### 2.9.1 Internal conservation

#### Standard corrosion protection

After the test run of the gear unit at the factory, the gear unit is protected against corrosion for a limited time.

#### Long-term corrosion protection

After the test run of the gear unit at the factory, a phase inhibitor is filled into the gear unit to protect it against corrosion for a limited time. The breather filter is replaced by a screw plug and enclosed with the gear unit.

### 2.9.2 Exterior corrosion protection

The following measures are taken for exterior corrosion protection:

- Anti-corrosion agent is applied to bare, non-painted functional surfaces of shafts, flanges, mounting and foot surfaces of the housing. The anti-corrosion agent must be removed only with a suitable solvent that does not damage the oil seal.
- Small spare parts and loose pieces, such as bolts, nuts, etc., are packed in corrosion protection plastic bags (VCI corrosion protection bags).
- Threaded holes and blind holes are covered with plastic plugs.
- If the gear unit is stored longer than 6 months, you must regularly check the protective coating of unpainted areas as well as the paint coating. Renew areas with damaged protective coating/paint.

### 2.9.3 Packaging

#### Standard packaging

The gear unit is delivered on a pallet without cover.

Use: transport by truck or rail

#### Long-term packaging

The gear unit is delivered in a wooden box that is also appropriate for sea transport.

Use: transport by ship and/or extended storage

### 2.9.4 Storage conditions

Improper storage may result in damage to the gear unit. Observe the following information to prevent damage to the gear unit:

- While in storage until startup, the gear unit must be stored in a shock-free manner to prevent damage to the rolling bearing races.
- Only fill gear units with oil up to the uppermost rolling element. This ensures a remaining air volume for the oil to expand in case of higher temperatures. Add VCI Anticorit and tightly seal the gear unit (replace the breather with a screw plug)
- The permissible storage temperature is -30 °C to +50 °C.
- If stored in tropical zones, provide for sufficient protection against insect damage. Contact SEW-EURODRIVE in the case of differing requirements.

The gear units are delivered without oil as standard; different protection systems are required depending on the storage period and storage conditions as shown in the following table.

Corrosion protection + packaging	Storage location	Storage duration
Standard corrosion protection + standard packaging	Under a roof and enclosed at constant temperature and atmospheric humidity (5 °C < $\vartheta$ < 60 °C, < 50% relative humidity).  No sudden temperature fluctuations. Controlled ventilation with filter (free from dust and dirt). No aggressive vapors and no shocks.	Max. 6 months with intact surface protection.
Long-term corrosion protection + standard packaging	Under a roof and enclosed at constant temperature and atmospheric humidity (5 °C < $\vartheta$ < 60 °C, < 50% relative humidity).  No sudden temperature fluctuations. Controlled ventilation of the storage location with filter (free from dust and dirt). No aggressive vapors and no shocks.	Max. 3 years with regular inspection and checking for intactness.
Long-term corrosion protection + long-term packaging	Under a roof, protected against rain and free from shocks.	Max. 3 years with regular inspection and checking for intactness.

3

**Gear unit structure**  
 3.1 Planetary gear unit nameplates

The following figures show examples of the nameplates of a planetary gear unit.


Nameplate 1

SEW-EURODRIVE

Bruchsal/Germany

Type


Nr. 


[1]


		min.	norm.	max.	i	<input type="text" value="1433.00"/>
PK1	[kW]	<input type="text" value="1.20"/>	<input type="text" value="3.58"/>	<input type="text" value="3.5"/>	F <sub>s</sub>	<input type="text" value="1.12"/>
Mk2	[Nm]	<input type="text" value="32768"/>	<input type="text" value="32768"/>	<input type="text" value="32768"/>	PM1	[kW] <input type="text" value="4.00"/>
n1	[rpm]	<input type="text" value="482"/>	<input type="text" value="1445"/>	<input type="text" value="1464"/>	T <sub>a</sub>	[°C] <input type="text" value="0...40"/>
n2	[rpm]	<input type="text" value="0.34"/>	<input type="text" value="1"/>	<input type="text" value="1"/>	1743 897 7 D	

IM

Qty of greasing points ☐ Fans ☐ Mass [kg]  Year



27021616353036939

Type		Type designation
No.		Production number
PK1	kW	Operating power on the input shaft (HSS)
MK2	Nm	Gear unit output torque
n1	rpm	Input speed (HSS)
n2	rpm	Output speed (LSS)
norm.		Normal operating point
min.		Operating point at minimum speed
max		Operating point at maximum speed
I		Exact gear unit ratio
F <sub>s</sub>		Service factor
PM1	kW	Nominal motor power
T <sub>A</sub>	°C	Deviation from standard temperature range (−20 °C to +40 °C)
Mass	kg	Gear unit weight
Qty. of greasing points		Number of points that require republication
Fans		Number of installed fans
		Oil grade and viscosity class/oil quantity
Year		Year of manufacture
IM		Mounting position and mounting surface
[1]		CE symbol

27788024/EN – 12/2022



### **Nameplate 2**

Product label with QR code. The QR code can be scanned. You will be redirected to the digital services of SEW-EURODRIVE. There, you have access to product-specific data, documents, and further services.

The following figure shows an example of a product label:




9007234276331531

### 3.2 DRN.. gearmotor nameplates

The following figures show examples of the nameplates of a DRN.. gearmotor.

Nameplate 1



18014423934358283

Line	Information
[1]	• Manufacturer, address, CE mark
[2]	• Type designation
[3]	• Serial number • Suitability for inverter operation • Number of phases and underlying rating and performance standard
[4]	• Rated frequency • Rated speed of the motor / speed of the gear unit output shaft • Nominal voltage
[5]	• Rated power and operating mode • Rated current • Energy efficiency class according to IEC 60034-30-1
[6]	• Power factor • Efficiency after capacity utilization of 100%, 75%, and 50% • Degree of protection according to IEC 60034-5
[7]	• Thermal class
[8]	• Year of manufacture
[9]	• brake voltage • Waste disposal according to WEEE Directive
[10]	• Gear unit ratio • Output torque • Mounting position • Nominal braking torque
[11]	• Oil type and oil fill volume • Brake control

Line	Information
[12]	<ul style="list-style-type: none"> <li>• Gearmotor weight</li> <li>• Permitted ambient temperature range of the motor</li> <li>• Nameplate number</li> <li>• Country of manufacture</li> </ul>

### Nameplate 2



18014432148567307

The QR code on the product gives you quick access to the digital services from SEW-EURODRIVE.

In addition to being able to enter the QR code with the camera of your mobile device or an appropriate app, you can also use the "Product ID Plus" app from SEW-EURODRIVE. After scanning, you will see the technical data to identify the product directly.

In addition, the search for product-specific spare parts and documentation, as well as fault diagnostics and direct service requests are simple and fast.

**3.3 Type designations for gear units and options****3.3.1 P..RF.. helical-planetary gear units**

Gear unit design	Abbreviation	Meaning
Foot-mounted design (solid shaft)	<b>P..RF..</b>	<ul style="list-style-type: none"> <li>• Solid shaft with key</li> <li>• Solid shaft with 2 keys (optional)</li> </ul>
	<b>PR..RF..</b>	Smooth solid shaft
	<b>PL..RF..</b>	Splined solid shaft
Flange-mounted design (solid shaft)	<b>PF..RF..</b>	<ul style="list-style-type: none"> <li>• Solid shaft with key</li> <li>• Solid shaft with 2 keys (optional)</li> </ul>
	<b>PRF..RF..</b>	Smooth solid shaft
	<b>PLF..RF..</b>	Splined solid shaft
Foot-mounted design (hollow shaft)	<b>PH..RF..</b>	Hollow shaft with shrink disk
	<b>PV..RF..</b>	Splined hollow shaft
Flange-mounted design (hollow shaft)	<b>PHF..RF..</b>	Hollow shaft with shrink disk
	<b>PVF..RF..</b>	Splined hollow shaft

**3.3.2 P..KF../P..K.. bevel-planetary gear units**

Gear unit design	Abbreviation	Meaning
Foot-mounted design (solid shaft)	<b>P..KF../P..K..</b>	<ul style="list-style-type: none"> <li>• Solid shaft with key</li> <li>• Solid shaft with 2 keys (optional)</li> </ul>
	<b>PR..KF../PR..K..</b>	Smooth solid shaft
	<b>PL..KF../PL..K..</b>	Splined solid shaft
Flange-mounted design (solid shaft)	<b>PF..KF../PF..K..</b>	<ul style="list-style-type: none"> <li>• Solid shaft with key</li> <li>• Solid shaft with 2 keys (optional)</li> </ul>
	<b>PRF..KF../PRF..K..</b>	Smooth solid shaft
	<b>PLF..KF../PLF..K..</b>	Splined solid shaft
Foot-mounted design (hollow shaft)	<b>PH..KF../PH..K..</b>	Hollow shaft with shrink disk
	<b>PV..KF../PV..K..</b>	Splined hollow shaft
Flange-mounted design (hollow shaft)	<b>PHF..KF../PHF..K..</b>	Hollow shaft with shrink disk
	<b>PVF..KF../PVF..K..</b>	Splined hollow shaft

### 3.3.3 Additional features of gear units

Designation	
/T	With torque arm

### 3.3.4 Input shaft assembly

Designation	
AD	Input shaft assembly
.../P	With motor platform
.../RS	With backstop
.../ZR	With centering shoulder


### 3.3.5 Adapters

Designation	
AM	Adapter for mounting IEC/NEMA motors
AR	Adapter with slip clutch
AT	Adapter with hydraulic start-up coupling
.../RS	and backstop
.../BM(G)	and disk brake
.../HF	with manual brake release, lockable
.../HR	with manual brake release with automatic re-engaging function

## 3.3.6 Example: Type designation for a PHF.. planetary gear unit with KF.. primary gear unit

The type designation of the gear unit is structured as follows:

Example: PHF012/T KF77 DRN112M4		
Planetary gear unit	P	Gear unit type
	H	Hollow shaft
	F	Flange-mounted design
	012	Gear unit size
	/T	Torque arm
Primary gear unit	KF	Series
	77	Gear unit size
Motor	DRN..	Series
	112M4	Size + number of poles




18014404889238539

### 3.4 Planetary gear unit with primary gear unit combination

The planetary gear units are a combination of

- P.. planetary gear unit output stage
- RF../KF../K... primary gear unit
- Mount-on components: Motor, coupling, adapter, and backstop

The following figure shows a sample combination of a planetary gear unit, a primary gear unit and a motor.




18014404759276299

- |     |   |
|-----|---|
| [1] | Motor   |
| [2] | KF../K... Bevel-helical gear unit (flange-mounted design) |
| [3] | P.. Planetary gear unit                                   |
| [4] | RF.. Helical gear unit (flange-mounted design)            |


### 3.5 Mounting position

The mounting position defines the spatial orientation of the gear unit housing and is designated **M1..M6**.

**P..RF..**



**P..KF..**



18014399537630603

27788024/EN – 12/2022



### 3.6 Pivoted mounting position: Fixed and variable mounting positions

Mounting positions deviating from the standard are distinguished as **fixed** or **variable** pivoted mounting position.

Gear units with a fixed pivoted mounting position have a fixed mounting position that differs from the standard. This means that the gear unit does not change its mounting position during operation.

Gear units with variable pivoted mounting position can change the mounting position **variably** during operation within the specified max./min. range.

The designation of pivoted and variable mounting positions is set up as follows:

**M1 - M2/20°/V**


[1] [2] [3] [4]

1811133707

- [1] Initial mounting position  
[2] Required mounting position

- [3] Pivoting angle  
[4] F = Fixed end position;  
V = Variable end position

The following figure shows examples:



9007200257525259

All final positions have to be specified if the mounting position of the gear unit deviates from standard mounting positions in several directions. Fixed and variable final positions can be combined.

Example of a gear unit based on mounting position M1 that is tilted by  $\pm 20^\circ$  around the output shaft during operation and is mounted in a fixed angle of  $30^\circ$  around the longitudinal axis:

**M1 – M2/20°/V – M4/20°/V – M5/30°/F**

## INFORMATION



Pivoted mounting positions may involve restrictions for accessories and technical data and possibly longer delivery times. Contact SEW-EURODRIVE.

### 3.7 Mounting positions of primary gear units

## INFORMATION




In addition to the mounting position, the following information is specified for planetary gearmotors.

#### 3.7.1 KF../K.. primary bevel gear units

For the KF../K.. primary bevel gear units, the positions **0°**, **90°**, **180°** or **270°** are specified.

The position of the mounting flange on the **A** or **B** side is also defined.









1043984907

To reduce the churning losses in the primary gear unit to a minimum, SEW-EURODRIVE recommends that you choose one of the standard mounting positions shown below.

## INFORMATION



Contact SEW-EURODRIVE in case of deviating mounting conditions.



18014399553181195

Key	
M1/M2/M3/M4/M5/M6	= Mounting position of planetary gear unit
0°/90°/180°/270°	= Mounting position of primary bevel gear unit
A/B	= Position of the mounting flange at the primary bevel gear unit
1) Example position; the position of the piping deviates from the figure.	

## 3.7.2 RF.. primary helical gear units


For the primary helical gear units RF..., positions **0**, **90**, **180** or **270** are fixed.

To reduce the churning losses in the primary gear unit to a minimum, SEW-EURODRIVE recommends that you choose one of the standard mounting positions shown below.

## INFORMATION



Contact SEW-EURODRIVE in case of deviating mounting conditions.









1043719691

Key	
M1/M2/M3/M4/M5/M6	= Mounting position of planetary gear unit
0°/90°/180°/270°	= Mounting position of primary helical gear unit



### 3.8 Mounting position sheets

The following table shows the symbols used in the mounting position sheets and what they mean:

Symbol	Meaning
	Breather plug
	Oil level plug
	Oil drain plug
	Breather
	Oil dipstick
	Oil sight glass



## 3.8.1 P..RF..

45 129 00 08





**3.8.2 PF..RF..**

**45 130 00 08**



## 3.8.3 P..KF../K..



45 131 00 08





3.8.4 PF.KF../K..


45 132 00 08




### 3.9 Output shaft variants

The output shaft [LSS] of the planetary gear unit can have the following design as standard:


#### 3.9.1 P.. Solid shaft with key




#### 3.9.2 P.. Solid shaft with 2 keys



#### 3.9.3 PR.. Smooth solid shaft




**3.9.4 PL.. Splined solid shaft**




17863714187

**3.9.5 PH.. Hollow shaft with shrink disk**



9007205553363339


**3.9.6 PV.. Splined hollow shaft**



17863717515

### 3.10 Components on the input side

The following figure shows the components on the input end.







27021604062840971

### 3.11 Sealing system

#### 3.11.1 Output shaft

The following table shows the output sealing systems for horizontal and vertical mounting positions.




Designation	Property	Environment	Figure
<b>Standard for mounting positions M1/M3/M5/M6</b>	Single oil seal, inside sealing with dust protection lip on a hardened sleeve [1]	Normal environment	
<b>Standard for mounting position M4 (optional for mounting positions M1/M3/M5/M6)</b>	2 oil seals, inside sealing on a hardened sleeve [1]	<b>Medium</b> dust load with abrasive particles	
<b>Standard for mounting position M2 (optional for mounting positions M1/M3/M5/M6)</b>	1 oil seal, sealing on the inside, and 1 oil seal, sealing on the outside, on a hardened sleeve [1]	<b>High</b> dust load with abrasive particles and splash water load	
<b>Radial labyrinth seal Regreasable for mounting positions M1/M2/M3/M4/M5/M6</b>	Single oil seal with radial labyrinth seal on a hardened sleeve [1]	<b>Very high</b> dust load with abrasive particles	


27788024/EN – 12/2022

### 3.12 Coating and surface protection systems

The following description provides an overview of the coating and surface protection system.

Used as surface protection under typical ambient conditions, corrosivity category DIN EN ISO 12944-2.

OS 1 low environmental pollution	
	Suited for environments prone to condensation and atmospheres with low humidity or contamination, such as outdoor applications under roof or with protection, unheated buildings where condensation can build up. According to corrosivity category: C2 (low)
Sample applications	<ul style="list-style-type: none"> <li>• Systems in saw mills</li> <li>• Agitators and mixers</li> </ul>
Condensation test ISO 6270	120 h
Salt spray test ISO 7253	–
OS 2 medium environmental pollution	
	Suited for environments with high humidity or moderate atmospheric contamination, such as applications outdoors subject to direct weathering. According to corrosivity category: C3 (moderate)
Sample applications	<ul style="list-style-type: none"> <li>• Applications in gravel plants</li> <li>• Cableways</li> </ul>
Condensation test ISO 6270	120 h
Salt spray test ISO 7253	240 h
OS 3 high environmental pollution	
	Suited for environments with high humidity and occasionally severe atmospheric and chemical contamination. Occasional acidic or caustic wet cleaning. Also for applications in coastal areas with moderate salt load. According to corrosivity category: C4 (high)
Sample applications	<ul style="list-style-type: none"> <li>• Port cranes</li> <li>• Sewage treatment plants</li> <li>• Mining applications</li> </ul>
Condensation test ISO 6270	240 h
Salt spray test ISO 7253	480 h

<b>OS 4 high environmental pollution</b>	
	Suitable for environments with permanent humidity or severe atmospheric or chemical contamination. Regular acidic and caustic wet cleaning also with chemical cleaning agents. According to corrosivity category: C5 (very high)
Sample applications	<ul style="list-style-type: none"> <li>• Drives in malting plants</li> <li>• Wet areas in the beverage industry</li> <li>• Conveyor belts in the food industry</li> </ul>
Condensation test ISO 6270	360 h
Salt spray test ISO 7253	600 h

## INFORMATION




- Standard top coat color RAL 7031, can deviate depending on the order, see order documents.
- Color according to RAL
- Water and hand perspiration repelling rust preventive for external preservation applied to uncoated parts, shaft ends/flanges.
- Sheet metal parts (such as protection covers) are painted in RAL 1003 as standard.
- If you need surface protection systems of a higher quality, contact SEW-EURODRIVE.

### 3.13 Types of lubrication

Depending on the mounting position of the planetary gear unit, two different standard lubrication variants are possible.

#### 3.13.1 Splash lubrication for horizontal mounting positions: M1/M3/M5/M6

The gear unit is half filled with oil. Gearing and bearing parts that are not immersed in the oil bath are lubricated by splashing oil. The oil level is checked at the oil sight glass [1] on the housing gear rim. The oil drain plug [2] can be replaced with an oil drain valve as an option. Oil is filled into the gear unit through the bore in which the breather [3] is installed. The breather [3] must be removed before you fill in oil.



9007215369642763



### 3.13.2 Bath lubrication for vertical mounting positions: M2/M4


The gear unit is (almost completely) filled with oil. All tooth engagement or bearing points are immersed in the oil bath completely or partly.

#### Mounting position M2

Standard lubrication type with oil expansion tank:

- Oil expansion tank [2] for volume compensation
- The oil level is checked by means of a combined oil dipstick with breather [1]
- Oil is filled in via the oil expansion tank

Sizes **P.002 – 082**:




18014402989780619

- [1] Oil dipstick with breather  
[2] Oil expansion tank

- [3] Riser pipe  
[4] Oil drain plug

Sizes **P.092 – P.102**:



18014402998269195


- [1] Oil dipstick  
[2] Breather

- [3] Oil expansion tank  
[4] Oil drain plug

**Mounting position M4**

Standard lubrication type without oil expansion tank:

- Oil level is checked using an oil dipstick
- Separate breather
- Oil is filled in via the riser pipe




[1] Breather  
[2] Oil dipstick

[3] Riser pipe  
[4] Oil drain plug

18014402999766283

### 3.14 Extended warranty



The prerequisite for claiming extended warranty is an acceptance test of the customer-installed gear unit performed by a service technician from SEW-EURODRIVE. In the interest of both parties, the inspection ensures correct installation, alignment, and proper preparation of the drive system for operation. For this reason, inspection by SEW-EURODRIVE must be performed after installation and before startup.

The following requirements apply to assembly acceptance:

- Qualified service technician of SEW-EURODRIVE
- Inspection scope:
  - Individual drive: 100 %
  - Projects > 4 gear units: 50% of the gear units/drive systems are inspected
  - Projects > 9 gear units: 30% of the gear units/drive systems are inspected

The following packages are available for the gear units.

Packages	Scope	Benefits
<b>+24</b>	24 months of warranty on the gear unit.	<ul style="list-style-type: none"> <li>• The correct installation of the gear unit is checked by an SEW service technician.</li> </ul>
<b>+24 advanced</b>	Gear unit filled with premium lubricant GearOil by SEW-EURODRIVE, giving you an additional 24 months warranty for your industrial gear unit free of charge.	<ul style="list-style-type: none"> <li>• The correct installation of the gear unit is checked by an SEW service technician.</li> </ul>

## 4 Structure of options and additional features


### 4.1 Oil expansion tank /ET

The oil expansion tank is designed to compensate for oil volume variations in the system caused by temperature fluctuations. When the gear unit temperature increases, the oil expansion tank absorbs some of the increasing oil volume and feeds it back to the gear unit as the temperature goes down, which means the gear unit is always completely filled with oil.

Based on the oil level specified by SEW-EURODRIVE, the oil expansion tank is designed to compensate the oil volume change within the permitted operating temperature range. A temperature decrease below the permitted temperature range causes the oil expansion tank to be completely emptied and air being sucked into the gear unit. This might result in insufficient lubrication and a malfunction of the gear unit. An increase above the permitted temperature range causes an overfilling of the expansion tank and oil might leak from the gear unit. During operation, any oil level above the level specified by SEW-EURODRIVE is permitted as long as there is oil in the expansion tank and the oil expansion tank does not overflow. During operation, the oil level must not be below the min. marking on the oil dipstick.

### 4.2 Oil drain

The gear unit is equipped with an oil drain plug [1] as standard. An oil drain valve [4] with screw plug [5] can optionally be added to mounting position M1, M3, M5, or M6. This valve allows for a drain pipe to be easily attached when changing the gear unit oil.



18014402746961035

#### NOTICE

The oil drain valve might be damaged if it is not sufficiently secured.

Possible damage to property.

- The oil drain valve must be additionally secured using a screw plug. At temperatures below -20 °C, the permeability of the valve might be limited.

### 4.3 Torque arm /T


A torque arm is available to support the reaction torque of solid and hollow shaft gear units in the shaft-mounted design.

Depending on the load direction and type of the customer load bearing point, the reaction torque acts as a tensile or compressive force.

#### 4.3.1 Single-sided torque arm

The torque arm is enclosed in the delivery or can be mounted according to customer requirements. The retaining screws are included in the delivery.

The following figure shows a sample combination of a planetary gearmotor with a torque arm on one side.



1138611211

### 4.4 Breather /BPG

The breather serves to prevent non-permitted pressure generated by heating or cooling during operation.


#### INFORMATION



Refer to the dimension sheet and the order documents for further information on the breather.

The following breathers can be used.

#### 4.4.1 Standard




18847956107

#### Structure

Features	
Housing material	Polyamide
Filter inserts	Polyester filter, not exchangeable
Filter size	2 µm
Threads	3/4" or 1"

#### 4.4.2 Breather with filter insert /PI



9007218102699787

The breather has the following characteristics:

- Corrosion-resistant


- Robust filter housing
- High dirt-absorbing capacity

### Structure

The breather has a corrosion-proof housing with an air intake opening at the top. The cover with protection lip keeps splashing water off.

Features	
Housing material	Polyamide
Filter inserts	Wire mesh, galvanized
Filter size	10 µm
Threads	3/4" or 1"

#### 4.4.3 Steel breather for harsh operating conditions




19118584971

### Structure

Characteristics	
Housing material	Steel
Filter inserts	Steel and aluminum wire mesh
Design	Cylindrical pipe thread according to DIN EN ISO 228-1 Dimensioned for operating conditions with special protection against drip and splash water

#### 4.4.4 Stainless steel breather for harsh operating conditions



19118584971


# 4 Structure of options and additional features

Breather /BPG

## Structure

Characteristics	
Housing material	Stainless steel
Filter inserts	Steel and aluminum wire mesh
Design	Cylindrical pipe thread according to DIN EN ISO 228-1 Dimensioned for operating conditions with special protection against drip and splash water

### 4.4.5 Desiccant breather filter /DC



9007222800055435

The breather has the following characteristics:

- Absorbs water moisture and humidity
- Reduces oil mist

## Structure

Features	
Housing material	Polycarbonate
Filter inserts	<ul style="list-style-type: none"><li>• Polyester filter: Removes air particles &gt; 3 µm</li><li>• Silica gel: Absorbs water moisture and humidity. Saturation is indicated by the color changing from blue to pink.</li><li>• Foam pad: Absorbs oil mist.</li></ul>
Threads	3/8" or 1"

27788024/EN – 12/2022



#### 4.5 Temperature sensor /Pt100

The Pt100 temperature sensor can be used to measure the temperature of the gear unit oil.

The temperature sensor is located in the oil sump of the gear unit. The exact position depends on the gear unit variant.

## 5 Installation/assembly

### 5.1 Required tools/resources

The following tools and aids are required for installation/assembly:

- Set of wrenches
- Torque wrench
- Mounting device
- Compensation elements (washers, spacing rings), if necessary
- Fasteners for input and output elements
- Lubricant, such as NOCO® fluid from SEW-EURODRIVE → except for hollow shaft gear units with shrink disk
- For hollow-shaft gear units → aids for mounting onto/removal from the machine shaft
- Fastening parts for the gear unit base

The listed tools and aids are not included in the scope of delivery.

### 5.2 Tolerances

Observe the following tolerances.

#### INFORMATION



Refer to the dimension sheet in your order documents for the tolerances of the interfaces (e.g. mounting flange) for gear unit connection.

#### 5.2.1 Planetary gear units P..

Shaft ends			
Diameter tolerance according to DIN 748:	Ø	> 50 mm	→ ISO m6
Center bores:	Ø	120 – 210 mm	→ M20
	Ø	240 – 290 mm	→ M24
Mounting flange			
Centering shoulder tolerance: ISO f9			

#### 5.2.2 Primary gear units RF../KF../K..

Shaft ends			
Diameter tolerance according to DIN 748:	Ø	≤ 50 mm	→ ISO k6
	Ø	> 50 mm	→ ISO m6
Centering bores according to DIN 332 D:	Ø	>85 – 130 mm	→ M24
	Ø	>130 – 180 mm <sup>1)</sup>	→ M30
Keys according to DIN 6885 (domed type)			

1) Dimensions not according to DIN 332; the thread depth including the counterbore is at least twice that of the nominal thread diameter

### 5.3 Important information

Read the following notes prior to installation/mounting.



#### ⚠ WARNING

Risk of crushing if the drive starts up unintentionally.  
Severe or fatal injuries.

- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up. Attach an information sign near the ON switch to warn that the gear unit is being worked on.



#### ⚠ WARNING

Danger due to mounting in impermissible mounting position.  
Severe or fatal injuries.

- Install/mount the gear unit only in the specified mounting position on a level, vibration-damping, and torsionally rigid support structure. Do not twist housing legs and mounting flanges against each other.
- Contact SEW-EURODRIVE before mounting the gear unit in another mounting position than the one permitted.



#### ⚠ WARNING

Danger due to freely accessible, rotating parts.  
Severe or fatal injuries.

- Secure rotating components such as shafts, couplings, gears or belt drives using suitable protection covers.
- Ensure that installed protection covers are sufficiently attached.



#### ⚠ WARNING

An operator machine that is not appropriately secured can fall down during gear unit installation or removal.

Severe or fatal injuries.

- Protect the operator's machine against unintentional movement when installing or removing the gear unit.
- Before releasing shaft connections, make sure that there are no active torsional moments present (tensions within the system).



#### ⚠ WARNING

Danger due to installing impermissible components.  
Severe or fatal injuries.

- Do not mount any impermissible components to the gear unit.
- Mounting impermissible components may lead to material failure at the gear unit. This may cause the gear unit to fall over or down.



### ⚠ WARNING

Danger due to using impermissible gear unit oil.

Severe or fatal injuries.

- Only use food-grade oils when the gear unit is used in the food industry.



### ⚠ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injury.

- Let the gear unit cool down before you start working on it.
- Remove the oil drain plug very carefully.



### ⚠ CAUTION

Risk of falling or ejection of unsecured mount-on components, such as keys.

Possible injuries.

- Install appropriate protective devices.
- Secure the mount-on components.



### ⚠ CAUTION

Danger due to lubricant leaking from damaged seals and the breather.

Minor injuries.

- Check the gear unit and mount-on components for leaking lubricant.
- The seals must not come in contact with cleaning agent as this may damage the seals.
- Protect the breather against damage.
- Make sure that there is not too much oil in the gear unit. If the oil level is too high and the temperature rises, lubricant may escape from the breather.



### ⚠ CAUTION

Risk of injury due to protruding parts.

Minor injuries.

- Gear units and mount-on components must not protrude into footways.

### NOTICE

Starting up the gear unit below the permitted ambient temperature may damage the unit.

Possible damage to property.

- Before startup, the oil must be heated up to the specified temperature.

## NOTICE

Improper installation and assembly can damage the gear unit.

Possible damage to property.

- Observe the following notes.

- Make sure that the customer components are designed for the load.
- The most important technical data is provided on the nameplate.
- You can find more information on operation together with the dimension sheet and further documents in the overall documentation for the gear unit.
- Do not modify the gear unit or the mount-on components without prior consultation of SEW-EURODRIVE.
- Do not change the mounting position without prior consultation with SEW-EURODRIVE. The warranty will become void without prior consultation. An oil expansion tank and/or an oil riser pipe are required if you change to a vertical mounting position. Adjust the lubricant fill quantities and the position of the breather accordingly.
- Planetary gear units are delivered without oil fill as standard.
- As standard, RF../KF../K.. primary gear units are with oil fill. Refer to the order documents for discrepancies.
- Note that planetary gear units and primary gear units have two separate oil chambers. Before startup, make sure that both gear units are filled with the correct oil fill quantity.
- In exceptional cases, planetary gear unit and primary gear unit can be delivered with a shared oil chamber. Refer to the order documents for further information. Note that with separate as well as with shared oil chambers, a nameplate is attached to the planetary gear unit and to the primary gear unit. The oil specifications on the nameplates must be added in case of a shared oil chamber.
- Note that the oil quantities on the nameplates are approximate values. The marks on the oil sight glass or oil dipstick are decisive for determining the correct oil quantity.
- The oil level plug and the oil drain plug as well as the breather must be freely accessible.
- Use plastic inserts (2 to 3 mm thick) if there is a risk of electrochemical corrosion between the gear unit and the driven machine (connection between different metals such as cast iron and stainless steel). Also fit the bolts with plastic washers. Always ground the gear unit housing.
- Only mechanical specialists may assemble gear head units with motors and adapters.
- Do not weld anywhere on the drive. Do not use the drives as a ground point for welding work. Welding may destroy gearing components and bearings.
- Units installed outdoors must be protected from the sun. Suitable protection devices are required, such as covers or roofs. When using protective devices, avoid heat build-up. The user must ensure that no foreign objects impair the function of the gear unit (e.g. due to falling objects or spillage).
- Protect the gear unit from direct cold air currents. Condensation may cause water to accumulate in the oil.
- Repair any damage to the paint work (e.g. on the breather).

## 5.4 Prerequisites for installation

### NOTICE

Danger due to insufficiently cleaned flange surfaces.

Possible damage to property.

- Clean the output shafts and flange surfaces thoroughly to ensure they are free of anti-corrosion agents, contamination or similar. Use a commercially available solvent. Do not let the solvent come into contact with the oil seals.
- 

Check that the following conditions have been met:

- The specifications on the nameplate of the motor and the electrical components match the voltage supply system.
- The drive has not been damaged during transportation or storage.
- The ambient temperature matches the information in the order documents.
- No harmful oils, acids, gases, vapors, radiation etc. in the vicinity.

### 5.4.1 Extended storage

Observe the following: The service life of the lubricant in the bearings is reduced if the unit is stored for  $\geq 1$  year (applies only to bearings with grease lubrication).

Replace the breather with a screw plug.

## 5.5 Installing the gear unit



### ⚠ WARNING

Danger due to insufficient attachment options on the part of the operator.

Severe or fatal injuries.

- Make sure that there are sufficient and suitable attachment options for the gear unit at the operator's machine before mounting the gear unit to the operator's machine.

### NOTICE

An improper foundation may result in damage to the gear unit.

Possible damage to property.

- The foundation must be level and flat; the gear unit must not be deformed when the retaining screws are tightened. Any irregularity of the surface must be leveled out appropriately.
- Observe the weight specified on the nameplate.

To ensure the quick and reliable mounting of a gear unit with foot mounting, the proper foundation should be selected and the mounting carefully planned in advance. System drawings with all necessary construction and dimension details should be available.

To ensure the quick and reliable mounting of a gear unit with flange mounting, a suitable steel construction should be selected and the mounting carefully planned in advance. System drawings with all necessary construction and dimension details should be available.

To prevent harmful vibrations and oscillations, ensure sufficient rigidity of the foundation or the steel construction during installation of the gear unit with foot or flange mounting. The foundation and steel construction must be dimensioned according to the weight and torque of the gear unit, taking into account the forces acting on the gear unit.

Tighten the retaining screws or nuts with the specified tightening torque. Use the screws and tightening torques specified in chapter "Gear unit mounting" (→ 68).

### 5.5.1 Tightening torques: Recommendations for gear unit mounting with foot-mounted design

The following table shows the thread sizes and tightening torques for mounting the individual gear unit sizes.

Mount the gear unit according to the order-specific mounting position and mounting surface using all the holes provided for the foot screw fitting.

The values given in the table for the recommended tightening torques for foot screw fittings are based on the following friction coefficient:

Friction coefficient $\mu_{GK}$ for thread and head contact surface	Strength class of the screws
0.14 – 0.24	8.8

Do not lubricate the screw connections during installation.

If you use screws with another friction coefficient, adapt the tightening torques accordingly.

Size	Screw/nut	Tightening torque screw/nut Strength class 8.8	Quantity
		Nm	
P.002	M20	460	8
P.012			
P.022			
P.032	M24	795	
P.042	M30	1590	
P.052	M36	2760	
P.062			
P.072	M42	4410	
P.082			
P.092	M48	6650	
P.102			

Use one of the recommended tools to tighten the screw connections:

- Torque wrench
- Motorized torque wrench with dynamic torque measurement
- Torque-controlled, gradual hydraulic tools



### 5.5.2 Tightening torques: Recommendations for retaining screws of gear unit mount-on parts

Tighten the screws of gear unit mount-on parts and protection covers using the following tightening torque. Do not lubricate the screw connections during installation.

The tightening torques do not apply to mounting types such as torque arm, flange-mounted gear unit, hollow shaft with shrink disk etc. These are described in the individual chapters.

Screw/nut	Tightening torque
	Strength class 8.8 Nm
M5	6.8
M6	12
M8	28
M10	56
M12	96

### 5.5.3 Foot-mounted gear unit with RF../KF../K.. primary gear unit

In case of the following combinations of foot-mounted planetary gear units with RF../KF../K.. primary gear units, the primary gear unit can be lower than the mounting surface.

#### INFORMATION




Observe **dimension A** for the following gear unit combinations. The customer base construction must be prepared accordingly.

In addition, you need enough room to perform an oil change. The customer has to specify a **dimension B** for this purpose.

	Size/combinations		Dimension A mm
	RF..	KF../K..	
P.002	-	97	10
P.012	-	107	32.5
P.022	-	107	2.5
P.022	137	-	7.5
P.032	147	-	18.5
P.092	-	187	15

The following figure shows a planetary gear unit with RF primary gear unit.



9007202573959819

### 5.5.4 Aligning the shaft axis



#### ⚠ WARNING

Shafts can break if the shaft axis is not aligned accurately.

Severe or fatal injuries.

- Refer to the separate operating instructions regarding the requirements of the coupling.

The service life of the shafts, bearings and couplings depends on the precision of the alignment of the shaft axes with each other.


Always try to achieve zero misalignment. When doing so, you should also consult the special operating instructions regarding the requirements of the couplings, for example.

## 5.6 Mounting the oil expansion tank

If the oil expansion tank has not already been installed at the factory (option), it must be installed before startup. The delivery includes the piping for installing the oil expansion tank. Install the oil expansion tank as follows depending on mounting position, size, and lubrication type.


### 5.6.1 Sizes P.002 – P.082 with bath lubrication in mounting position M2

The gear unit must not be filled with oil while installing the oil expansion tank. For gear units with factory-filled oil, drain the oil before mounting the oil expansion tank. For gear units without oil filled at the factory, do not fill the gear unit with oil until the oil expansion tank has been installed.




#### Procedure

1. Remove the two screw plugs from the connection bores [1] and [2] of the planetary gear unit.
2. Loosen the pipe fitting of the fittings [5] and [6] on the enclosed oil expansion tank.
3. Screw the pipe fitting [5] and [6] into the connection bores [1] and [2] on the planetary gear unit.
4. Mount the piping [4] and [7] with cutting ring [8] and union nut [9] to the screwed-in pipe fitting [5] and [6] on the planetary gear unit.




5. If necessary, loosen the screw fitting [3] to being able to position the piping more easily. Tighten the screw fitting [3] again.
6. Screw the two pipes [4] and [7] to the planetary gear unit using the pipe fitting [5] and [6]. When doing so, hold the pipe fitting [5] and [6] using a wrench and tighten the union nut with a wrench for approx.  $\frac{1}{4}$  turn after you feel a resistance.



23330795147

### 5.6.2 Sizes P.092 – P.102 with bath lubrication in mounting position M2


The gear unit must not be filled with oil while installing the oil expansion tank. For gear units with factory-filled oil, drain the oil before mounting the oil expansion tank. For gear units without oil filled at the factory, do not fill the gear unit with oil until the oil expansion tank has been installed.



9007222581315723


#### Procedure

1. Remove the two screw plugs from the connection bores [1] and [2] of the planetary gear unit.
2. Loosen the pipe fitting of the fittings [5] and [7] on the enclosed oil expansion tank.
3. Screw the pipe fitting [5] and [7] into the connection bores [1] and [2] on the planetary gear unit.
4. Mount the piping [4] and [6] with cutting ring [8] and union nut [9] to the screwed-in pipe fitting [5] and [7] on the planetary gear unit.



23330723339

5. If necessary, loosen the screw fitting [3] to being able to position the piping more easily. Tighten the screw fitting [3] again.
6. Screw the two pipes [4] and [6] to the planetary gear unit using the pipe fitting [5] and [7]. When doing so, hold the pipe fitting [5] and [7] using a wrench and tighten the union nut with a wrench for approx.  $\frac{1}{4}$  turn after you feel a resistance.



23330795147


## 5.7 Filling the gear unit with oil

Observe the notes in chapter "Important information" (→ 63).

### Requirements

- Use an oil from the current lubricant table:  
**[www.sew-eurodrive.de/lubricants](http://www.sew-eurodrive.de/lubricants)**
- Fill in the oil when the gear unit is in the intended mounting position.
- Make sure the oil is fluid when filling it into the gear unit. The flowability can be improved by prior heating, e.g. by using an oil heater. SEW-EURODRIVE recommends an oil temperature of 20 °C to 40 °C for filling in oil.
- Fill the gear unit with the oil grade specified on the nameplate. The oil quantity specified on the nameplate is an approximate quantity. The required oil quantity is indicated by the marks on the oil level glass.
- The required oil fill quantity is higher when additional attachments are mounted to the gear unit, such as an oil supply system. In this case, observe the respective "Oil Cooling System" operating instructions from SEW-EURODRIVE.
- For gear units with external supply pipes, e.g. oil cooling systems, establish the connections before filling the oil.
- Use a clean filling aid (plastic funnel or similar) for filling the oil. Avoid using galvanized filling aids.

### Procedure



36028797478650891

1. Open the oil fill plug.
2. Fill in the oil via the oil fill plug until the oil level reaches the center [1] of the oil sight glass.
3. Screw in the oil fill plug.

## INFORMATION



Gear unit with splash guard adapter

To speed up the filling process, remove the splash guard adapter at the oil fill opening. Then fill the oil into the gear unit. Observe chapter "Installing the splash guard adapter" for mounting the splash guard adapter.

## 5.7.1 Gear units with oil expansion tank /ET

Also observe the notes in chapter "Changing the oil" (→ 134).

**NOTICE**

An oil viscosity above the permitted level of 3500 mm<sup>2</sup>/s may result in inadequate venting and an insufficient oil filling which could damage the gear unit.

Possible damage to property.

- Observe the oil viscosity during the filling process.

**NOTICE**

An oil temperature outside the permitted range during the filling process may cause oil deficiency or oil leakage during operation.

Possible damage to property.

- The temperature of the oil to be filled must generally be within a temperature range of 10 °C and 40 °C.

A higher minimum filling temperature might be required depending on the selected oil type. The following table lists guide values.


Minimum oil filling temperature in °C		
Viscosity class	Mineral	Synthetic
ISO VG 220	10	10
ISO VG 320	10	10
ISO VG 460	15	10
ISO VG 680	20	15



## 5.8 Gear units delivered with oil fill (option)

If the gear unit is delivered with oil fill, you have to install the breather prior to startup. It is enclosed with the delivery.

The following illustration serves as an example. The position of the breather is specified in the order documents.



18014402757284107

1. Remove the closing plug.
2. Insert the breather [1].
3. Check the oil level. Observe chapter "Checking the oil level at the planetary gear unit" (→ 130).


**5.9 Gear unit with splash guard adapter (option)****NOTICE**

Improper mounting of the splash guard adapter may result in damage to the gear unit.

Possible damage to property.

- Prevent foreign particles from entering into the gear unit when performing the following work.

The splash guard adapter [2] and the breather [1] must be installed prior to startup if the gear unit is delivered with oil fill or after an oil change. They are included in the delivery of the gear unit.

**5.9.1 Installing the splash guard adapter****Procedure**

1. Clean the tapped hole and the thread of the splash guard adapter with solvent.
2. Apply liquid threadlocker, e.g. Loctite® 577, to the thread of the splash guard adapter.
3. Screw the splash guard adapter into the gear unit.
4. Align the splash guard adapter [2] in a way that the positioning mark shows in the direction of the output shaft.
5. Screw the breather [1] on the splash guard adapter [2].

## 5.10 Gear units with solid shaft

### INFORMATION



The material of the machine shaft should be dimensioned by the customer according to the loads that will occur. The shaft material should have a yield point of at least 320 N/mm<sup>2</sup>.

#### 5.10.1 Assembling the input and output components

#### NOTICE


Bearings, housing or shaft may be damaged due to improper assembly.

Possible damage to property.

- Always use a mounting device for installing input and output elements. Use the threaded centering bore on the shaft end for positioning.
- Never force belt pulleys, couplings, pinions, etc. onto the shaft end by hitting them with a hammer. This may damage the bearing, the housing and the shaft.
- If belt pulleys are used, make sure that the belt is tensioned correctly in accordance with the manufacturer's instructions.

#### Installation with mounting device

The following figure shows a mounting device for installing couplings or hubs on gear unit ends or motor shaft ends. Should you be able to tighten the screw connection without any problems, you may not need the thrust bearing on the mounting device.





211368587

- [1] Gear unit shaft end
- [2] Thrust bearing
- [3] Coupling hub

**Avoid excessive overhung loads**

To avoid high overhung loads: Install gear wheels or chain sprockets according to figure **A**, if possible.



- [1] Hub  
 [A] Correct  
 [B] Incorrect

1055550219


**INFORMATION**

Mounting is easier if you first apply lubricant containing MoS<sub>2</sub> to the output element and/or heat it up briefly (to 80 – 140° C).

## 5.11 Output shaft as hollow shaft with shrink disk

Note the following points when you assemble the shrink disk:

- Ensure that the dimensions of the machine shaft correspond to the specifications of SEW-EURODRIVE.
- The material of the machine shaft should be dimensioned by the customer according to the loads that will occur. The shaft material should have a yield point of at least 320 N/mm<sup>2</sup>.
- Note that the shrink disk is secured with 2 screws [1] on delivery. Remove the screws prior to assembly.




27021601203992459

### 5.11.1 Assembly

Observe the notes in chapter "Important information" (→ 63).


1. Before installing the shrink disk, clean and degrease the hub [1] and the machine shaft [2]. This is very important for reliable torque transmission.




18014399562333451

2. **⚠ CAUTION!** The loose shrink disk could slip. Risk of injury to persons and damage to property. Secure the shrink disk against slipping. Slide the shrink disk with untightened screws onto the hollow shaft [1] and position the inner ring of the shrink disk [8].


3. **NOTICE!** Tightening the locking screws [4] without installed machine shaft may result in the hollow shaft being deformed. Possible damage to property. Only tighten the locking screws [4] with the machine shaft [2] installed. Check the correct position of the shrink disk [3]. The shrink disk is positioned correctly when it is in contact with the shaft shoulder [7].



4. Install the machine shaft [2], or push the gear unit [5] onto the machine shaft [2] to the stop. Carry out the individual installation steps slowly to allow the compressed air to escape around the outside of the shaft.




5. To guarantee a complete torque transmission from the gear unit to the machine shaft, observe the following procedure during assembly. Push the gear unit onto the machine shaft until the contact surfaces [6] touch.





9007217842556171

6. First tighten the locking screws [4] manually. Tighten all locking screws by working round equally (not in diametrically opposite sequence) in  $\frac{1}{4}$  turn increments.



27021598817762443

7. Adhere to the tightening torque in the following table. Tighten the locking screws [4] by continuing to work round in  $\frac{1}{4}$  turns until you reach the tightening torque.



36028798072507275

8. Verify the type details on your shrink disk and choose the tightening torque.

Shrink disk type	Size	Screws	Rated torque Nm	Tightening torque Nm $\pm 20\%$
3191	P.002	M16	41000	250
3181	P.012	M16	75500	290
3181	P.022	M16	95500	290
3181	P.032	M20	134000	570
3181	P.042	M20	194000	570
3181	P.052	M20	255000	570
3181	P.062	M24	405000	980
3181	P.072	M24	525000	980
3181	P.082	M24	720000	980
3181	P.092	M27	906000	1450
3181	P.102	M27	1160000	1450

## INFORMATION



The front end surfaces of inner ring [8] and outer ring [9] need not necessarily be flush when the locking screws are tightened.



For gear units with hollow shaft and shrink disk, a protection cover may be installed as an option. The protection cover provides protection against touching the rotating output shaft.



### ⚠ CAUTION

Improper assembly of the protection cover may result in risk of injury due to rotating parts.

Possible injury to persons.

- After assembly, check to see that the protection cover is properly attached.

#### 5.11.2 Removal



### ⚠ WARNING

Improper disassembly may cause the shrink disk and/or the gear unit to fall down.

Serious injury.

- Never completely unscrew the shrink disk locking screw.
- Secure the shrink disk and the gear unit against slipping.

### NOTICE

Removing the gear unit incorrectly from the machine shaft may damage bearings and other components.

Possible damage to property.

- You may only use the hollow shaft as a support for disassembly. Note that supporting on any other parts of the gear unit may damage the material.
- Remove the shrink disk properly. Never completely unscrew the retaining screws because the shrink disk might jump off and cause an injury.
- Shrink disks and corresponding parts of different gear units must not be swapped.

Observe the notes in chapter "Important information" (→ 63).



1. **NOTICE!** Improper loosening of the locking screws can lead to straining of the connecting surface. Possible damage to property.  
Loosen the locking screws [4] by a quarter turn one after the other to avoid straining the connecting surface.

### INFORMATION




If the bevel (outer ring) [9] and the taper bushing (inner ring) [8] do not separate by themselves:

- Take the necessary number of locking screws and screw them evenly into the disassembly bores. Tighten the locking screws in several steps until the tapered bushing separates from the tapered ring.



27021598821138187

2. Remove the machine shaft [2] or pull the hub [1] off the machine shaft. If rust has formed on the shaft in front of the hub, you must remove the rust first.



36028798075882379

3. **⚠ WARNING!** The loose shrink disk could slip. Risk of injury to persons and damage to property. Secure the shrink disk against slipping. Remove the shrink disk [3] from the hub [1].

## 5.11.3 Cleaning and lubrication


**INFORMATION**

You must perform the following steps carefully to ensure proper functioning of the shrink disk. Use only products that are comparable to the specified solid lubricant.

If the tapered surfaces of the shrink disk are damaged, the shrink disk can no longer be used and must be replaced.

**Procedure**

1. Thoroughly clean the removed shrink disk from dirt and the remaining adhering lubricants.
2. Apply an MoS<sub>2</sub> compound onto the threads and under the screw heads of the locking screws [10], for example "gleitmo 100" by FUCHS LUBRITECH ([www.fuchs-lubritech.com](http://www.fuchs-lubritech.com)).
3. Also evenly lubricate the tapered surface of the taper (outer ring) [9a] with a thin layer of an MoS<sub>2</sub> compound.




18014400035867147

[9a] Taper (outer ring)

[10] Locking screws

### 5.12 Gear unit in foot-mounted design with hollow output shaft with shrink disk

1. Install the hollow shaft with shrink disk onto the machine shaft according to chapter "Output shaft as hollow shaft with shrink disk" (→ 81).
2. If there is a gap between foundation and mounting surface of the gear unit foot, compensate with shims [2] before tightening the retaining screws [1] at the gear unit foot.
3. Tighten the retaining screws [1] at the gear unit foot. Observe the tightening torques in chapter "Tightening torques: Recommendations for gear unit mounting with foot-mounted design" (→ 68).



18570924299

#### NOTICE

Static overdetermination of the gear unit might result in damage to the gear unit.

Possible damage to property.

- Make sure the gear unit is not statically overdetermined. A statically overdetermined gear unit might result in damages to the gear unit.


## 5.13 Gear unit with splining

### 5.13.1 Notes for mounting the gear unit

#### INFORMATION



The material of the machine shaft should be dimensioned by the customer according to the loads that will occur. The shaft material should have a yield point of at least 320 N/mm<sup>2</sup>.



45036011931926411

The specified tolerances for gear shaft and machine shaft correspond to the standard design. If requested by the customer, other tolerances of the gear shaft are possible.

#### NOTICE

Constraining forces can occur on the output shaft bearing due to the rigid connection between the machine shaft and the gear shaft. This may result in damages to the output shaft bearing and increased fretting corrosion in the connection between the machine shaft and the gear shaft.

Possible damage to property.

- The gear unit is usually foot or flange-mounted and used as bearing point when the machine shaft has no individual bearing or merely provides one bearing point. You have to provide for an accurate coaxial alignment with the bearing point.
- If the machine shaft has at least 2 bearing points, the gear unit should be connected merely to the machine shaft and supported with a torque arm. In order to prevent excess stress on the bearing, gear units with foot or flange mounting are to be avoided.

### 5.13.2 Mounting the gear unit onto the machine shaft

#### INFORMATION




Make sure the dimensions of the machine shaft correspond to SEW-EURODRIVE specifications → refer to the dimension sheet in your order documents.

#### Output shaft as a splined hollow shaft /..V

Observe the notes in chapter "Important information" (→ 63).

1. Apply some NOCO® FLUID on the machine shaft around the centering seat and the splining.




15633485323

2. Push the gear unit onto the machine shaft. The splining of the gear shaft must mesh with the splining of the machine shaft.
3. Make sure that the customer shaft is at the correct position in axial direction.

### Output shaft as a splined solid shaft /..L


Observe the notes in chapter "Important information" (→ 63).

1. Apply some NOCO® FLUID on the gear shaft around the centering seat and the splining.



15634076939

2. Push the gear unit onto the machine shaft. Use a mounting device, if necessary. The splining of the gear shaft must mesh with the splining of the machine shaft.



15637823371

- [1] Splined solid shaft
- [2] Thrust bearing
- [3] Coupling hub

3. Make sure that the customer shaft is at the correct position in axial direction.

### 5.13.3 Disassembling the gear unit from the machine shaft

#### NOTICE

Improper disassembly of the gear unit and machine shaft may damage bearings and other components.

Possible damage to property.

- You may only use the gear shaft as a support for disassembly. Note that supporting on any other parts of the gear unit may damage the material.

## 5.14 Torque arm

### 5.14.1 Notes on installation



#### **⚠ WARNING**

Insufficiently secured gear units can fall down during assembly/disassembly.

Severe or fatal injuries.

- Secure the gear unit during assembly/disassembly. Support the gear unit using appropriate tools.

#### **NOTICE**

Deforming the torque arm leads to constraining forces on the output shaft, which may negatively influence the service life of the output shaft bearings.

Possible damage to property.

- Do not deform the torque arm.

#### **NOTICE**

Strain on the torque arm may break the housing.

Possible damage to property.

- Adhere to the specified screw size, tightening torques and required screw strength.



#### **INFORMATION**


- Retaining screws are included in the scope of delivery.
- When using a shrink disk cover, install the torque arm before mounting the cover.



### 5.14.2 Single-sided torque arm

#### Installation situation

The torque arm can be installed at 0° to 360° in consideration of the order-specific configuration.



18014402746304779

The reactive force resulting from the gear unit torque is absorbed via the torque arm with lever arm A. The figure on the next page shows an example of a customer fixture in a welded structure. Two supporting plates are welded on the machine design with the suggested dimensions. Once the gear unit has been mounted, a connecting cover plate is welded onto the two supporting plates. The force of the gear unit torque acts on the support, divided by the length of the lever arm A. The reaction force also acts on the gear unit and machine shafts.

The figure shows a sample mounting position and the combination of a planetary gear unit with torque arm.

### Dimensions


The following figure shows a sample torque arm with dimensions.

### NOTICE

Mounting elements may be damaged by to high impacts.

Possible damage to property

- Limit the maximum clearance for the torque arm bearing according to F7 and F8 in the following table.



19817440779

Size	Dimensions in mm										Quantity	Mass
	A	B	C	D1	D2	O	F7	F8	S	T	X	kg
P.002	650	60	50	334	370	25	2	50	22	880	16	25
P.012	700	70	60	374	410	30	2	60	22	955	20	35
P.022	750	90	70	414	460	35	2	70	22	1035	24	48
P.032	800	110	90	464	510	35	2	70	26	1125	20	58
P.042	900	150	120	484	560	40	2	80	33	1270	20	93
P.052	1000	160	130	534	590	40	2	80	33	1390	24	102
P.062	1200	180	150	614	690	50	2	100	39	1655	24	183
P.072	1500	230	200	694	770	60	2	120	39	2020	24	317
P.082	1600	230	200	754	840	70	2	140	45	2160	24	420
P.092	1650	250	220	804	870	70	2	140	45	2235	24	440
P.102	1700	250	220	854	960	70	2	140	45	2335	24	510

### INFORMATION



The torque arm seat must be sufficiently dimensioned by the user.

## Tightening torques



### INFORMATION

The tightening torques listed in the following table are based on the friction coefficient for threads and a mounting surface of  $\mu = 0.11$ .

If you use other screws than those included in the delivery, adjust the tightening torques to the new friction conditions.

Use only the following tools for installation:


- Signal-generating torque wrench
- Motorized torque wrench with dynamic torque measuring
- Torque-controlled, gradual hydraulic tools

Size	Thread	Tightening torque	Strength class	DIN screws
		Nm		
P.002 – P.022	M20	555	10.9	DIN EN ISO 4017 DIN EN ISO 4762
P.032	M24	960		
P.042 – P.052	M30	1910		
P.062 – P.072	M36	3320		
P.082 – P.102	M42	5310		

### 5.15 Flange-mounted gear units

The following figure shows an example of how gear units with a flange-mounted design are installed.

Retaining screws are not included in the delivery.



54043196587609227

### INFORMATION



The tightening torques listed in the following table are based on the friction coefficient for threads and a mounting surface of  $\mu = 0.11$ .

The screws are not included in the delivery. Adjust the tightening torques to the new friction conditions.

Use only the following tools for installation:

- Signal-generating torque wrench
- Motorized torque wrench with dynamic torque measuring
- Torque-controlled, gradual hydraulic tools


The following values in the table apply to steel constructions.

Size	Thread	Quantity	Tightening torque	Dimensions in mm							Strength classes	Screws EN ISO
			Nm	Ø S	H	min. L	min. LX	Ø A	Ø B	Ø C		
P.002	M20	16	555	22	39.5	73.5	34	410	370	330 <sub>f9</sub>	10.9	4017 4762
P.012	M20	20	555	22	41.5	73.5	32	450	410	370 <sub>f9</sub>		
P.022	M20	24	555	22	48	84	36	500	460	410 <sub>f9</sub>		
P.032	M24	20	960	26	50	84	34	560	510	460 <sub>f9</sub>		
P.042	M30	20	1910	33	64	114	50	620	560	480 <sub>f9</sub>		
P.052	M30	24	1910	33	64	114	50	650	590	530 <sub>f9</sub>		
P.062	M36	24	3320	39	74	134	60	760	690	610 <sub>f9</sub>		
P.072	M36	24	3320	39	84	144	60	840	770	690 <sub>f9</sub>		
P.082	M42	24	5310	45	84	154	70	920	840	750 <sub>f9</sub>		
P.092	M42	24	5310	45	90	160	70	950	870	800 <sub>f9</sub>		
P.102	M42	24	5310	45	100	180	80	1050	960	850 <sub>f9</sub>		

## 5.16 Couplings

### 5.16.1 Aligning the coupling

Adjust the following misalignments when mounting couplings.



Use a laser-optical alignment system to align the coupling as accurately as possible.

### 5.16.2 Mounting tolerances


#### INFORMATION



- The table values for radial offset and angular offset apply to common mechanical couplings, such as elastic claw couplings or couplings with steel lamella package.
- The values listed below result from the consideration of the entire drive train and therefore differ from the tolerance values of the coupling manufacturers.
- Drive speeds greater than  $1500 \text{ min}^{-1}$  in conjunction with coupling diameters greater than 400 mm require a case-by-case test and approval.
- All tooth and barrel couplings must be set and aligned according to the respective manufacturer's operating instructions.
- The setting and alignment tolerances for special couplings must be checked and agreed on in individual cases.

Observe the following information.


**Radial misalignment**



$b$  = Max. radial offset

$D$  = Outer diameter

**Angular offset**



$a_1 - a_2$  = Max. radial offset

The installation tolerances stated in the following table apply to flexible couplings.

Outer diameter D in mm	Mounting tolerances in mm					
	$n < 500 \text{ min}^{-1}$		$n: 500 - 1500 \text{ min}^{-1}$		$n > 1500 \text{ min}^{-1}$	
	$a_1 - a_2$	$b$	$a_1 - a_2$	$b$	$a_1 - a_2$	$b$
0 – 200	0.2	0.2	0.2	0.2	0.2	0.2
200 – 400	0.3	0.3	0.3	0.3	0.3	0.3
> 400	0.3	0.3	0.3	0.3	–	–

## 5.17 AMS.. adapter

### 5.17.1 Figure and note concerning the installation of the AMS.. adapter

#### NOTICE

Damage to the adapter due to ingress of moisture or dirt (e.g. dust) when a motor/drive is attached to the adapter.


Damage to the adapter.

- Seal the adapter with an anaerobic fluid seal.
- When the motor/drive to be attached has openings or bores that provide access to the inside of the adapter, seal these against dust or liquid.

#### INFORMATION



To avoid contact corrosion, SEW-EURODRIVE recommends applying NOCO® fluid to the motor shaft before mounting the coupling half.



9007233488991243

- [1] Motor shaft
- [479] Coupling half
- [481] Set screw
- [484] Key
- A Distance A
- Z12 Distance between shaft shoulder and coupling

### 5.17.2 Fitting the motor to IEC adapters AMS63 – 225

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
2. Remove the key from the motor shaft. Replace this key with the supplied key [484]. **Notice!** The key must not protrude beyond the base of the coupling claw in the installed condition!
3. Heat the coupling half [479] to approx. 80 °C to a **maximum** of 100 °C. Slide the coupling half onto the shoulder of the motor shaft as far as it will go.
4. Check the position of the coupling half. The values for distance "A" are listed in the following table.
5. Secure the key and the coupling half to the motor shaft using the set screw [481]. Refer to the following table for the required tightening torque " $T_A$ ".
6. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
7. Fit the motor to the adapter in such a way that the coupling claws of the adapter shaft engage in the plastic coupling ring. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106).

IEC adapter AM63 to 225: Distance A and tightening torque  $T_A$

	63/71	80	90	100/112	132	160/180	200	225
A /mm	27.3	30	39	48.5	56.5	80.5	78	93
$T_A$ /Nm	1.5	2	2	4.8	10	17	17	17
Thread	M4	M5	M5	M6	M8	M10	M10	M10

### 5.17.3 Fitting the motor to IEC adapter AMS250/280 and NEMA adapter AMS56 – 365 with the provided key

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
2. Remove the key from the motor shaft.
3. Install the supplied key [484]. The position of the key is dependent upon the adapter:
  - ⇒ **AMS250-280:** The key must lie against the shoulder of the motor shaft.
  - ⇒ **NEMA:** The shoulder of the key must lie against the front of the motor shaft.
4. Heat the coupling half [479] to approx. 80 °C to a maximum of 100 °C and slide the coupling half onto the motor shaft. Slide the coupling half onto the shoulder of the key as far as it will go.
5. Check the position of the coupling half. The values for distance "A" are listed in the following table.
6. Secure the key and the coupling half to the motor shaft using the set screw [481]. Refer to the following table for the required tightening torque " $T_A$ ".
7. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
8. Fit the motor to the adapter in such a way that the coupling claws of the adapter shaft engage in the plastic coupling ring. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106).



**IEC adapter AMS250/280: Distance A and tightening torque  $T_A$**

	250/280
<b>A /mm</b>	139
<b><math>T_A</math> /Nm</b>	17
<b>Thread</b>	M10

**NEMA adapter AMS56 – 365: Distance A and tightening torque  $T_A$**

	56	143/145	182/184	213/215	254/256 284/286	324/326 364/365
<b>A /mm</b>	37.7	46.3	54.2	61.2	81.6	90.4
<b><math>T_A</math> /Nm</b>	2	2	4.8	10	17	17
<b>Thread</b>	M5	M5	M6	M8	M10	M10

**5.17.4 Fitting the motor to IEC adapters AMS250/280 and NEMA adapters AMS56 – 365 with standard key**

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
2. Remove the key from the motor shaft. Replace this with a standard key. The required standard key size can be found in the following table. **Notice!** The key must not protrude beyond the base of the coupling claw in the installed condition!
3. Heat the coupling half [479] to approx. 80 °C to a **maximum** of 100 °C and slide the coupling half onto the motor shaft. Slide the coupling half onto the motor shaft up to distance Z12. The values for distance "Z12" are listed in the following table.
4. Check the position of the coupling half. The values for distance "A" are listed in the table in chapter "Fitting the motor to IEC adapter AMS250/280 and NEMA adapter AMS56 – 365 with the provided key" (→ 100).
5. Secure the key and the coupling half to the motor shaft using the set screw [481]. The required tightening torque " $T_A$ " can be found in the table in chapter "Fitting the motor to IEC adapter AMS250/280 and NEMA adapter AMS56 – 365 with the provided key" (→ 100).
6. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
7. Fit the motor to the adapter in such a way that the coupling claws of the adapter shaft engage in the plastic coupling ring. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106).

Adapter	Z12 mm	Standard key <sup>1)</sup> inch	Standard key <sup>2)</sup> mm
<b>AMS56</b>	3.1	B3/16 × 3/16 × 7/16	–
<b>AMS143/145</b>	10.6	B3/16 × 3/16 × 9/16	–
<b>AMS182/184</b>	9	B1/4 × 1/4 × 1/2	–
<b>AMS213/215</b>	11.3	B5/16 × 5/16 × 13/16	–
<b>AMS254/256</b>	7.4	B3/8 × 3/8 × 1 1/4	–
<b>AMS284/286</b>	13.8	B1/2 × 1/2 × 1 1/4	–
<b>AMS324/326</b>	18.7	B1/2 × 1/2 × 1 1/2	–

Adapter	Z12 mm	Standard key <sup>1)</sup> inch	Standard key <sup>2)</sup> mm
AMS364/365	19	B5/8 × 5/8 × 1 1/4	—
AMS250	19	—	B18 × 11 × 70
AMS280	19	—	B20 × 12 × 70

1) The key size relates to material type 1045 or type 1018 in accordance with ASTM A 29/A29M.

2) The key size relates to material C45+C in accordance with DIN EN 10277-2.

### 5.17.5 Permitted loads

#### NOTICE

The gear unit can become overloaded due to excessive weight or the excessive power rating of an attached motor.

Gear unit damage.

- Note that the load data specified in the following table is not to be exceeded.
- Ensure that the permitted power rating (torque and speed) on the adapter is adhered to according to the nameplate.


#### NOTICE

Danger due to static overdetermination if motors are additionally attached via a foot plate.

Damage to property.

- A motor attached at the foot relieves the interface at the adapter; however, make sure that the installed foot-mounted motor is attached to the customer's construction in a stress-free manner.

The following figure shows the load caused by the mass of the motor:



27021597782736395

- ⊗ Motor center of gravity
- x Distance between adapter flange and motor center of gravity
- F<sub>R</sub> Overhung load

Permitted loads for gear unit type series R., F..<sup>2)</sup>, K., S., and W..9:

IEC adapter	x <sup>1)</sup>	Gear unit input end flange diameter	Standard	Option /DH	Option /RS
	mm	mm	F <sub>R</sub> <sup>1)</sup> in N	F <sub>R</sub> <sup>1)</sup> in N	F <sub>R</sub> <sup>1)</sup> in N
AMS63/71 <sup>2)</sup>	77	105	260	220	–
		≥ 120	530	455	–
AMS80 <sup>2)</sup>	113	105	300	265	–
		120	420	370	350
		≥ 160	1000	880	820
AMS90 <sup>2)</sup>	113	120	420	375	350
		≥ 160	1000	895	840
AMS100/112 <sup>2)</sup>	144	≥ 160	2000	1685	1685
AMS132 <sup>2)</sup>	186	160	1600	1375	1370
		≥ 200	4700	4060	4055
AMS160/180	251	≥ 250	4600	4200	4600
AMS200/225	297	≥ 300	5600	5600	5600
AMS250/280	390	≥ 450	11200	11200	11200

NEMA adapter	x <sup>1)</sup>	Gear unit input end flange diameter	Standard	Option /DH	Option /RS
	mm	mm	F <sub>R</sub> <sup>1)</sup> in N	F <sub>R</sub> <sup>1)</sup> in N	F <sub>R</sub> <sup>1)</sup> in N
AMS56	77	105	215	185	–
		≥ 120	445	385	–
AMS143/145	113	120	410	370	345
		≥ 160	965	865	820
AMS182/184	144	≥ 160	1960	1660	1660
AMS213/215	186	160	1585	1360	1360
AMS213/215		≥ 200	4640	4010	4010
AMS254 – 286	251	≥ 250	4525	4135	4525
AMS324 – 365	297	≥ 300	5600	5600	5600

1) Maximum load values for connection screws of strength class 8.8. If the center of gravity distance x increases, the maximum permitted weight F<sub>R</sub> of the attached motor must be reduced linearly. If the center of gravity distance x decreases, the maximum permitted weight F<sub>R</sub> must not be increased.

2) An extended adapter is used for certain adapter combinations with parallel-shaft helical gear units (see following table) to avoid collisions with the safety cover. This changes the maximum permitted weight F<sub>R</sub>.

Permissible power ratings and mass moments of inertia

The following table shows the permitted power ratings and mass moments of inertia:

Adapter		$P_m^{1)}$ kW	$J_{\text{Adapter}}$ kg × m <sup>2</sup>
IEC	NEMA		
AMS63	—	0.25	$0.44 \times 10^{-4}$
AMS71 <sup>2)</sup>	—	0.37	$0.44 \times 10^{-4}$
AMS80 <sup>2)3)</sup>	AMS56	0.75	$1.3 \times 10^{-4}$
AMS90 <sup>2)</sup>	AMS143/145	1.5	$2.5 \times 10^{-4}$
AMS100 <sup>2)</sup>	AMS182	3	$7.8 \times 10^{-4}$
AMS112 <sup>2)</sup>	AMS184	4	$7.8 \times 10^{-4}$
AMS132S/M <sup>2)</sup>	AMS213/215	7.5	$22 \times 10^{-4}$
AMS132ML <sup>2)</sup>	—	9.2	$22 \times 10^{-4}$
AMS160	AMS254/256	15	$72 \times 10^{-4}$
AMS180	AMS284/286	22	$72 \times 10^{-4}$
AMS200	AMS324/326	30	$201 \times 10^{-4}$
AMS225	AMS364/365	45	$204 \times 10^{-4}$
AMS250	—	55	$442 \times 10^{-4}$
AMS280	—	90	$547 \times 10^{-4}$

1) Maximum rated power of the mounted standard electric motor at 1400 min<sup>-1</sup>.

2) An extended adapter is used for certain adapter combinations with parallel-shaft helical gear units (see following table) to avoid collisions with the safety cover. This changes the mass moment of inertia.

3)  $J_{\text{AMS80/VL}} = J_{\text{AMS90}} = 2.5 \times 10^{-4} \text{ kg} \times \text{m}^2$

The specified mass moments of inertia apply for the standard adapter and the adapter with reinforced bearings (VL). An exception is the AMS80/VL adapter, which has the same inertia as the AMS90 adapter. The mass moments of inertia of the adapters with backstop AMS../RS and drain hole AMS../DH can be found in the tables in chapters "Adapter with backstop AMS../RS" and "Adapter with drain hole AMS../DH" (→ 105).

#### 5.17.6 Adapter with backstop AMS../RS

Check the direction of rotation of the drive prior to assembly or startup. In case of a wrong direction of rotation, contact SEW-EURODRIVE.

The backstop is maintenance-free in operation. Backstops have a minimum lift-off speed depending on the size (see following table).

### NOTICE

If the speed is below the minimum lift-off speed of the drive, the backstop is subject to wear and heats up.

Possible damage to property.

- In nominal operation the lift-off speed of the drive must not drop below the specified minimum.
- During startup or braking, the lift-off speed of the drive may drop below the minimum levels.

Adapter		Maximum locking torque of the back-stop	Minimum lift-off speed	J <sub>Adapter</sub>
IEC	NEMA	Nm	min <sup>-1</sup>	kg × m <sup>2</sup>
AMS80/RS	—	130	720	4.5 × 10 <sup>-4</sup>
AMS90/RS	AMS143/145/RS			
AMS100/RS	AMS182/RS	190	625	15 × 10 <sup>-4</sup>
AMS112/RS	AMS184/RS			
AMS132/RS	AMS213/215/RS	500	550	44 × 10 <sup>-4</sup>
AMS160/RS	AMS254/256/RS	900	515	108 × 10 <sup>-4</sup>
AMS180/RS	AMS284/286/RS			
AMS200/RS	AMS324/326/RS	1900	490	257 × 10 <sup>-4</sup>
AMS225/RS	AMS364/365/RS			496 × 10 <sup>-4</sup>
AMS250/RS	—			
AMS280/RS	—			601 × 10 <sup>-4</sup>

#### 5.17.7 Adapter with drain hole AMS../DH

The following table shows the maximum permissible rotational speeds and mass moments of inertia for the adapters with the drain hole option (condensation drain hole):

Adapter		Max. permitted speed	J <sub>Adapter</sub>
IEC	NEMA	min <sup>-1</sup>	kg × m <sup>2</sup>
AMS63/71/DH	—	3600	0.6 × 10 <sup>-4</sup>
AMS80/DH	AMS56/DH	3600	1.8 × 10 <sup>-4</sup>
AMS90/DH	AMS143/145/DH	3600	3.1 × 10 <sup>-4</sup>
AMS100/DH	AMS182/DH	3600	11 × 10 <sup>-4</sup>
AMS112/DH	AMS184/DH	3600	11 × 10 <sup>-4</sup>
AMS132/DH	AMS213/215/DH	3200	31 × 10 <sup>-4</sup>
AMS160/DH	AMS254/256/DH	2600	87 × 10 <sup>-4</sup>
AMS180/DH	AMS284/286/DH	2600	86 × 10 <sup>-4</sup>
AMS200/DH	AMS324/326/DH	1900	201 × 10 <sup>-4</sup>
AMS225/DH	AMS364/365/DH	1900	204 × 10 <sup>-4</sup>
AMS250/DH	—	1900	442 × 10 <sup>-4</sup>
AMS280/DH	—	1900	547 × 10 <sup>-4</sup>

### 5.17.8 Mounting of third-party motor(s) to AR../AL.. adapters

If a third-party motor is mounted, the customer must ensure that the permitted weight and the power at the adapter are adhered to according to the operating instructions. For information on the permitted loads, refer to chapter "Permitted loads" (→ 102).

Adapter	x <sup>1)</sup> mm	F <sub>R</sub> <sup>1)</sup> N
AR/AL71	77	375
AR/AL80/90	113	320
AR/AL100/112	144	1560
AR/AL132 <sup>2)</sup>	186	1230
AR/AL132	186	3630
AR/AL160/180	251	3540

1) Maximum load values for connection screws of strength class 8.8. If the center of gravity distance x increases, the maximum permitted weight F<sub>R</sub> of the attached motor must be reduced linearly. If the center of gravity distance x decreases, the maximum permitted weight F<sub>R</sub> must not be increased.

2) Gear unit input end flange diameter: 160 mm.

### 5.17.9 Tightening torques for motor to adapter

Screw the motors to the adapters with the following tightening torques. When doing this, observe the tightening torques in chapter "Notes concerning tightening torques".

Screw size	Strength class	Tightening torque ±15% Nm
M5	8.8	7
M6	8.8	12
M8	8.8	28
M10	8.8	56
M12	8.8	96
M16	8.8	235

### 5.17.10 AMS.. adapter with attached foot-mounted motor

A foot-mounted motor reduces the loads at the adapter interface. The foot-mounted motor at the adapter must be installed without tension on the customer's construction.

## 5.18 AQS.. adapter

### 5.18.1 Figure and note concerning the installation of the AQS.. adapter

#### NOTICE

Damage to the adapter due to ingress of moisture or dirt (e.g. dust) when a motor/drive is attached to the adapter.

Damage to the adapter.


- Seal the adapter with an anaerobic fluid seal.
- When the motor/drive to be attached has openings or bores that provide access to the inside of the adapter, seal these against dust or liquid.

#### INFORMATION



**With AQSA..:** To avoid contact corrosion, SEW-EURODRIVE recommends applying NOCO® fluid to the motor shaft before mounting the coupling half.

**With AQSH..:** The use of NOCO® fluid is not permitted.



34327699083

- [1] Motor shaft
- [3] Clamping screw
- [479] Coupling half
- [481] Set screw
- [484] Key
- A Distance A

### 5.18.2 Mounting of motor to adapter AQSH.. with coupling half pre-mounted in adapter

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
2. Ensure that the clamping screw [3] of the coupling is accessible through the lateral hole in the housing. **Information!** The coupling half [479] is spread apart in the delivery state.
3. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
4. Fit the motor to the adapter. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106).
5. Tighten the clamping screw of the coupling half. The values for tightening torque " $T_A$ " are listed in the table in chapter "Distances and tightening torques" (→ 109).
6. Close the lateral holes using the closing plugs.

### 5.18.3 Mounting of motor to adapter AQSH.. with coupling half pre-mounted to motor shaft

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
  2. Unscrew the clamping screw [3] of the coupling until the screw head is lying against the lateral pin. Then continue turning for half a revolution so that the coupling half [479] is spread apart.
  3. Slide the coupling half onto the motor shaft up to distance "A". The values for distance "A" are listed in the table in chapter "Distances and tightening torques" (→ 109).
  4. Check the position of the coupling half. The values for distance "A" are listed in the table in chapter "Distances and tightening torques" (→ 109).
  5. Secure the coupling half to the motor shaft. Tighten the clamping screw of the coupling half. The values for tightening torque " $T_A$ " are listed in the table in chapter "Distances and tightening torques" (→ 109).
  6. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
  7. Mount the motor onto the adapter, making sure that the claws of the two coupling halves engage in each other. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106). **Information!** The amount of mounting force can be reduced by lightly greasing or oiling the coupling ring or the coupling half. To do this, only use mineral oil-based oil or grease without additives.
  8. Close the lateral holes using the closing plugs.
- ⇒ The force that must be applied when joining the two coupling halves is dissipated after final assembly, so there is no risk of any axial load being applied to adjacent bearings.

### 5.18.4 Mounting of motor to adapter AQSA..

1. Clean the motor shaft [1] and the flange surfaces of the motor and the adapter.
2. Remove the key [484] of the motor shaft.
3. Install the supplied key so that it is as flush as possible to the claw base of the coupling.
  - ⇒ With AQSA100 – AQSA190, the key may protrude a maximum of 1 mm beyond the base of the coupling claw when installed!
4. Heat the coupling half [479] to approx. 80 °C to a **maximum** of 100 °C.



5. Slide the coupling half onto the motor shaft up to distance "A". The values for distance "A" are listed in the table in chapter "Distances and tightening torques" (→ 109).
  6. Check the position of the coupling half. The values for distance "A" are listed in the table in chapter "Distances and tightening torques" (→ 109).
  7. Secure the coupling half and the key to the motor shaft using the set screw [481]. The values for tightening torque "T<sub>A</sub>" are listed in the table in chapter "Distances and tightening torques" (→ 109).
  8. Seal the contact surfaces between the adapter and motor using a suitable sealing compound.
  9. Mount the motor onto the adapter, making sure that the claws of the two coupling halves engage in each other. Adhere to the tightening torques specified in chapter "Tightening torques for motor to adapter" (→ 106). **Information!** The mounting force can be reduced by lightly greasing or oiling the coupling ring or the coupling half. To do this, only use mineral oil-based oil or grease without additives.
  10. Close the lateral holes using the closing plugs.
- ⇒ The force that must be applied when joining the two coupling halves is dissipated after final assembly, so there is no danger of any axial load being applied to adjacent bearings.

#### 5.18.5 Distances and tightening torques

Adapter	Ø of coupling bore mm	Distance A mm	Screws		Tightening torque T <sub>A</sub> Nm	
			AQSA..	AQSH..	AQSA..	AQSH..
AQSA/AQSH50	8	23.3	–	M4	–	4.1
	9		M3		0.6	
AQSA/AQSH80	11	27.3	M4	M5	1	8.1
	14					
AQSA/AQSH100	14	30	M5	M6	2	14
	16					
	19					
AQSA/AQSH115	19	39	M5	M6	2	14
	22		–		–	14
	24		M5		2	14
AQSA/AQSH140	24	48.5	M6	M8	4.8	34
	28					
	32					
AQSA/AQSH160 AQSA/AQSH190/1 to 5	28	56.5	M8	M10	10	67
	32			M10		
	35		–	M10	–	
	38		M8	M10	10	
AQSA/AQSH190/6	35	68.5	M8	M10	10	67

## 5.18.6 Permitted loads

**NOTICE**

The gear unit can become overloaded due to excessive weight or the excessive power rating of an attached motor.

Gear unit damage.

- Note that the load data specified in the following table is not to be exceeded.
- Ensure that the permitted power rating (torque and speed) on the adapter is adhered to according to the nameplate.


**NOTICE**

Danger due to static overdetermination if motors are additionally attached via a foot plate.

Damage to property.

- A motor attached at the foot relieves the interface at the adapter; however, make sure that the installed foot-mounted motor is attached to the customer's construction in a stress-free manner.

The following figure shows the load caused by the motor mass:



27021597782736395

- ⊗ Motor's center of gravity  
 x Distance from adapter flange to motor's center of gravity  
 $F_R$  Overhung load

**Permitted loads for gear unit series R..7, F..7, K..7, K..9, S..7, S..7p and W..9:**

Adapter	$x^{1)}$ mm	Flange diameter of gear unit at the input end mm	$F_R^{1)}$ N
AQS50	45	$\geq 105$	200
AQS80	77	105	200
		$\geq 120$	370
AQS100	113	105	200
		$\geq 120$	350
AQS115	113	$\geq 120$	300

27788024/EN – 12/2022

Adapter	$x^{1)}$	Flange diameter of gear unit at the input end	$F_R^{1)}$
	mm	mm	N
AQS140	144	120	300
		$\geq 160$	1550
AQS160	144	$\geq 160$	1450
AQS190	186	160	1250
		$\geq 200$	3750


1) Maximum load values for connection screws of strength class 8.8. If the center of gravity distance  $x$  increases, the maximum permitted weight  $F_R$  of the attached motor must be reduced linearly. If the center of gravity distance  $x$  decreases, the maximum permitted weight  $F_R$  must not be increased.

## 5.19 AD input shaft assembly

Observe chapter "Assembling the input and output components" (→ 79) when installing input components.

### 5.19.1 AD../P input shaft assembly with motor platform

Mounting the motor and adjusting the motor platform.



212119307

- [1] Motor platform
- [2] Stud bolt (only AD6/P/AD7/P)
- [3] Support (only AD6/P/AD7/P)
- [4] Nut
- [5] Threaded column

Observe the notes in chapter "Important information" (→ 63).

1. Set the motor platform to the required mounting position by evenly tightening the adjusting nuts. Remove the lifting eyebolt from helical gear units to achieve the lowest adjustment position. Touch up any damage to the paint work.
2. Align the motor on the motor platform (shaft ends must be in alignment) and secure it.
3. Mount the input elements on the input shaft end and the motor shaft, line them up with one another and correct the motor position again, if necessary.
4. Put on the traction elements (V-belt, chain, etc.) and apply a pretension by evenly adjusting the motor platform. Do not stress the motor platform and the columns against each other when doing this.
5. Tighten all the nuts not used for adjustment in order to fix the threaded columns.

### 5.19.2 Only AD6/P and AD7/P

Unscrew the nuts on the stud bolts before adjustment to allow the stud bolts to move axially in the support without restriction. Do not tighten the nuts until the final adjustment position has been reached. Do not adjust the motor platform using the support.


27788024/EN – 12/2022

### 5.19.3 AD../ZR input shaft assembly with centering shoulder

Mounting components on the input shaft assembly with centering shoulder.

Observe the notes in chapter "Important information" (→ 63).

1. To fasten mount-on components to the cover with AD../ZR.. centering shoulder, use screws with appropriate length. The length  $l$  of the new screws is calculated as follows:



27021597976344459

- [l]  $t+a$
- [t] Screw-in depth (see table)
- [a] Thickness of the application
- [s] Retaining thread (see table)

**Round down the calculated screw length to the next smallest standard length.**

2. Remove the retaining screws from the centering shoulder.
3. Clean the contact surface and the centering shoulder.
4. Clean the threads of the new screws and apply a thread locking compound (e.g. Loctite® 243) to the first few threads.
5. Attach the application to the centering shoulder and tighten the retaining screws with the specified tightening torque  $T_A$  (see table).

Type	Screw-in depth $t$ mm	Retaining thread $s$	Tightening torque $T_A$ for connection screws of strength class 8.8 Nm
AD2/ZR	25.5	M8	28
AD3/ZR	31.5	M10	56
AD4/ZR	36	M12	96
AD5/ZR	44	M12	96
AD6/ZR	48.5	M16	235
AD7/ZR	49	M20	460
AD8/ZR	42	M12	96


### Permitted loads

#### NOTICE

Impermissibly high loads may occur when mounting a motor.

Possible damage to property.

- The load data specified in the following table are not to be exceeded.



1178977035

Type	$x^{1)}$ mm	$F_{q^{1)}}$ N
AD2/ZR	193	330
AD3/ZR	274	1400
AD4/ZR <sup>2)</sup>	361	1120
AD4/ZR		3300
AD5/ZR	487	3200
AD6/ZR	567	3900
AD7/ZR	663	10000
AD8/ZR	516	4300

- Maximum load values for connection screws of strength class 8.8. The maximum permitted weight of the attached motor  $F_{qmax}$  must be reduced linearly as the center of gravity distance  $x$  increases. When this distance  $x$  is reduced,  $F_{qmax}$  cannot be increased.
- Diameter of the adapter output flange: 160 mm

#### 5.19.4 Cover with backstop AD../RS

Check the direction of rotation of the drive prior to mounting or startup. Inform the SEW-EURODRIVE service in the case of incorrect direction of rotation.

During operation, the backstop is maintenance-free and does not require any maintenance. Backstops have a minimum lift-off speed depending on the size (see following table).

#### NOTICE

If the actual speed level falls below the minimum lift-off speed level, the backstops are subject to wear and the resulting friction causes the temperature to increase.


Possible damage to property.

- In nominal operation, the lift-off speeds must not drop below the minimum values.
- During startup or braking, the lift-off speeds may drop below the minimum values.


Type	Maximum locking torque of the backstop Nm	Minimum lift-off speed 1/min
AD2/RS	45	800
AD3/RS	200	670
AD4/RS	470	660
AD5/RS	630	550
AD6/RS	1430	600
AD7/RS	1430	600
AD8/RS	1430	600

**5.20 Breather for RF../KF../K... primary gear units**


Check whether the breather is activated. If the breather has not been activated, you must remove the transport protection device from the breather before starting up the gear unit.

**1. Breather with transport protection**


975574923

**2. Remove the transport protection**

211316875

**3. Activated breather**

211314699


**5.21 Temperature sensor /Pt100****5.21.1 Dimensions**

27021598123377419

Dimension "A" is determined specifically in each order.



### 5.21.2 Electrical connection



359158539

[1] [2] Resistor element connection

### 5.21.3 Technical data

- Design with thermowell and changeable measuring insert
- Sensor tolerance  $K \pm (0.3 + 0.005 \times T)$ , (corresponds to DIN IEC 751 class B),  
T = Oil temperature °C
- Plug connector: DIN EN 175301-803 PG9 (IP65)
- The tightening torque for the retaining screw in the back of the plug connector for electrical connection is 0.25 Nm.

## 6 Startup

### 6.1 Important information

Read the following notes prior to startup.



#### ⚠ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up. Attach an information sign near the ON switch to warn that the gear unit is being worked on.



#### ⚠ WARNING

Danger due to freely accessible, rotating parts.

Severe or fatal injuries.

- Secure rotating components such as shafts, couplings, gears or belt drives using suitable protection covers.
- Ensure that installed protection covers are sufficiently attached.



#### ⚠ CAUTION

Danger due to unsecured mount-on components, e.g. keys.

Possible injury to persons due to falling parts.

- Install appropriate protective devices.
- Secure the mount-on components.



#### ⚠ CAUTION

Danger due to lubricant leaking from damaged seals and the breather.

Minor injuries.

- Check the gear unit and mount-on components for leaking lubricant.
- The seals must not come in contact with cleaning agent as this may damage the seals.
- Protect the breather against damage.
- Make sure that there is not too much oil in the gear unit. If the oil level is too high and the temperature rises, lubricant may escape from the breather.

#### NOTICE

Improper startup can damage the gear unit.

Possible damage to property.

- Observe the following information.

- Before startup, check that the oil level is correct. For the lubricant fill quantities, refer to the respective nameplate.

Check the oil level again after a few operating hours, see chapter "Checking the oil level at the planetary gear unit" (→ 130).

- Planetary gear units are delivered without oil fill as standard.
- As standard, RF../KF../K.. primary gear units are with oil fill. Refer to the order documents for discrepancies.
- Note that planetary gear units and primary gear units have two separate oil chambers. Before startup, make sure that both gear units are filled with the correct oil fill quantity.
- In exceptional cases, planetary gear unit and primary gear unit can be delivered with a shared oil chamber. Refer to the order documents for further information. Note that with separate as well as with shared oil chambers, a nameplate is attached to the planetary gear unit and to the primary gear unit. The oil specifications on the nameplates must be added in case of a shared oil chamber.
- Fill the gear unit with the oil grade specified on the nameplate. The oil quantity specified on the nameplate is an approximate quantity. The required oil quantity is indicated by the marks on the oil level glass or oil dipstick. When the gear unit is equipped with an oil dipstick and an oil sight glass, refer to the oil dipstick for the correct oil level. For additional information, refer to chapter "Checking the oil level at the planetary gear unit" (→ 130) and chapter "Changing the oil at the planetary gear unit" (→ 134).

The required oil fill quantity is higher when additional attachments are mounted to the gear unit, such as an oil supply system. Observe the operating instructions of the oil supply system.

- Check the thermal rating/heating for the following operating conditions:
  - High ambient temperatures (over 45 °C).
  - Mounting position M2/M4 and/or motor speed above 1800 min<sup>-1</sup>.

Consult SEW-EURODRIVE.

- The most important technical data is provided on the nameplate. Additional data relevant for operation is available in drawings, technical specifications, or any order-specific documentation.
- After installing the gear unit, check to see that all retaining screws are tight.
- Make sure that the alignment has not changed after tightening the mounting elements.
- It is essential that there is no open fire or risk of sparks when working on the gear unit.
- If there are any oil drain valves, ensure that they cannot be opened unintentionally.
- Protect the oil sight glass against damage.
- Protect the gear unit from falling objects.
- Make sure that the gear unit is grounded. Electrical mount-on components, such as motor, frequency inverter, etc., must be grounded separately.
- Make sure that the monitoring devices (pressure switch, temperature switch etc.) are fully operational prior to and during startup.
- Observe the safety notes in the individual chapters.

**6.1.1 Permitted external loads**

During project planning, the drives are dimensioned according to the radial and axial loads described in the order confirmation.

**INFORMATION**

If the configured loads are exceeded during operation, the drive may be damaged and impermissibly high temperatures may occur.

The warranty will become void without prior consultation with SEW-EURODRIVE.

---

**6.2 Startup of gear units with long-term protection**

Adhere to the following points for gear units with long-term protection:

**6.2.1 Anti-corrosion agent**

Clean the output shafts and flange surfaces thoroughly to ensure that they are free of anti-corrosion agents, contamination or similar. Use a standard solvent.

**NOTICE**

If the dust lips of the oil seal come in contact with solvents, the dust lips can be damaged.

Possible damage to property.

- Do not let the solvent, for example, Rivolta, come into contact with the dust lips.
- 

**6.2.2 Breather**


Replace the screw plug at the location indicated on the gear unit with a breather (position → see order documents).

## 6.3 Desiccant breather filter /DC

### 6.3.1 Usage

#### Before startup

Open only 2 of the air openings (offset by 180°) at the bottom of the breather filter. Remove the blue cap that protects the rising pipe. If required, install a suitable adapter to the filter before installing the filter at the gear unit.



## 6.4 Limit temperature for gear unit start

Check if the gear unit/gearmotor is designed for the ambient temperature. For the application limits, refer to the technical documentation, the nameplate, or the lubricant table, see chapter "Permitted lubricants" (→ 142).

### NOTICE

Starting up the gear unit below the permitted minimum oil temperature may damage the unit.

Possible damage to property can occur.

- Observe the specified start temperatures for gear unit startup.

## 6.5 Backstop


### NOTICE

Operating the motor in the blocking direction could destroy the backstop.

Possible damage to property.

- Do not start up the motor in the blocking direction. Before motor startup, make sure the current supply of the motor for the direction of rotation is connected accordingly.
- For control purposes, operation in blocking direction with half the gear unit output torque is permitted once.

The backstop is installed in the AD../RS.. cover. The purpose of it is to prevent undesirable reverse rotation. During operation, the backstop permits rotation in only one specified direction of rotation.



9007217330511499

The direction of rotation is specified as viewed onto the output shaft (LSS):

- CW rotation
- CCW rotation

The permitted direction of rotation is indicated on the housing.

## 6.6 Measuring the oil temperature

The oil temperature must be measured to determine the oil change intervals. See chapter "Lubricant change intervals" (→ 129) for a description. Measure the temperature at the bottom of the gear unit. If the gear unit has an oil drain plug, measure the temperature on this screw. Add 10 K to the measured value. This value is the basis for the oil change intervals.

## 6.7 Gear unit shutdown / gear unit conservation



### ⚠ WARNING

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up. Attach an information sign near the ON switch to warn that the gear unit is being worked on.

### INFORMATION



Gear units with water cooling system: disrupt the cooling water supply and drain the water from the cooling circuit. For oil supply systems, please contact SEW-EURODRIVE.

Additional conservation measures are required if the gear unit is to be shut-down for a longer period. Note the installation site, ambient conditions and lubricant condition of the gear unit, depending on which conservation may be necessary after only a few weeks of downtime.

#### 6.7.1 Internal conservation

- **New or hardly used gear units:**
    - SEW-EURODRIVE recommends the VCI conservation method for internal conservation of the gear unit.
    - Apply the required amount of VCI anti-corrosion agent to the inside of the gear unit (e.g. FUCHS Anticorit VCI UNI O-40, [www.fuchs.com](http://www.fuchs.com)). The amount depends on the free space inside the gear unit. Any existing oil may usually remain in the drive.

Corrosion protection with VCI anti-corrosion agent is not permitted for gear units that are operated with food grade lubricants. Contact SEW-EURODRIVE in such cases.

  - Replace the breather with a screw plug and close the gear unit so that it is air tight. Mount a new breather prior to startup.
- **After longer gear unit operation:**
  - The oil might be contaminated (oil sludge, water, etc.) after long periods of operation. Therefore, drain the oil and thoroughly rinse the inside of the gear unit with new oil prior to conservation. Observe the information in chapter "Changing the oil" (→ 134) in the corresponding operating instructions. The inside of the gear unit can then be conserved as described above.

For gear units without "contactless sealing systems", you may also use the oil type indicated on the nameplate to perform the conservation. In this case, the gear unit must be completely filled with clean oil. Replace the breather with a screw plug and fill in the oil from the highest point of the gear unit. To ensure sufficient conservation, all the gearing components and bearing components must be completely covered in oil.

For gear units with "contactless sealing systems", contact SEW-EURODRIVE.


Before startup, mount a new breather. Observe the information on the nameplate regarding the oil grade and oil quantity.

**6.7.2 Exterior corrosion protection**

- Clean the respective surfaces.
- Grease the shaft near the sealing lip to separate the sealing lip of the oil seal and the anti-corrosion agent.
- Apply a wax-based protective coating to shaft ends and unpainted surfaces as external corrosion protection (e.g. Herm. Hölterhoff Hölterol MF 1424, [www.hoelterhoff.de](http://www.hoelterhoff.de)).

**INFORMATION**

Consult the respective supplier regarding the compatibility with the oil that is used and the duration of corrosion protection for your particular gear unit design.

Also observe the information in chapter "Storage and transport conditions" (→  26). This chapter provides information on the possible storage periods in conjunction with adequate packaging – depending on the storage location.

Refer to chapter "Startup" (→  118) before restarting the gear unit.

---



## 7 Inspection/maintenance

### 7.1 Preliminary work regarding inspection/maintenance

Observe the following notes before you start with inspection/maintenance work.



#### **⚠ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up. Attach an information sign near the ON switch to warn that the gear unit is being worked on.



#### **⚠ WARNING**

An operator machine that is not appropriately secured can fall down during gear unit installation or removal.

Severe or fatal injuries.

- Protect the operator's machine against unintentional movement when installing or removing the gear unit.
- Before releasing shaft connections, make sure that there are no active torsional moments present (tensions within the system).



#### **⚠ WARNING**

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injury.

- Let the gear unit cool down before you start working on it.
- Remove the oil drain plug very carefully.



#### **⚠ CAUTION**

Danger due to lubricant leaking from damaged seals and the breather.

Minor injuries.

- Check the gear unit and mount-on components for leaking lubricant.
- The seals must not come in contact with cleaning agent as this may damage the seals.
- Protect the breather against damage.
- Make sure that there is not too much oil in the gear unit. If the oil level is too high and the temperature rises, lubricant may escape from the breather.



#### **⚠ CAUTION**

Danger due to leakage of lubricant.

Injuries.

- Remove any dripping oil immediately with oil binding agent.

**NOTICE**

Filling in the wrong oil may result in significantly different lubricant characteristics.

Possible damage to property.

- Do not mix oils of different types and from different manufacturers.

**NOTICE**

Improper maintenance may result in damage to the gear unit.

Possible damage to property.

- Observe the following notes.

- Strict adherence to the inspection and maintenance intervals is absolutely necessary to ensure safe working conditions.
- Observe the tightening torques.
- For primary gearmotors, also observe the maintenance information for motor and primary gear unit in the "Gear Unit Series R..7, F..7, K..7, K..9, S..7, SPIROPLAN® W" operating instructions.
- For the position of the oil level plug, oil drain plug and breather, refer to the "mounting position sheets" (→ 41).
- Note that planetary gear units and primary gear units have 2 separate oil chambers. Before startup, make sure that both gear units are filled with the correct oil fill quantity.
- Use only original spare parts according to the delivered spare and wearing parts lists.
- Prevent foreign particles from entering into the gear unit when performing the following work.
- Never clean the gear unit with a high-pressure cleaning system. Water might enter the gear unit and the seals might be damaged.
- Replace any damaged seals.
- Perform a safety check and functional check following all maintenance and repair work.
- Observe the safety notes in the individual chapters.

## 7.2 Inspection and maintenance intervals

Adhere to the following inspection and maintenance intervals:

### 7.2.1 P.. planetary gear units

Time interval	What to do?
<ul style="list-style-type: none"> <li><b>Daily</b></li> </ul>	<ul style="list-style-type: none"> <li>Check the housing temperature: <ul style="list-style-type: none"> <li>Mineral oil: max 90 °C</li> <li>Synthetic oil: max 100 °C</li> </ul> </li> <li>Check for gear unit noise.</li> </ul>
<ul style="list-style-type: none"> <li><b>Monthly</b></li> </ul>	<ul style="list-style-type: none"> <li>Check the gear unit for signs of leakage</li> <li>Check the oil level</li> </ul>
<ul style="list-style-type: none"> <li><b>After 500 operating hours</b></li> </ul>	<ul style="list-style-type: none"> <li>First oil change after initial startup</li> </ul>
<ul style="list-style-type: none"> <li><b>Every 3000 operating hours, at least every 6 months</b></li> </ul>	<ul style="list-style-type: none"> <li>Check the oil consistency</li> </ul>
<ul style="list-style-type: none"> <li><b>Depending on the operating conditions, at least every 6 months</b></li> </ul>	<ul style="list-style-type: none"> <li>Fill regreasable sealing systems with grease</li> </ul>
<ul style="list-style-type: none"> <li><b>Depending on the operating conditions, at least every 12 months</b></li> </ul>	<ul style="list-style-type: none"> <li>Check whether retaining screws are tightly secured</li> <li>Clean the oil filter, replace filter element if necessary</li> <li>Check the breather, replace it if necessary</li> <li>Check the alignment of the input and output shaft</li> </ul>
<ul style="list-style-type: none"> <li><b>Depending on the operating conditions, at least every 3 years</b></li> </ul>	<ul style="list-style-type: none"> <li>Change mineral oil</li> </ul>
<ul style="list-style-type: none"> <li><b>Depending on the operating conditions, at least every 5 years</b></li> </ul>	<ul style="list-style-type: none"> <li>Change synthetic oil</li> </ul>
<ul style="list-style-type: none"> <li><b>Varying (depending on external factors)</b></li> </ul>	<ul style="list-style-type: none"> <li>Touch up or renew the surfaces/anti-corrosion coating</li> <li>Check installed hose pipes</li> <li>Clean the outer gear unit housing</li> </ul>

## 7.2.2 RF../KF../K... primary gear units

Time interval	What to do?
<ul style="list-style-type: none"> <li>Every 3000 operating hours, at least every 6 months</li> </ul>	<ul style="list-style-type: none"> <li>Check oil and oil level</li> <li>Check running noise for possible bearing damage</li> <li>Visual inspection of the seals for leakage</li> </ul>
<ul style="list-style-type: none"> <li>Depending on the operating conditions, every 3 years at the latest</li> <li>According to oil temperature</li> </ul>	<ul style="list-style-type: none"> <li>Change mineral oil</li> <li>Replace bearing grease (recommendation)</li> <li>Replace oil seal (do not install it in the same track again)</li> </ul>
<ul style="list-style-type: none"> <li>Depending on the operating conditions, every 5 years at the latest</li> <li>According to oil temperature</li> </ul>	<ul style="list-style-type: none"> <li>Change synthetic oil</li> <li>Replace rolling bearing grease (recommendation)</li> <li>Replace oil seal (do not install it in the same track again)</li> </ul>
<ul style="list-style-type: none"> <li>Varying (depending on external factors)</li> </ul>	<ul style="list-style-type: none"> <li>Touch up or renew the surface/anti-corrosion coating</li> </ul>

## 7.2.3 AMS/AQS adapter

Time interval	What to do?
<ul style="list-style-type: none"> <li>Every 3000 operating hours, at least every six months</li> </ul>	<ul style="list-style-type: none"> <li>Check the running noises to detect possible bearing damage.</li> <li>Perform a visual check of the adapter for leakage.</li> <li>With the drain hole design, check whether the condensation drain holes are clear.</li> </ul>
<ul style="list-style-type: none"> <li>After 10 000 operating hours</li> </ul>	<ul style="list-style-type: none"> <li>Check the rotational clearance.</li> <li>Visually check the coupling ring (AMS., EWH., or AQS., AL..).</li> </ul>
<ul style="list-style-type: none"> <li>After 10 000 operating hours with NBR/FKM oil seals</li> <li>After 20 000 operating hours with Premium Sine Seal adapter oil seals</li> </ul>	<ul style="list-style-type: none"> <li>Change the oil seal. With standard NBR or FKM oil seals, the new oil seal must not be fitted on the previous track. This is allowed with Premium Sine Seal adapter oil seals.</li> </ul>

## 7.2.4 Cover AD

Time interval	What to do?
<ul style="list-style-type: none"> <li>Every 3000 operating hours, at least every six months</li> </ul>	<ul style="list-style-type: none"> <li>Check the running noises to detect possible bearing damage.</li> <li>Perform a visual check of the adapter for leakage.</li> </ul>
<ul style="list-style-type: none"> <li>After 10 000 operating hours</li> </ul>	<ul style="list-style-type: none"> <li>Change the oil seal. Do not mount it in the same track.</li> </ul>


### 7.3 Lubricant change intervals

It might be necessary to change the oil more frequently when using special designs or under more severe/aggressive ambient conditions.

#### INFORMATION



Mineral CLP lubricants and synthetic polyalphaolefin-based (PAO) lubricants are used for lubrication. The synthetic lubricant CLP HC (according to DIN 51502) shown in the following figure corresponds to the PAO oils.



- [1] Operating hours
- [2] Sustained oil bath temperature – average value per oil type at 70 °C
- [3] CLP HC/CLP HC NSF H1
- [4] CLP (CC)/E
- [5] SEW GearOil Base
- [6] SEW GearOil Synth

#### INFORMATION



SEW-EURODRIVE recommends that the gear unit oil is analyzed regularly (see chapter "Checking the oil consistency" (→ 133)) to optimize the lubricant change intervals.

## 7.4 Checking the oil level at the planetary gear unit

Note the following when checking the oil level.

### 7.4.1 General information



#### NOTICE


Improper checking of the oil level may result in damage to the gear unit.

Possible damage to property.

- Check the oil level only when the gear unit is cooled down to room temperature.
- Check the oil level again after a few operating hours.
- When the gear unit is equipped with an oil dipstick and an oil sight glass, refer to the oil dipstick for the correct oil level. The value of the oil sight glass is only a guide value.
- If you want to check the oil level at the primary gear unit, observe the "Gear units of the R..7, F..7, K..7, K..9, S..7, SPIROPLAN® W Series" operating instructions.

### 7.4.2 Oil dipstick

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).



36028797478649227



#### INFORMATION

For gear unit sizes P.002 – P.082 in mounting position M2, oil dipstick and breather are combined in one component. For gear unit sizes P.092 – P.102 in mounting position M2 as well as all other gear unit sizes in mounting position M4, oil dipstick and breather are separate.


1. Unscrew the oil dipstick and remove it.
2. Clean the oil dipstick.
3. Re-insert the oil dipstick by turning it hand-tight into the gear unit up to the stop.
4. Remove the oil dipstick and check the oil level. The oil level must be between the markings [1] and [2].
5. Proceed as follows if the oil level is too low:

- Remove the oil fill plug.
  - Fill in oil of the same oil grade until the oil level is in the middle between marking [1] and marking [2].
6. If you filled in too much oil, proceed as follows:
    - Place a suitable container underneath the oil drain.
    - Remove the oil drain plug or open the oil drain valve.
    - Drain the oil until the oil level is between the markings [1] and [2].
    - Insert the oil drain plug or close the oil drain valve.
  7. Screw in the oil fill plug.
  8. Screw in the oil dipstick.

### 7.4.3 Oil sight glass

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Check the oil level on the oil sight glass as shown in the following figure. The oil level must be within the marked range [1].



36028797478650891

2. Proceed as follows if the oil level is too low:
  - Open the oil fill plug.
  - Fill in new oil of the same type via the oil fill plug until the oil level reaches the center of the oil sight glass.
  - Screw in the oil fill plug.

## INFORMATION




The oil fill quantity must not exceed the upper edge of the oil sight glass.

#### 7.4.4 Notes on the procedure for fixed and variable pivoted mounting positions

Observe the information on the nameplate.


##### Fixed pivoted mounting positions

Check the oil level in the fixed, intended position.




##### Variable pivoted mounting positions

Before checking the oil level of gear units with variable pivoted mounting position, position the gear unit in the mounting position defined in the order documents.





## 7.5 Checking the oil consistency

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→  125).

Proceed as follows to check the oil consistency:

1. Start the gear unit for a short time for the oil to mix with suspended particles.
2. Determine the oil drain position and place a container underneath.
3. **▲ WARNING!** Risk of burns due to hot gear unit and hot gear unit oil. Serious injury. Let the gear unit cool down before you start working on it. Remove the oil level plug and oil drain plug carefully.  
Open the oil drain carefully and drain some oil.
4. Close the oil drain valve.
5. Check the oil consistency:
  - Check the drained oil for appearance, color, and contamination.
  - If the oil sample is severely contaminated (e.g. water, color, dirt), consult a specialist to find out the cause.
  - For more detailed information on checking the oil for water content and viscosity, contact your lubricant manufacturer.

## 7.6 Changing the oil at planetary gear units

### 7.6.1 Important information

Observe the following when changing the oil.



#### ⚠ WARNING

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injury.

- Let the gear unit cool down before you start working on it.
- Remove the oil drain plug very carefully.

#### NOTICE

Improper oil change can damage the gear unit.

Possible damage to property.

- Observe the following information.


- Planetary gear units are delivered without oil fill as standard.
- As standard, RF../KF../K.. primary gear units are with oil fill. Refer to the order documents for discrepancies.
- Note that planetary gear units and primary gear units have two separate oil chambers. Before startup, make sure that both gear units are filled with the correct oil fill quantity.
- In exceptional cases, planetary gear unit and primary gear unit can be delivered with a shared oil chamber. Refer to the order documents for further information. Note that with separate as well as with shared oil chambers, a nameplate is attached to the planetary gear unit and to the primary gear unit. The oil specifications on the nameplates must be added in case of a shared oil chamber.
- Oil grade and oil viscosity are listed on the nameplate of the gear unit. Note that the oil quantities on the nameplates are approximate values. The marks on the oil sight glass or oil dipstick are decisive for determining the correct oil quantity.  
The required oil fill quantity is higher when additional attachments are mounted to the gear unit, such as an oil supply system. Observe the operating instructions of the oil supply system.
- An oil level above the max marking might indicate that foreign liquids (e.g. water) have entered. An oil level below the min. marking might indicate a leakage. Find and eliminate the cause before you fill in new oil.
- Perform the oil change quickly after you have switched off the gear unit to prevent solids from settling. If possible, drain the oil while it is still warm. Avoid oil temperatures well above 50 °C.
- Remove the screw plug before draining the oil.
- Always fill the gear unit with the same oil grade as before. Mixing oils of different grades and/or manufacturers is not permitted. Synthetic oils in particular must not be mixed with mineral oils or other synthetic oils. When switching from mineral oil and/or when switching from synthetic oil of one basis to synthetic oil of another basis, thoroughly flush the gear unit with the new oil grade.

Refer to the lubricant table for information on the permitted oil of the various lubricant manufacturers.

- When changing the oil, flush the interior of the gear unit thoroughly with oil to remove oil sludge, oil residue, and abrasion. Use the same oil grade as for operating the gear unit. Fill in fresh oil only after all residues have been removed.
- For the position of the oil level plug, the oil drain plug, and the breather, refer to the order documents.
- If required, empty accessories e.g. filters and pipes.
- Replace any damaged seals on the oil drain plug.
- If present, clean the magnetic oil drain plug and the oil dipstick with magnet tip.
- Empty the oil-bearing system of gear units with circulation lubrication and oil supply systems according to the manufacturer's maintenance instructions.
- Elements for checking the oil level, oil drain and oil fill openings are indicated by safety symbols on the gear unit.

## 7.6.2 Procedure

Sizes P.002 - P.102 with splash lubrication in mounting positions M1/M3/M5/M6



18014402746961035

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Place a suitable container underneath the oil drain plug [1].
2. Remove the oil drain plug [1]/screw plug [5].
3. Remove the oil fill plug or the breather [2]. With gear units that are not equipped with an oil fill plug due to their mounting position, the breather is used as oil filling hole.
4. Open the oil drain valve [4] if required.
5. Drain all the oil.
6. Close the oil drain valve [4] if required.
7. Screw in the oil drain plug [1]/screw plug [5] again.
8. Fill in new oil of the same grade through the oil fill opening.
  - The oil quantity specified on the nameplate is an approximate quantity. The mark on the oil sight glass [3] or the oil dipstick is the decisive indicator of the correct oil quantity, see chapter "Checking the oil level of the planetary gear unit" (→ 130).
  - Use a clean filling aid (plastic funnel or similar). Avoid using galvanized filling aids.
9. Insert the oil fill plug or the breather [2].

### ⚠ CAUTION


Danger due to leakage of lubricant.

Injuries.

- Remove any dripping oil immediately with oil binding agent.



Sizes P.002 – P.082 with bath lubrication in mounting position M2



18014402989780619

- [1] Oil dipstick with breather  
[2] Oil expansion tank

- [3] Riser pipe  
[4] Oil drain plug

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Place a suitable container underneath the oil drain plug [4].
2. Remove the oil drain plug [4].
3. Remove the oil dipstick/breather [1].
4. Drain all the oil.
5. Re-insert the oil drain plug [4].
6. Fill in new oil of the same grade through the oil fill opening [1].
  - The oil quantity specified on the nameplate is an approximate quantity. The mark on the oil sight glass or oil dipstick is the decisive indicator of the correct oil quantity, see "Checking the oil level at the planetary gear unit" (→ 130).
  - Use a clean filling aid (plastic funnel or similar). Avoid using galvanized filling aids.
7. Screw in the oil dipstick/breather [1].

**⚠ CAUTION**


Danger due to leakage of lubricant.

Injuries.

- Remove any dripping oil immediately with oil binding agent.



### Sizes P.092 - P.102 with bath lubrication in mounting position M2



18014402998269195

- |                  |                        |
|------------------|------------------------|
| [1] Oil dipstick | [3] Oil expansion tank |
| [2] Breather     | [4] Oil drain plug     |

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Place a suitable container underneath the oil drain plug [4].
2. Remove the oil drain plug [4].
3. Remove the oil dipstick [1].
4. Drain all the oil.
5. Re-insert the oil drain plug [4].
6. Fill in new oil of the same grade through the oil filling hole [1].
  - The oil quantity specified on the nameplate is an approximate quantity. The mark on the oil sight glass or oil dipstick is the decisive indicator of the correct oil quantity, see "Checking the oil level at the planetary gear unit" (→ 130).
  - Use a clean filling aid (plastic funnel or similar). Avoid using galvanized filling aids.
7. Screw in the oil dipstick [1].

#### ⚠ CAUTION


Danger due to leakage of lubricant.

Injuries.

- Remove any dripping oil immediately with oil binding agent.



Sizes P.002 - P.102 with bath lubrication in mounting position M4



18014402999766283

[1] Breather  
[2] Oil dipstick

[3] Riser pipe  
[4] Oil drain plug

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Place a suitable container underneath the oil drain plug [4].
2. Remove the oil drain plug [4].
3. Remove the oil dipstick [2].
4. Drain all the oil.
5. Re-insert the oil drain plug [4].
6. Fill in new oil of the same grade through the oil filling hole [2].
  - The oil quantity specified on the nameplate is an approximate quantity. The mark on the oil sight glass or oil dipstick is the decisive indicator of the correct oil quantity, see "Checking the oil level at the planetary gear unit" (→ 130).
  - Use a clean filling aid (plastic funnel or similar). Avoid using galvanized filling aids.
7. Screw in the oil dipstick [2].

**⚠ CAUTION**

Danger due to leakage of lubricant.

Injuries.

- Remove any dripping oil immediately with oil binding agent.



## 7.7 Refilling sealing grease



### ⚠ WARNING

Risk of crushing due to rotating parts.

Severe or fatal injuries.

- Make sure to provide for sufficient safety measures during relubrication.




### INFORMATION

Turn the shaft slowly when you relubricate the labyrinth seal. Doing so provides for a better grease distribution.

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Use moderate pressure to force grease into each lubrication point [1] until grease leaks out of the sealing gap [2]. The grease must leak out evenly over the entire circumference of the sealing gap.



45036000508837899



### INFORMATION

Immediately remove the old grease that leaked out. Old grease can leak out between labyrinth ring and output flange.



## 7.8 Breather /BPG

### 7.8.1 Checking and cleaning the breather

#### NOTICE

Improper cleaning of the breather may damage the gear unit.

Possible damage to property.

- Prevent foreign particles from entering into the gear unit when performing the following work.

Observe the notes in chapter "Preliminary work regarding inspection and maintenance" (→ 125).

1. Remove any deposits near the breather.
2. If the breather is clogged, replace it.

### 7.8.2 Desiccant breather filter /DC

#### Proper operation:

If possible, use desiccant breather filters only for gear units filled with new oil that do not contain water. Only then can the maximum service life of the filter be ensured.

The service life of the filters usually is 12 months, after that time the filters must be replaced. In case the filters are operated in a highly contaminated environment, the service life of the filters can be limited to 2 months or less. The color of the granulate indicates whether a filter needs to be replaced or whether it can still be used.

Color/color transition	Distribution of color gradient	Meaning	Action
Blue → pink	Filter top → filter bottom	Moisture in the gear unit	Determine the cause
Entirely pink or white	Entire filter	Filter capacity exhausted	Replace the filter

Once the capacity of the filter is exhausted, the desiccant breather filters change their color from blue to pink, proceeding from the bottom of the filter to the top.

If the main part of the breather valve has changed its color to pink (or white after a longer time), the breather filter must be replaced by a new one.

If the color changes from top to bottom, this indicates that a large amount of moisture is in the gear unit.

#### Disposal

If the desiccant breather filter must be replaced, it is likely to contain oil vapor. The filter must be disposed of in accordance with the corresponding regulations.

## 8 Permitted lubricants

This chapter describes the permitted lubricants and the permitted temperatures for industrial gear units from SEW-EURODRIVE.

### 8.1 Lubricant selection

Note the following when selecting the lubricants.

#### NOTICE

Selecting improper lubricants may damage the gear unit.

Possible damage to property.

- Observe the following notes.

- The oil viscosity and type (mineral/synthetic) to be used are determined by SEW-EURODRIVE specifically for each order. This information is noted in the order confirmation and on the gear unit's nameplate.

If other lubricants are used in the gear units and/or in other temperature ranges as those recommended, the right to claim under warranty will become invalid. Exceptions are application-specific approvals that have to be confirmed by SEW-EURODRIVE in written form.

The lubricant recommendation in the lubricant table in no way represents a guarantee regarding the quality of the lubricant delivered by each respective supplier. Each lubricant manufacturer is responsible for the quality of its product.

- Oils of the same viscosity class from different manufacturers do not have the same characteristics. In particular, the minimum permitted oil bath temperatures are manufacturer-specific. These temperatures are specified in the lubricant tables.
- The minimum permitted oil bath temperatures depend on the lubrication type used. These temperatures are specified in the lubricant tables. The values correspond to the maximum viscosity of the individual lubricants.
- The values specified in the lubricant tables apply as of the time of printing of this document. The data of the lubricants are subject to dynamic change on the part of the lubricant manufacturers. For up-to-date information about the lubricants, visit:

**[www.sew-eurodrive.de/lubricants](http://www.sew-eurodrive.de/lubricants)**

- Before startup, ensure that the planetary gear unit and the primary gear unit are filled with the correct oil grade and quantity. You can obtain the corresponding information from the gear unit nameplate and the lubricant table on the following page.
- As standard, planetary gear units and primary gear units have separate oil chambers. With separate oil chambers, the planetary gear unit is delivered without oil, the primary gear unit is delivered with oil.
- The lubricant fill quantity and viscosity of planetary gearmotors with common oil chamber depend only on the information on the nameplate of the planetary gear unit. Planetary gear units and primary gear units with a common oil chamber are delivered without oil fill as standard.
- Do not mix different synthetic lubricants and do not mix synthetic with mineral lubricants.
- Check the compatibility of the greases and oils used.
- Observe the safety notes in the individual chapters.





## 8.2 Structure of the tables and abbreviations

			<b>SEW EURODRIVE</b>
[2]			-20 -5 +5
			+65
		VG 150 <sup>1)</sup>	SEW GearOil Base 150 E1 SEW070040013
[1]			-15 0 +10
			+75
		VG 220	SEW GearOil Base 220 E1 SEW070040013
			-10 +5 +15
			+85
		VG 320	SEW GearOil Base 320 E1 SEW070040013

27021615684069515

- [1] Lubricant type  
[2] Viscosity class

### Abbreviations

Icons	Designation
CLP	= Mineral oil
CLP HC	= Synthetic polyalphaolefin (PAO)
E	= Ester-based oil
	= Mineral lubricant
	= Synthetic lubricant
	= Lubricant for the food industry ( <b>NSF H1</b> -compliant)
	= Biodegradable oil (lubricant for agriculture, forestry, and water management)
1)	= Lubricants may only be used if service factor $F_s \geq 1.3$

### 8.3 Explanation of the various lubricants

			[5]
[1]	-20		
[2]	-5	+65	[6]
[3]	+5		
[4]	xyz		
	SEW070040013		[7]

18014416413363467

- [1] Lowest cold start temperature in °C for splash lubrication<sup>1)</sup>
- [2] Lowest cold start temperature in °C for drives with pumps up to a max. oil viscosity of 5000 cSt<sup>1)</sup>
- [3] Lowest cold start temperature in °C for drives with pumps up to a max. oil viscosity of 2000 cSt<sup>1)</sup>
- [4] Trade name
- [5] Manufacturer
- [6] Highest oil bath temperature in °C<sup>2)</sup>
- [7] Approvals

1) In case of low temperatures, the oil must be heated to the specified minimum temperature, for example, by using an oil heater. For the maximum permitted oil viscosity per pump type, refer to the following chapter.

2) Service life is significantly reduced when exceeded. Observe chapter "Lubricant change intervals".








## 8.4 Lubricant tables

This lubricant table is valid when the document is published. Please refer to [www.sew-eurodrive.de/schmierstoffe](http://www.sew-eurodrive.de/schmierstoffe) for the latest version of the table.

[1]	[2]	SEW EURODRIVE	Castrol	FUCHS	Mobil®	KLÜBER LUBRICATION	SINOPEC	TOTAL
CLP	VG 150	SEW GearOil Base 150 E1 / US1 / CN1 / BR1	Optigear BM 150	Renolin CLP 150 Plus	Mobilgear 600 XP 150	Klüberoil GEM 1-150 N	AP-SGO 150	
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
CLP	VG 220	SEW GearOil Base 220 E1 / US1 / CN1 / BR1	Optigear BM 220	Renolin CLP 220 Plus	Mobilgear 600 XP 220	Klüberoil GEM 1-220 N	AP-SGO 220	Carter EP 220
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
CLP	VG 320	SEW GearOil Base 320 E1 / US1 / CN1 / BR1	Optigear BM 320	Renolin CLP 320 Plus	Mobilgear 600 XP 320	Klüberoil GEM 1-320 N	AP-SGO 320	Carter EP 320
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
CLP	VG 460	SEW GearOil Base 460 E1 / US1 / CN1 / BR1	Optigear BM 460	Renolin CLP 460 Plus	Mobilgear 600 XP 460	Klüberoil GEM 1-460 N	AP-SGO 460	Carter EP 460
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
CLP	VG 680	SEW GearOil Base 680 E1 / US1 / CN1 / BR1	Optigear BM 680	Renolin CLP 680 Plus	Mobilgear 600 XP 680	Klüberoil GEM 1-680 N	AP-SGO 680	Carter EP 680
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
CLP	VG 1000	SEW GearOil Base 1000 E1 / US1 / CN1 / BR1	Optigear BM 1000	Renolin CLP 1000 Plus	Mobilgear 600 XP 1000	Klüberoil GEM 1-1000 N	AP-SGO 1000	Carter EP 1000
		SEW070040013		SEW070030013	SEW070030013		SEW070030013	
		-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	-20 -5 +65	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	
		-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	-15 +75	
		0 +10	0 +10	0 +10	0 +10	0 +10	0 +10	

27021622249421707

This lubricant table is valid when the document is published. Please refer to [www.sew-eurodrive.de/schmierstoffe](http://www.sew-eurodrive.de/schmierstoffe) for the latest version of the table.

[1]	[2]									
	VG 32 <sup>1)</sup>				<div><div>-40</div><div>-30</div><div>-25</div><div>+30</div></div> <div>SHC 624</div>					
	VG 68 <sup>1)</sup>			<div><div>-35</div><div>-20</div><div>-10</div><div>+50</div></div> <div>Renolin Unisyn CLP 68</div>		<div><div>-35</div><div>-20</div><div>-10</div><div>+50</div></div> <div>Klüber synth GEM 4-68 N</div>				
	VG 150 <sup>1)</sup>	<div><div>-35</div><div>-15</div><div>-5</div><div>+75</div><div>0</div></div> <div>GearOil Synth 150 E1</div>	<div><div>-25</div><div>-10</div><div>0</div><div>+70</div><div>0</div></div> <div>Alphasyn EP 150</div>	<div><div>-30</div><div>-10</div><div>+0</div><div>+70</div><div>+0</div></div> <div>Optigear Synthetic X 150</div>	<div><div>-30</div><div>-10</div><div>-10</div><div>+70</div><div>+0</div></div> <div>Renolin Unisyn CLP 150</div>		<div><div>-30</div><div>-10</div><div>0</div><div>+75</div><div>-5</div></div> <div>SHC 629</div>	<div><div>-25</div><div>-10</div><div>0</div><div>70</div><div>0</div></div> <div>Klüber synth GEM 4-150 N</div>	<div><div>-30</div><div>-10</div><div>0</div><div>+75</div><div>-5</div></div> <div>Omala S4 GX 150</div>	<div><div>-35</div><div>-15</div><div>-5</div><div>+75</div><div>-5</div></div> <div>Carter SH 150</div>
	VG 220	<div><div>-30</div><div>-10</div><div>0</div><div>+85</div><div>+5</div></div> <div>GearOil Synth 220 E1</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+80</div><div>+5</div></div> <div>Alphasyn EP 220</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+80</div><div>+5</div></div> <div>Optigear Synthetic X 220</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+80</div><div>+5</div></div> <div>Renolin Unisyn CLP 220</div>		<div><div>-25</div><div>-5</div><div>0</div><div>+85</div><div>+5</div></div> <div>SHC 630</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+80</div><div>+5</div></div> <div>Klüber synth GEM 4-220 N</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+85</div><div>+5</div></div> <div>Omala S4 GX 220</div>	<div><div>-25</div><div>-5</div><div>+5</div><div>+80</div><div>+5</div></div> <div>Carter SH 220</div>
	VG 320	<div><div>-25</div><div>-5</div><div>+5</div><div>+100</div><div>+10</div></div> <div>GearOil Synth 320 E1</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+90</div><div>+10</div></div> <div>Alphasyn EP 320</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+90</div><div>+10</div></div> <div>Optigear Synthetic X 320</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+90</div><div>+10</div></div> <div>Renolin Unisyn CLP 320</div>		<div><div>-20</div><div>0</div><div>+10</div><div>+95</div><div>+10</div></div> <div>SHC 632</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+95</div><div>+10</div></div> <div>Klüber synth GEM 4-320 N</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+95</div><div>+10</div></div> <div>Omala S4 GX 320</div>	<div><div>-20</div><div>0</div><div>+10</div><div>+90</div><div>+10</div></div> <div>Carter SH 320</div>
	VG 460	<div><div>-20</div><div>-5</div><div>+15</div><div>+110</div><div>+15</div></div> <div>GearOil Synth 460 E1</div>	<div><div>-15</div><div>+5</div><div>+15</div><div>+100</div><div>+15</div></div> <div>Alphasyn EP 460</div>	<div><div>-15</div><div>+5</div><div>+15</div><div>+100</div><div>+15</div></div> <div>Optigear Synthetic X 460</div>	<div><div>-15</div><div>+5</div><div>+15</div><div>+100</div><div>+15</div></div> <div>Renolin Unisyn CLP 460</div>		<div><div>-15</div><div>+5</div><div>+15</div><div>+105</div><div>+15</div></div> <div>SHC 634</div>	<div><div>-15</div><div>+5</div><div>+20</div><div>+105</div><div>+15</div></div> <div>Klüber synth GEM 4-460 N</div>	<div><div>-15</div><div>+5</div><div>+15</div><div>+105</div><div>+15</div></div> <div>Omala S4 GX 460</div>	<div><div>-15</div><div>+5</div><div>+15</div><div>+100</div><div>+15</div></div> <div>Carter SH 460</div>
	VG 680	<div><div>-15</div><div>+5</div><div>+20</div><div>+110</div><div>+20</div></div> <div>GearOil Synth 680 E1</div>		<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>Optigear Synthetic X 680</div>	<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>Renolin Unisyn CLP 680</div>		<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>SHC 636</div>	<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>Klüber synth GEM 4-680 N</div>	<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>Omala S4 GX 680</div>	<div><div>-10</div><div>+10</div><div>+25</div><div>+110</div><div>+25</div></div> <div>Carter SH 680</div>
	VG 1000						<div><div>-10</div><div>+15</div><div>+30</div><div>+110</div><div>+30</div></div> <div>SHC 639</div>	<div><div>-10</div><div>+15</div><div>+30</div><div>+110</div><div>+30</div></div> <div>SHC Gear 1000</div>	<div><div>0</div><div>+20</div><div>+30</div><div>+110</div><div>+30</div></div> <div>Klüber synth EG4-1000</div>	

CLP HC

18014423000933387

2202/21 – NE/42088LL2

This lubricant table is valid when the document is published. Please refer to [www.sew-eurodrive.de/schmierstoffe](http://www.sew-eurodrive.de/schmierstoffe) for the latest version of the table.

[1]	[2]	[3]	SEW EURODRIVE	bremser & leguit	Castrol	FUCHS	KLÜBER LUBRICATION
		VG 68 <sup>1)</sup>		<div> <div>-35</div> <div>-20</div> <div>-10</div> <div>+45</div> </div> <div>Cassida Fluid HF 68</div>	<div> <div>-40</div> <div>-25</div> <div>-15</div> <div>+45</div> </div> <div>Optileb HY 68</div>	<div> <div>-35</div> <div>-20</div> <div>-10</div> <div>+45</div> </div> <div>Cassida Fluid HF 68</div>	<div> <div>-35</div> <div>-20</div> <div>-10</div> <div>+45</div> </div> <div>Klüberoil 4UH1-68 N</div>
	CLP HC <sub>2</sub> NSF H1	VG 220 <sup>1)</sup>	<div> <div>-30</div> <div>-5</div> <div>0</div> <div>+80</div> </div> <div>SEW GearOil Synth 220 H1 E1</div> <div>SEW 070040313</div>	<div> <div>-20</div> <div>-5</div> <div>+5</div> <div>+75</div> </div> <div>Cassida Fluid GL 220</div>	<div> <div>-25</div> <div>-5</div> <div>+5</div> <div>+75</div> </div> <div>Optileb GT 220</div> <div>SEW 0700403113</div>	<div> <div>-20</div> <div>-5</div> <div>+5</div> <div>+75</div> </div> <div>Cassida Fluid GL 220</div>	<div> <div>-25</div> <div>-5</div> <div>+5</div> <div>+75</div> </div> <div>Klüberoil 4UH1-220 N</div>
		VG 460 <sup>1)</sup>	<div> <div>-20</div> <div>0</div> <div>+15</div> <div>+100</div> </div> <div>SEW GearOil Synth 460 H1 E1</div> <div>SEW 070040313</div>	<div> <div>-15</div> <div>+5</div> <div>+20</div> <div>+90</div> </div> <div>Cassida Fluid GL 460</div>	<div> <div>-15</div> <div>+5</div> <div>+20</div> <div>+95</div> </div> <div>Optileb GT 460</div> <div>SEW 070040313</div>	<div> <div>-15</div> <div>+5</div> <div>+20</div> <div>+90</div> </div> <div>Cassida Fluid GL 460</div>	<div> <div>-15</div> <div>+5</div> <div>+20</div> <div>+95</div> </div> <div>Klüberoil 4UH1-460 N</div>
		VG 680 <sup>1)</sup>		<div> <div>-10</div> <div>+10</div> <div>+25</div> <div>+105</div> </div> <div>Cassida Fluid GL 680</div>		<div> <div>-10</div> <div>+10</div> <div>+25</div> <div>+105</div> </div> <div>Cassida Fluid GL 680</div>	<div> <div>-10</div> <div>+10</div> <div>+25</div> <div>+105</div> </div> <div>Klüberoil 4UH1-680 N</div>
		VG 320				<div> <div>-20</div> <div>0</div> <div>+10</div> <div>+8a5</div> </div> <div>Plantogear 320 S</div>	<div> <div>-20</div> <div>0</div> <div>+10</div> <div>+85</div> </div> <div>Klüberbio EG2-320</div>
	E	VG 460				<div> <div>-15</div> <div>+5</div> <div>+15</div> <div>+95</div> </div> <div>Plantogear 460 S</div>	<div> <div>-15</div> <div>+5</div> <div>+15</div> <div>+95</div> </div> <div>Klüberoil 4UH1-460 N</div>

27021622249424139

1) Lubricants may only be used if the service factor  $F_s$  and peak load factor  $F_F \geq 1.6$ .

The peak output torque  $M_{K2per}$  is limited as follows:  $F_F \geq 1.6 \rightarrow M_{K2per} \leq 1.25 \times M_{N2}$  (nominal torque)  $\rightarrow M_{K2per} \leq 2 \times M_{N2} / F_F = 2 / 1.6 \times M_{N2}$ .

In case of deviations, contact SEW-EURODRIVE.

2) NSF-H1 registered oils for the food processing industry cannot be combined with the gear unit option "Extended storage" (a VCI anti-corrosion agent is added).

#### NOTICE:

The thermal operating limits of the oil seal materials must also be taken into account, see chapter "Lubricant compatibility with oil seal" ( $\rightarrow$  151).

## 8.5 Lubricant fill quantities

Observe the notes in chapter "Lubricant selection" (→ 142).

The specified fill quantities are **guide values**. The precise values vary depending on the number of stages and gear ratios.

Observe the following information:

### INFORMATION



- The oil chambers of planetary gear unit and primary gear unit are separate as standard. In exceptional cases, planetary gear unit and primary gear unit can be delivered with a shared oil chamber. Refer to the order documents for further information.
- Planetary gear units are supplied without lubricant as standard.
- RF.., KF.., and K.. primary gear units are filled with lubricant at the factory depending on the mounting position.
- For pivoted mounting positions adhere to the lubricant fill quantity on the nameplates.
- The lubricant values und the nameplate are guide values. The required oil quantity depends on the respective marks on the oil sight glass or oil dipstick.

### 8.5.1 P.. planetary gear units

The oil level of planetary gear units is checked using the oil sight glass or oil dipstick.

The table below shows the lubricant fill quantities for planetary gear units.

Size	Mounting position					
	M1	M2	M3	M4	M5	M6
	Liters					
P.002	5	9	5	7	5	5
P.012	7	12	7	10	7	7
P.022	9	18	9	18	9	9
P.032	12	21	12	21	12	12
P.042	16	30	16	25	16	16
P.052	20	36	20	30	20	20
P.062	28	54	28	49	28	28
P.072	35	67	35	59	35	35
P.082	49	94	49	81	49	49
P.092	62	134	62	103	62	62
P.102	71	153	71	121	71	71



## 8.5.2 Primary gear units

### Bevel (KF/K) primary gear units

#### INFORMATION



- The lubricant fill quantity depends on the mounting position of the planetary gear unit and the mounting position of the KF.. and K.. primary gearmotor.
- For notes on the mounting positions of KF.. and K.. primary gear units, see chapter "KF../K.. primary bevel gear units" (→ 38).
- The oil level of primary gear units is checked using the oil level plug.

The table below shows the lubricant fill quantities.

Size	Fill quantities in liters											
	M1				M2				M3			
	0° A	90° A	180° B	270° A	0° A	90° A	180° A	270° A	0° B	90° A	180° A	270° A
KF67	1.1	2.4	1.1	3.7	2.7	2.7	2.7	2.7	1.1	3.7	1.1	2.4
KF77	2.1	4.1	2.1	5.9	4.5	4.5	4.5	4.5	2.1	5.9	2.1	4.1
KF87	3.7	8.2	3.7	11.9	8.4	8.4	8.4	8.4	3.7	11.9	3.7	8.2
KF97	7	14.7	7	21.5	16.5	16.5	16.5	16.5	7	21.5	7	14.7
KF107	10	21.8	10	35.1	25.2	25.2	25.2	25.2	10	35.1	10	21.8
KF127	21	41.5	21	55	41	41	41	41	21	55	21	41.5
KF157	31	62	31	92	62	62	62	62	31	92	31	66
K167	33	95	33	123	95	95	95	95	105	33	105	85
K187	53	152	53	200	152	152	152	152	167	53	167	143

Size	Fill quantities in liters											
	M4				M5				M6			
	0° A	90° A	180° B	270° A	0° A	90° B	180° A	270° A	0° B	90° A	180° A	270° B
KF67	2.7	2.7	2.7	2.7	2.4	1.1	3.7	1.1	3.7	1.1	2.4	1.1
KF77	4.5	4.5	4.5	4.5	4.1	2.1	5.9	2.1	5.9	2.1	4.1	2.1
KF87	8.4	8.4	8.4	8.4	8.2	3.7	11.9	3.7	11.9	3.7	8.2	3.7
KF97	15.7	15.7	15.7	15.7	14.7	7.0	21.5	7	21.5	7.0	14.7	7
KF107	25.2	25.2	25.2	25.2	21.8	10	35.1	10	35.1	10	21.8	10
KF127	41	41	41	41	41.5	21	55	21	55	21	41.5	21
KF157	62	62	62	62	66	31	90	31	92	31	66	31
K167	123	123	123	123	85	33	123	33	84	33	95	33
K187	200	200	200	200	143	53	200	53	143	53	152	53

Key:

M1/M2/M3/M4/M5/M6	= Mounting position of planetary gear unit
0°/90°/180°/270°	= Mounting position of bevel (KF/K) primary gear unit
A/B	= Position of the mounting flange at the primary bevel gear unit

## Helical (RF) primary gear units

## INFORMATION



- The lubricant fill quantity depends on the mounting position of the planetary gear unit and the mounting position of the RF primary gear unit.
- For information on the mounting positions of the RF.. primary gear unit, refer to chapter "RF.. primary helical gear units" (→ 40)
- The oil level of primary gear units is checked using the oil level plug.

The table below shows the lubricant fill quantities.

Size	Fill quantities in liters					
	M1	M2	M3	M4	M5	M6
	0°	0°	180°	→0°	270°	90°
RF77	1.2	3.10	3.30	3.60	2.40	3.00
RF87	2.4	6.4	7.1	7.2	6.3	6.4
RF97	5.1	11.9	11.2	14.0	11.2	11.8
RF107	6.3	15.9	17.0	19.2	13.1	15.9
RF127	6.6	18.3	18.2	21.4	15.9	17.0
RF137	9.5	27.0	29.0	32.5	25.0	25.0
RF147	16.4	47.0	48.0	52.0	42.0	42.0
RF167	26.0	82.0	78.0	88.0	65.0	71.0

Legend:

M1/M2/M3/M4/M5/M6	= Mounting position of planetary gear unit
0°/90°/180°/270°	= Mounting position of helical (RF) primary gear unit

## 8.6 Lubricant compatibility with oil seal

Approval	Explanation
SEW07004__13:	A lubricant especially recommended with regard to compatibility with the approved oil seals. The lubricant exceeds the state-of-the-art requirements regarding elastomer compatibility.

### Approved application temperature range of the oil seals

In the low temperature range, oil seals can withstand shaft deflections (e. g. through overhung load) only to a limited extent. Especially avoid or limit pulsating or changing radial displacements of the shaft. Contact SEW-EURODRIVE, if required.

Oil seal Material class	Permitted Oil sump temperature
NBR	-40 °C to +80 °C
FKM	-25 °C to +115 °C
FKM-PSS	-25 °C to +115 °C

**Limitations of use** of oil seals with the specific lubricant are described in the following table:

Material class			Manufacturer		Material	
S	1	NBR	1	Freudenberg		72 NBR 902
			2	Trelleborg		4NV11
	2	FKM	1	Freudenberg	1	75 FKM 585
					2	75 FKM 170055
			2	Trelleborg	1	VCBVR



### Examples:

**S11:** Only the elastomer 72NBR902 of the Freudenberg company meets the requirements of the approval in conjunction with the specific lubricant.

**S2:** Only the elastomer FKM meets the requirements of the approval in conjunction with the specific lubricant.

### 8.7 Sealing greases/bearing greases: Planetary gear unit

The table shows the grease types recommended by SEW-EURODRIVE for operating temperatures from the lower limit temperature to 100 °C.

Area of operation	Manufacturer	Grease	Lower limit temperature °C
Standard	Fuchs	<b>Renolit CX TOM 15 OEM<sup>1)</sup></b>	-40
	BP	Energrease LS EP-2	-30
	Castrol	Longtime PD 2	-35
		Spheerol EPL 2	-20
	Klüber	Centoplex EP 2	-25
		Petamo GHY 133 N	-40
	Mobil	Moliux EP 2	-20
	Shell	Gadus S2 V220 2	-20
	Total	Multis EP 2	-20
	Bremer & Leguil	Cassida Grease GTS2 <sup>1)</sup>	-40
	Fuchs	<b>Plantogel 2<sup>1)</sup></b>	-40

1) Grease used by the factory should be preferred.



### INFORMATION



- Do not mix permitted greases from different areas of application.
- If the lubricant used is not listed in the above table, you have to make sure that it is suitable for the intended application.

## 8.8 Sealing grease: RF../KF../K.. primary gear units and motors

The rolling bearings in RF../KF../K.. primary gear units and motors are given a factory-fill with the greases listed below. SEW-EURODRIVE recommends regreasing rolling bearings with a grease fill at the same time as changing the oil. Observe the separate operating instructions for RF../KF../K.. primary gear units and motors.

	Ambient temperature	Manufacturer	Type
Gear unit rolling bearings	-40°C to +80°C	Fuchs	Renolit CX-TOM 15 <sup>1)</sup>
	-40 °C to +80 °C	Klüber	Petamo GHY 133 N
	-40 °C to +40 °C	Bremer & Leguil	Cassida Grease GTS 2
	-20 °C to +40 °C	Fuchs	Plantogel 2S

1) Bearing grease based on semi-synthetic base oil

### INFORMATION



The following grease quantities are required:

- **For fast-running bearings (gear unit input side):** Fill the cavities between the rolling elements one-third full with grease.
- **For slow-running bearings (gear unit output side):** Fill the cavities between the rolling elements two-thirds full with grease.

## 9 Malfunctions/remedy

### 9.1 Troubleshooting information

Read the following notes before you proceed with troubleshooting.



#### **⚠ WARNING**

Risk of crushing if the drive starts up unintentionally.

Severe or fatal injuries.

- Work on the gear unit only when the machine is not in use. Secure the drive unit against unintentional power-up. Attach an information sign near the ON switch to warn that the gear unit is being worked on.



#### **⚠ WARNING**

Risk of burns due to hot gear unit and hot gear unit oil.

Serious injury.

- Let the gear unit cool down before you start working on it.
- Remove the oil drain plug very carefully.

#### **NOTICE**

Improper handling of the gear unit and the motor may lead to damage.

Possible damage to property.

- Only qualified personnel are permitted to separate drive and motor and to carry out repair work on SEW drives.
- Contact SEW-EURODRIVE.

### 9.2 Service

**Please have the following information available if you require customer service assistance:**

- Complete nameplate data
- Type and extent of the malfunction
- Time the problem occurred and any accompanying circumstances
- Assumed cause
- If possible video and audio recordings

### 9.3 Malfunctions of P.. planetary gear units

Fault	Possible cause	Measure
Unusual, regular running noise	<ul style="list-style-type: none"> <li>Meshing/grinding noise: Bearing damage</li> <li>Knocking noise: Irregularity in the gearing</li> <li>Deformation of the housing upon tightening</li> <li>Noise generation caused by insufficient rigidity of the gear unit foundation</li> </ul>	<ul style="list-style-type: none"> <li>Check the oil consistency; change bearings</li> <li>Contact SEW-EURODRIVE. For a better assessment of the failure, send an audio recording of the noise</li> <li>Check the gear unit mounting for possible deformation and correct if necessary</li> <li>Reinforce the gear unit foundation</li> </ul>
Unusual, irregular running noises	<ul style="list-style-type: none"> <li>Foreign objects in the oil</li> </ul>	<ul style="list-style-type: none"> <li>Check the oil consistency</li> <li>Stop the drive, contact SEW-EURODRIVE</li> </ul>
Unusual noise in the area where the gear unit is mounted	<ul style="list-style-type: none"> <li>Gear unit mounting has loosened</li> </ul>	<ul style="list-style-type: none"> <li>Tighten retaining screws and nuts to the specified torque</li> <li>Replace the damaged/defective retaining screws or nuts</li> </ul>
Operating temperature too high	<ul style="list-style-type: none"> <li>Too much oil</li> <li>Oil too old</li> <li>The oil is heavily contaminated</li> <li>Ambient temperature too high</li> </ul>	<ul style="list-style-type: none"> <li>Check oil level, correct if necessary</li> <li>Check when the oil was last changed; change the oil, if necessary</li> <li>Analyze the oil to determine the cause; take measures, if necessary; change the oil</li> <li>Protect the gear unit from external heat sources (e.g. provide shade)</li> </ul>
Temperature at bearing points too high	<ul style="list-style-type: none"> <li>Not enough oil</li> <li>Oil too old</li> <li>Bearing damaged</li> </ul>	<ul style="list-style-type: none"> <li>Check oil level; correct if necessary</li> <li>Check when the oil was last changed; change the oil if necessary</li> <li>Check the bearing and replace it if necessary. Contact SEW-EURODRIVE</li> </ul>
Oil leaking <ul style="list-style-type: none"> <li>At the gear unit breather</li> </ul>	<ul style="list-style-type: none"> <li>Too much oil</li> <li>Drive not installed in proper mounting position</li> <li>Frequent cold starts (oil foaming) and/or high oil level</li> </ul>	<ul style="list-style-type: none"> <li>Check oil level, correct if necessary</li> <li>Install gear unit breather correctly and adjust the oil level</li> <li>Install oil expansion tank</li> </ul>
Oil leaking <ul style="list-style-type: none"> <li>From the screw plug</li> <li>From the oil drain valve</li> </ul>	<ul style="list-style-type: none"> <li>Seal not tight</li> <li>Fittings loosened</li> </ul>	<ul style="list-style-type: none"> <li>Retighten the screw</li> <li>Retighten the fitting and screw</li> </ul>

Fault	Possible cause	Measure
Oil leaking <sup>1)</sup> • From oil seal	<ul style="list-style-type: none"> <li>• Too much oil</li> <li>• Venting sealed</li> <li>• Oil seal damaged/worn</li> </ul>	<ul style="list-style-type: none"> <li>• Check the oil level; correct if necessary</li> <li>• Check the breather and replace if necessary</li> <li>• Check oil seals; replace if necessary</li> </ul>

1) During the run-in phase (24-hour runtime), it is normal for (small amounts of) oil/grease to leak from the oil seal (see also DIN 3761).

#### 9.4 Malfunctions of primary RF../KF../K.. primary gear units

Fault	Possible cause	Measure
Unusual, regular running noise	<ul style="list-style-type: none"> <li>• Meshing/grinding noise: Bearing damage</li> <li>• Knocking noise: Irregularity in the gearing</li> <li>• Deformation of the housing upon tightening</li> <li>• Noise generation caused by insufficient rigidity of the gear unit foundation</li> </ul>	<ul style="list-style-type: none"> <li>• Check the oil consistency; change bearings</li> <li>• Contact SEW-EURODRIVE. For a better assessment of the failure, send an audio recording of the noise</li> <li>• Check the gear unit mounting for possible deformation and correct if necessary</li> <li>• Reinforce the gear unit foundation</li> </ul>
Unusual, irregular running noises	<ul style="list-style-type: none"> <li>• Foreign objects in the oil</li> </ul>	<ul style="list-style-type: none"> <li>• Check the oil consistency</li> <li>• Stop the drive, contact SEW-EURODRIVE</li> </ul>
Oil leaking • From cover plate • From inspection cover • From bearing cover • From mounting flange	<ul style="list-style-type: none"> <li>• Seal not tight at: <ul style="list-style-type: none"> <li>– Cover plate</li> <li>– Inspection cover</li> <li>– Bearing cover</li> <li>– Mounting flange</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Tighten the bolts on the respective cover. Observe the gear unit. Contact SEW-EURODRIVE if oil is still leaking</li> </ul>
Oil leaking • At the gear unit breather	<ul style="list-style-type: none"> <li>• Too much oil</li> <li>• Drive not installed in proper mounting position</li> <li>• Frequent cold starts (oil foaming) and/or high oil level</li> </ul>	<ul style="list-style-type: none"> <li>• Check oil level, correct if necessary</li> <li>• Install gear unit breather correctly and adjust the oil level</li> <li>• Install oil expansion tank</li> </ul>
Oil leaking <sup>1)</sup> • From oil seal	<ul style="list-style-type: none"> <li>• Too much oil</li> <li>• Venting sealed</li> <li>• Oil seal damaged/worn</li> </ul>	<ul style="list-style-type: none"> <li>• Check the oil level; correct if necessary</li> <li>• Check the breather and replace if necessary</li> <li>• Check oil seals; replace if necessary</li> </ul>
Output shaft does not turn although the motor is running or the input shaft is rotated	<ul style="list-style-type: none"> <li>• Shaft-hub connection in the gear unit interrupted</li> </ul>	<ul style="list-style-type: none"> <li>• Send in the gear unit/gearmotor for repair</li> </ul>



Fault	Possible cause	Measure
Operating temperature at backstop too high, no blocking function	<ul style="list-style-type: none"> <li>Damaged/defective backstop</li> </ul>	<ul style="list-style-type: none"> <li>Check the backstop, replace it if necessary</li> <li>Contact SEW-EURODRIVE</li> </ul>

1) During the run-in phase (24-hour runtime), it is normal for (small amounts of) oil/grease to leak from the oil seal (see also DIN 3761).

## 9.5 Malfunctions of AMS/AQS adapters

Fault	Possible cause	Measure
Unusual, regular running noise	<ul style="list-style-type: none"> <li>Meshing/grinding noise: Bearing damage</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
Oil leaking	<ul style="list-style-type: none"> <li>Seal defective</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
Output shaft does not turn although the motor is running or the input shaft is rotated	<ul style="list-style-type: none"> <li>Shaft-hub connection in the gear unit interrupted</li> </ul>	<ul style="list-style-type: none"> <li>Send in the gear unit/gearmotor for repair</li> </ul>
Change in running noise and/or vibrations	<ul style="list-style-type: none"> <li>Coupling ring wear, short-term torque transmission due to metal contact</li> </ul>	<ul style="list-style-type: none"> <li>Replace coupling ring.</li> </ul>
	<ul style="list-style-type: none"> <li>Screws to secure hub axially are loose</li> </ul>	<ul style="list-style-type: none"> <li>Tighten the screws</li> </ul>
Premature coupling ring wear	<ul style="list-style-type: none"> <li>Contact with aggressive fluids/oils; ozone influence; excessive ambient temperatures, etc. that can change the physical properties of the coupling ring.</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
	<ul style="list-style-type: none"> <li>Impermissibly high coupling ring ambient/contact temperatures; max. permissible: -20 °C to +80 °C.</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
	<ul style="list-style-type: none"> <li>Overload</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>

## 9.6 Malfunctions of AD input shaft assembly

Fault	Possible cause	Measure
Unusual, regular running noise	<ul style="list-style-type: none"> <li>Meshing/grinding noise: Bearing damage</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
Oil leaking	<ul style="list-style-type: none"> <li>Seal defective</li> </ul>	<ul style="list-style-type: none"> <li>Contact SEW-EURODRIVE</li> </ul>
Output shaft does not turn although the motor is running or the input shaft is rotated	<ul style="list-style-type: none"> <li>Shaft-hub connection in the gear unit interrupted</li> </ul>	<ul style="list-style-type: none"> <li>Send in the gear unit/gearmotor for repair</li> </ul>

## 9.7 Motor malfunctions

Fault	Possible cause	Measure
Motor does not start up	Supply cable interrupted	Check connections, correct if necessary
	Brake does not release	See chapter "Brake malfunctions"
	Fuse blown	Replace fuse
	Motor protection tripped	Check motor protection for correct setting, correct fault if necessary
	Motor protection does not switch, error in control	Check motor protection control, correct error if necessary
Motor only starts with difficulty or does not start at all	Motor designed for delta connection but used in star connection	Correct the connection
	Voltage or frequency differs considerably from the setpoint, at least when switching on the motor	Provide better power supply system; check cross section of supply cable
Motor does not start in star connection, only in delta connection	Star connection does not provide sufficient torque	Switch on directly if delta inrush current is not too great; else, use a larger motor or a special design. Contact SEW-EURODRIVE.
	Contact fault on star/delta switch	Rectify fault
Incorrect direction of rotation	Motor connected incorrectly	Swap two phases
Motor hums and has high current consumption	Brake does not release	See chapter "Brake malfunctions"
	Winding defective	Send motor to specialist workshop for repair
	Rotor rubbing	
Fuses blow or motor protection trips immediately	Short circuit in the line	Eliminate short circuit
	Short circuit in the motor	Send motor to specialist workshop for repair
	Cables connected incorrectly	Correct the connection
	Ground fault on motor	Send motor to specialist workshop for repair
Severe speed loss under load	Overload	Measure the power, use larger motor or reduce load if necessary
	Voltage drops	Increase cross section of incoming cable

Fault	Possible cause	Measure
Motor heats up excessively (measure temperature)	Overload	Measure the power, use larger motor or reduce load if necessary
	Insufficient cooling	Correct cooling air supply or clear cooling air passages, retrofit forced cooling fan if necessary
	Ambient temperature too high	Observe permitted temperature range
	Motor in delta connection instead of star connection as intended	Correct the connection
	Loose contact in incoming cable (one phase missing)	Tighten loose contact
	Fuse blown	Look for and rectify cause (see above); replace fuse
	The line voltage deviates from the rated motor voltage by more than 5%. A higher voltage has a particularly unfavorable effect in motors with a great number of poles since in these, the no-load current is already close to the rated current even when the voltage is normal.	Adjust motor to line voltage
Excessively loud	Nominal duty cycle (S1 to S10, DIN 57530) exceeded, e.g. caused by excessive starting frequency	Adjust the nominal duty cycle of the motor to the required operating conditions; consult a professional to determine the proper drive, if necessary
	Ball bearing compressed, dirty or damaged	Re-align motor, inspect ball bearing (→ chapter "Permitted ball bearing types"), grease if necessary (→ chapter "Lubricant table for rolling bearings of SEW motors"), replace
	Vibration of rotating parts	Rectify cause, possible imbalance
	Foreign objects in cooling air ducts	Clean cooling air ducts

## 9.8 Brake malfunctions

Fault	Possible cause	Measure
Brake does not release	Incorrect voltage on brake control unit	Apply correct voltage
	Brake control unit failed	Install a new brake control system, check internal resistance and insulation of brake coil, check switchgear
	Max. permitted working air gap exceeded because brake lining worn down	Measure and set working air gap
	Voltage drop along supply cable > 10%	Ensure correct connection voltage; check cable cross section
	Inadequate cooling, brake overheats	Replace type BG brake rectifier with type BGE
	Brake coil has interturn short circuit or a short circuit to frame	Replace complete brake and brake control system (specialist workshop), check switchgear
	Rectifier defective	Replace the rectifier and brake coil
Motor does not brake	Working air gap not correct	Measure and set working air gap
	Brake lining worn	Replace entire brake disk
	Incorrect braking torque	Change the braking torque (→ chapter "Technical data") <ul style="list-style-type: none"> <li>by changing the type and number of brake springs</li> <li>BG 05 brake: by installing the same brake coil body design as in the BMG 1 brake</li> <li>BG 2 brake: by installing the same brake coil body design as in the BMG 4 brake</li> </ul>
	BM(G) only: Working air gap so large that setting nuts come into contact	Set the working air gap
	BR03, BM(G) only: Manual brake release device not set correctly	Set the setting nuts correctly
Brake is applied with time lag	Brake is switched on AC voltage side	Switch on DC and AC voltage sides (e.g. BSR); observe wiring diagram
Noise in vicinity of brake	Gearing wear caused by jolting start-up	Check project planning
	Alternating torques due to incorrectly set frequency inverter	Check/correct setting of frequency inverter according to operating instructions

## 9.9 Disposal

Dispose gear units in accordance with the regulations in force regarding respective materials:

- Steel scrap
  - Housing parts
  - Gears
  - Shafts
  - Rolling bearing
- Collect used oil and dispose of it according to the regulations in force.

Dispose of the motors in accordance with the material structure and the regulations in force:

- Iron
- Aluminum
- Copper
- Plastics
- Electronic parts
- Oil and grease (not mixed with solvents)

## 10 Address list

Argentina			
Assembly Sales	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Ruta Panamericana Km 37.5, Lote 35 (B1619IEA) Centro Industrial Garín Prov. de Buenos Aires	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 <a href="http://www.sew-eurodrive.com.ar">http://www.sew-eurodrive.com.ar</a> <a href="mailto:sewar@sew-eurodrive.com.ar">sewar@sew-eurodrive.com.ar</a>
Australia			
Assembly Sales Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 <a href="http://www.sew-eurodrive.com.au">http://www.sew-eurodrive.com.au</a> <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 <a href="mailto:enquires@sew-eurodrive.com.au">enquires@sew-eurodrive.com.au</a>
Austria			
Assembly Sales Service	Vienna	SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Straße 24 1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 <a href="http://www.sew-eurodrive.at">http://www.sew-eurodrive.at</a> <a href="mailto:sew@sew-eurodrive.at">sew@sew-eurodrive.at</a>
Bangladesh			
Sales	Bangladesh	SEW-EURODRIVE INDIA PRIVATE LIMITED 345 DIT Road East Rampura Dhaka-1219, Bangladesh	Tel. +88 01729 097309 <a href="mailto:salesdhaka@seweurodrivebangladesh.com">salesdhaka@seweurodrivebangladesh.com</a>
Belarus			
Sales	Minsk	Foreign unitary production enterprise SEW- EURODRIVE Novodvorskiy village council 145 223016, Minsk region	Tel. +375 17 319 47 56 / +375 17 378 47 58 Fax +375 17 378 47 54 <a href="http://www.sew-eurodrive.by">http://www.sew-eurodrive.by</a> <a href="mailto:sew@sew-eurodrive.by">sew@sew-eurodrive.by</a>
Belgium			
Assembly Sales Service	Brussels	SEW-EURODRIVE n.v./s.a. Researchpark Haasrode 1060 Evenementenlaan 7 3001 Leuven	Tel. +32 16 386-311 Fax +32 16 386-336 <a href="http://www.sew-eurodrive.be">http://www.sew-eurodrive.be</a> <a href="mailto:info@sew-eurodrive.be">info@sew-eurodrive.be</a>
Service Competence Center	Industrial Gears	SEW-EURODRIVE n.v./s.a. Rue du Parc Industriel, 31 6900 Marche-en-Famenne	Tel. +32 84 219-878 Fax +32 84 219-879 <a href="http://www.sew-eurodrive.be">http://www.sew-eurodrive.be</a> <a href="mailto:info@sew.be">info@sew.be</a>
Brazil			
Production Sales Service	São Paulo	SEW-EURODRIVE Brasil Ltda. Estrada Municipal José Rubim, 205 – Rodovia Santos Dumont Km 49 Indaiatuba – 13347-510 – SP	Tel. +55 19 3835-8000 <a href="mailto:sew@sew.com.br">sew@sew.com.br</a>
Assembly Sales Service	Rio Claro	SEW-EURODRIVE Brasil Ltda. Rodovia Washington Luiz, Km 172 Condomínio Industrial Conpark Caixa Postal: 327 13501-600 – Rio Claro / SP	Tel. +55 19 3522-3100 Fax +55 19 3524-6653 <a href="mailto:montadora.rc@sew.com.br">montadora.rc@sew.com.br</a>
	Joinville	SEW-EURODRIVE Brasil Ltda. Jvl / Ind Rua Dona Francisca, 12.346 – Pirabeiraba 89239-270 – Joinville / SC	Tel. +55 47 3027-6886 Fax +55 47 3027-6888 <a href="mailto:filial.sc@sew.com.br">filial.sc@sew.com.br</a>
Bulgaria			
Sales	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 <a href="mailto:bever@bever.bg">bever@bever.bg</a>

**Cameroon**

Sales	Douala	SEW-EURODRIVE SARLU Ancienne Route Bonabéri P.O. Box B.P 8674 Douala-Cameroun	Tel. +237 233 39 12 35 Fax +237 233 39 02 10 <a href="http://www.sew-eurodrive.ci/">www.sew-eurodrive.ci/</a> <a href="mailto:info@sew-eurodrive.cm">info@sew-eurodrive.cm</a>
-------	--------	---	---

**Canada**

Assembly Sales Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, ON L6T 3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 <a href="http://www.sew-eurodrive.ca">http://www.sew-eurodrive.ca</a> <a href="mailto:l.watson@sew-eurodrive.ca">l.watson@sew-eurodrive.ca</a>
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. Tilbury Industrial Park 7188 Honeyman Street Delta, BC V4G 1G1	Tel. +1 604 946-5535 Fax +1 604 946-2513 <a href="mailto:b.wake@sew-eurodrive.ca">b.wake@sew-eurodrive.ca</a>
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2001 Ch. de l'Aviation Dorval Quebec H9P 2X6	Tel. +1 514 367-1124 Fax +1 514 367-3677 <a href="mailto:n.paradis@sew-eurodrive.ca">n.paradis@sew-eurodrive.ca</a>

**Chile**

Assembly Sales Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA Las Encinas 1295 Parque Industrial Valle Grande LAMP Santiago de Chile P.O. Box Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 2757 7000 Fax +56 2 2757 7001 <a href="http://www.sew-eurodrive.cl">http://www.sew-eurodrive.cl</a> <a href="mailto:ventas@sew-eurodrive.cl">ventas@sew-eurodrive.cl</a>
------------------------------	-------------------	---	--

**China**

Production Assembly Sales Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 78, 13th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25323273 <a href="http://www.sew-eurodrive.cn">http://www.sew-eurodrive.cn</a> <a href="mailto:info@sew-eurodrive.cn">info@sew-eurodrive.cn</a>
Assembly Sales Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021	Tel. +86 512 62581781 Fax +86 512 62581783 <a href="mailto:suzhou@sew-eurodrive.cn">suzhou@sew-eurodrive.cn</a>
	Guangzhou	SEW-EURODRIVE (Guangzhou) Co., Ltd. No. 9, JunDa Road East Section of GETDD Guangzhou 510530	Tel. +86 20 82267890 Fax +86 20 82267922 <a href="mailto:guangzhou@sew-eurodrive.cn">guangzhou@sew-eurodrive.cn</a>
	Shenyang	SEW-EURODRIVE (Shenyang) Co., Ltd. 10A-2, 6th Road Shenyang Economic Technological Development Area Shenyang, 110141	Tel. +86 24 25382538 Fax +86 24 25382580 <a href="mailto:shenyang@sew-eurodrive.cn">shenyang@sew-eurodrive.cn</a>
	Taiyuan	SEW-EURODRIVE (Taiyuan) Co., Ltd. No.3, HuaZhang Street, TaiYuan Economic & Technical Development Zone ShanXi, 030032	Tel. +86-351-7117520 Fax +86-351-7117522 <a href="mailto:taiyuan@sew-eurodrive.cn">taiyuan@sew-eurodrive.cn</a>
	Wuhan	SEW-EURODRIVE (Wuhan) Co., Ltd. 10A-2, 6th Road No. 59, the 4th Quanli Road, WEDA 430056 Wuhan	Tel. +86 27 84478388 Fax +86 27 84478389 <a href="mailto:wuhan@sew-eurodrive.cn">wuhan@sew-eurodrive.cn</a>
	Xi'An	SEW-EURODRIVE (Xi'An) Co., Ltd. No. 12 Jinye 2nd Road Xi'An High-Technology Industrial Development Zone Xi'An 710065	Tel. +86 29 68686262 Fax +86 29 68686311 <a href="mailto:xian@sew-eurodrive.cn">xian@sew-eurodrive.cn</a>
Sales Service	Hong Kong	SEW-EURODRIVE LTD. Unit No. 801-806, 8th Floor Hong Leong Industrial Complex No. 4, Wang Kwong Road Kowloon, Hong Kong	Tel. +852 36902200 Fax +852 36902211 <a href="mailto:contact@sew-eurodrive.hk">contact@sew-eurodrive.hk</a>

<b>Colombia</b>			
Assembly Sales Service	Bogota	SEW-EURODRIVE COLOMBIA LTDA. Calle 17 No. 132-18 Interior 2 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 <a href="http://www.sew-eurodrive.com.co">http://www.sew-eurodrive.com.co</a> <a href="mailto:sew@sew-eurodrive.com.co">sew@sew-eurodrive.com.co</a>
<b>Croatia</b>			
Sales Service	Zagreb	KOMPEKS d. o. o. Zeleni dol 10 10 000 Zagreb	Tel. +385 1 4613-158 Fax +385 1 4613-158 <a href="mailto:kompeks@inet.hr">kompeks@inet.hr</a>
<b>Czech Republic</b>			
Assembly Sales Service	Hostivice	SEW-EURODRIVE CZ s.r.o. Floriánova 2459 253 01 Hostivice	Tel. +420 255 709 601 Fax +420 235 350 613 <a href="http://www.sew-eurodrive.cz">http://www.sew-eurodrive.cz</a> <a href="mailto:sew@sew-eurodrive.cz">sew@sew-eurodrive.cz</a>
<b>Denmark</b>			
Assembly Sales Service	Copenhagen	SEW-EURODRIVE A/S Geminivej 28-30 2670 Greve	Tel. +45 43 95 8500 Fax +45 43 9585-09 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> <a href="mailto:sew@sew-eurodrive.dk">sew@sew-eurodrive.dk</a>
Service	Vejle	SEW-EURODRIVE A/S Bødkervej 2 7100 Vejle	Tel. +45 43 9585 00 <a href="http://www.sew-eurodrive.dk">http://www.sew-eurodrive.dk</a> <a href="mailto:sew@sew-eurodrive.dk">sew@sew-eurodrive.dk</a>
<b>Egypt</b>			
Representation: United Arab Emirates			
<b>Estonia</b>			
Sales	Tallin	ALAS-KUUL AS Loomäe tee 1, Lehmja küla 75306 Rae vald Harjumaa	Tel. +372 6593230 Fax +372 6593231 <a href="http://www.alas-kuul.ee">http://www.alas-kuul.ee</a> <a href="mailto:info@alas-kuul.ee">info@alas-kuul.ee</a>
<b>Finland</b>			
Assembly Sales Service	Hollola	SEW-EURODRIVE OY Vesimäentie 4 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> <a href="mailto:sew@sew.fi">sew@sew.fi</a>
Service	Hollola	SEW-EURODRIVE OY Keskikankaantie 21 15860 Hollola	Tel. +358 201 589-300 Fax +358 3 780-6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> <a href="mailto:sew@sew.fi">sew@sew.fi</a>
	Tornio	SEW-EURODRIVE Oy Lossirannankatu 5 95420 Tornio	Tel. +358 201 589 300 Fax +358 3 780 6211 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> <a href="mailto:sew@sew.fi">sew@sew.fi</a>
Production Assembly	Karkkila	SEW Industrial Gears Oy Santasalonkatu 6, PL 8 03620 Karkkila, 03601 Karkkila	Tel. +358 201 589-300 Fax +358 201 589-310 <a href="http://www.sew-eurodrive.fi">http://www.sew-eurodrive.fi</a> <a href="mailto:sew@sew.fi">sew@sew.fi</a>
<b>France</b>			
Production Sales	Haguenau	SEW USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 <a href="http://www.usocome.com">http://www.usocome.com</a> <a href="mailto:sew@usocome.com">sew@usocome.com</a>
Production	Forbach	SEW USOCOME Zone industrielle Technopôle Forbach Sud B. P. 30269 57604 Forbach Cedex	Tel. +33 3 87 29 38 00
	Brumath	SEW USOCOME 1 Rue de Bruxelles 67670 Mommenheim Cedex	Tel. +33 3 88 37 48 00



**France**

Assembly Sales Service	Bordeaux	SEW USOCOME Parc d'activités de Magellan 62 avenue de Magellan – B. P. 182 33607 Pessac Cedex	Tel. +33 5 57 26 39 00 dtcbordeaux@usocom.com
	Haguenau	SEW USOCOME 48-54 route de Soufflenheim B. P. 20185 67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 dtchaguenau@usocom.com
	Lyon	SEW USOCOME 75 rue Antoine Condorcet 38090 Vaulx-Milieu	Tel. +33 4 74 99 60 00 dtclyon@usocom.com
	Nantes	SEW USOCOME Parc d'activités de la forêt 4 rue des Fontenelles 44140 Le Bignon	Tel. +33 2 40 78 42 00 dtcnantes@usocom.com
	Paris	SEW USOCOME Zone industrielle 2 rue Denis Papin 77390 Verneuil l'Étang	Tel. +33 1 64 42 40 80 dtcparis@usocom.com

**Gabon**

Representation: Cameroon

**Germany**

Headquarters Production Sales	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Production / Industrial Gears	Bruchsal	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Str. 10 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-2970
Production / Precision Gear Units	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 sew@sew-eurodrive.de
Production	Graben	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf	Tel. +49 7251 75-0 Fax +49 7251-2970
Service Competence Center	Mechanics / Mechatronics	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 scc-mechanik@sew-eurodrive.de
	Electronics	SEW-EURODRIVE GmbH & Co KG Christian-Pähr-Straße 12 76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 scc-elektronik@sew-eurodrive.de
	MAXOLU- TION® Factory Automation	SEW-EURODRIVE GmbH & Co KG Eisenbahnstraße 11 76646 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 sew@sew-eurodrive.de
Drive Technology Center	North	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 43 30823 Garbsen (Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 dtc-nord@sew-eurodrive.de
	East	SEW-EURODRIVE GmbH & Co KG Dänkritzer Weg 1 08393 Meerane (Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-20 dtc-ost@sew-eurodrive.de
	South	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 85551 Kirchheim (München)	Tel. +49 89 909551-21 Fax +49 89 909551-50 dtc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 40764 Langenfeld (Düsseldorf)	Tel. +49 2173 8507-10 Fax +49 2173 8507-50 dtc-west@sew-eurodrive.de
Drive Center	Berlin	SEW-EURODRIVE GmbH & Co KG Melitta-Schiller-Straße 8 12526 Berlin	Tel. +49 306331131-30 Fax +49 306331131-36 dc-berlin@sew-eurodrive.de
	Bremen	SEW-EURODRIVE GmbH & Co KG Allerkai 4 28309 Bremen	Tel. +49 421 33918-10 Fax +49 421 33918-22 tb-bremen@sew-eurodrive.de

Germany			
	Hamburg	SEW-EURODRIVE GmbH & Co KG Hasselbinnen 11 22869 Schenefeld	Tel. +49 40298109-60 Fax +49 40298109-70 dc-hamburg@sew-eurodrive.de
	Saarland	SEW-EURODRIVE GmbH & Co KG Gottlieb-Daimler-Straße 4 66773 Schwalbach Saar – Hülzweiler	Tel. +49 6831 48946 10 Fax +49 6831 48946 13 dc-saarland@sew-eurodrive.de
	Ulm	SEW-EURODRIVE GmbH & Co KG Dieselstraße 18 89160 Dornstadt	Tel. +49 7348 9885-0 Fax +49 7348 9885-90 dc-ulm@sew-eurodrive.de
	Würzburg	SEW-EURODRIVE GmbH & Co KG Nürnbergerstraße 118 97076 Würzburg-Lengfeld	Tel. +49 931 27886-60 Fax +49 931 27886-66 dc-wuerzburg@sew-eurodrive.de
Drive Service Hotline / 24 Hour Service			0 800 SEWHELP 0 800 7394357
Great Britain			
Assembly Sales Service	Normanton	SEW-EURODRIVE Ltd. DeVilliers Way Trident Park Normanton West Yorkshire WF6 1GX	Tel. +44 1924 893-855 Fax +44 1924 893-702 <a href="http://www.sew-eurodrive.co.uk">http://www.sew-eurodrive.co.uk</a> info@sew-eurodrive.co.uk
Greece			
Sales	Athens	Christ. Boznos & Son S.A. 12, K. Mavromichali Street P.O. Box 80136 18545 Piraeus	Tel. +30 2 1042 251-34 Fax +30 2 1042 251-59 <a href="http://www.boznos.gr">http://www.boznos.gr</a> info@boznos.gr
Hungary			
Sales Service	Budapest	SEW-EURODRIVE Kft. Csillaghegyi út 13. 1037 Budapest	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 <a href="http://www.sew-eurodrive.hu">http://www.sew-eurodrive.hu</a> office@sew-eurodrive.hu
Iceland			
Sales	Reykjavik	Varma & Vélaverk ehf. Knarrarvogi 4 104 Reykjavik	Tel. +354 585 1070 Fax +354 585)1071 <a href="https://vov.is/">https://vov.is/</a> vov@vov.is
India			
Registered Office Assembly Sales Service	Vadodara	SEW-EURODRIVE India Private Limited 302, NOTUS IT PARK, Sarabhai Campus, Beside Notus Pride, Genda Circle, Vadodara 390023 Gujarat	Tel. +91 265 3045200 Fax +91 265 3045300 <a href="https://www.seweurodriveindia.com">https://www.seweurodriveindia.com</a> salesvadodara@seweurodriveindia.com
Assembly Sales Service	Chennai	SEW-EURODRIVE India Private Limited Plot No. K3/1, Sipcot Industrial Park Phase II Mambakkam Village Sriperumbudur - 602105 Kancheepuram Dist, Tamil Nadu	Tel. +91 44 37188888 Fax +91 44 37188811 saleschennai@seweurodriveindia.com
	Pune	SEW-EURODRIVE India Private Limited Plant: Plot No. D236/1, Chakan Industrial Area Phase- II, Warale, Tal- Khed, Pune-410501, Maharashtra	Tel. +91 21 35 628700 Fax +91 21 35 628715 salespune@seweurodriveindia.com
	Tapukara	SEW-EURODRIVE India Private Limited Plot No SP-6-46, Tapukara, Karoli Industrial Area, No. 1, district : Alwar , Rajasthan - 301707	Tel. +91 265 3045200 Fax +91 265 3045300 tapukara.plant@seweurodriveindia.com
Sales Service	Gurgaon	SEW-EURODRIVE India Private Limited Drive Center Gurugram Plot no 395, Phase-IV, UdyogVihar Gurugram , 122016 Haryana	Tel. +91 99588 78855 salesgurgaon@seweurodriveindia.com

Indonesia			
Sales	Medan	PT. Serumpun Indah Lestari Jl. Pulau Solor no. 8, Kawasan Industri Medan II Medan 20252	Tel. +62 61 687 1221 Fax +62 61 6871429 / +62 61 6871458 / +62 61 30008041 sil@serumpunindah.com serumpunindah@yahoo.com http://www.serumpunindah.com
	Jakarta	PT. Cahaya Sukses Abadi Komplek Rukan Puri Mutiara Blok A no 99, Sunter Jakarta 14350	Tel. +62 21 65310599 Fax +62 21 65310600 csajkt@cbn.net.id
	Jakarta	PT. Agrindo Putra Lestari Jl. Pantai Indah Selatan, Komplek Sentra Industri Terpadu, Pantai indah Kapuk Tahap III, Blok E No. 27 Jakarta 14470	Tel. +62 21 2921-8899 Fax +62 21 2921-8988 aplindo@indosat.net.id http://www.aplindo.com
	Surabaya	PT. TRIAGRI JAYA ABADI Jl. Sukosemolo No. 63, Galaxi Bumi Permai G6 No. 11 Surabaya 60111	Tel. +62 31 5990128 Fax +62 31 5962666 sales@triagri.co.id http://www.triagri.co.id
	Surabaya	CV. Multi Mas Jl. Raden Saleh 43A Kav. 18 Surabaya 60174	Tel. +62 31 5458589 Fax +62 31 5317220 sianhwa@sby.centrin.net.id http://www.cvmultimas.com
Ireland			
Sales Service	Dublin	Alperton Engineering Ltd. 48 Moyle Road Dublin Industrial Estate Glasnevin, Dublin 11	Tel. +353 1 830-6277 Fax +353 1 830-6458 http://www.alperton.ie info@alperton.ie
Israel			
Sales	Tel Aviv	Liraz Handasa Ltd. Ahofer Str 34B / 228 58858 Holon	Tel. +972 3 5599511 Fax +972 3 5599512 http://www.liraz-handasa.co.il office@liraz-handasa.co.il
Italy			
Assembly Sales Service	Milan	SEW-EURODRIVE S.a.s. di SEW S.r.l. & Co. Via Bernini, 12 20033 Solaro (Milano)	Tel. +39 02 96 980229 Fax +39 02 96 980 999 http://www.sew-eurodrive.it milano@sew-eurodrive.it
Ivory Coast			
Sales	Abidjan	SEW-EURODRIVE SARL Ivory Coast Rue des Pêcheurs, Zone 3 26 BP 916 Abidjan 26	Tel. +225 27 21 21 81 05 Fax +225 27 21 25 30 47 info@sew-eurodrive.ci http://www.sew-eurodrive.ci
Japan			
Assembly Sales Service	Iwata	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp
Kazakhstan			
Sales Service	Almaty	SEW-EURODRIVE LLP 291-291A, Tole bi street 050031, Almaty	Tel. +7 (727) 350 5156 Fax +7 (727) 350 5156 http://www.sew-eurodrive.com kazakhstan@sew-eurodrive.com
	Tashkent	Representative Office SEW-EURODRIVE Representative office in Uzbekistan 95A Amir Temur ave, office 401/3 100084 Tashkent	Tel. +998 97 134 01 99 http://www.sew-eurodrive.uz sew@sew-eurodrive.uz
	Ulaanbaatar	IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN	Tel. +976-77109997 Fax +976-77109997 imt@imt.mn

Latvia			
Sales	Riga	SIA Alas-Kuul Katlakalna 11C 1073 Riga	Tel. +371 6 7139253 Fax +371 6 7139386 <a href="http://www.alas-kuul.lv">http://www.alas-kuul.lv</a> <a href="mailto:info@alas-kuul.com">info@alas-kuul.com</a>
Lebanon			
Sales (Lebanon)	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 510 532 Fax +961 1 494 971 <a href="mailto:ssacar@inco.com.lb">ssacar@inco.com.lb</a>
Sales (Jordan, Kuwait , Beirut Saudi Arabia, Syria)		Middle East Drives S.A.L. (offshore) Sin El Fil. B. P. 55-378 Beirut	Tel. +961 1 494 786 Fax +961 1 494 971 <a href="http://www.medrives.com">http://www.medrives.com</a> <a href="mailto:info@medrives.com">info@medrives.com</a>
Lithuania			
Sales	Alytus	UAB Irseva Statybininku 106C 63431 Alytus	Tel. +370 315 79204 Fax +370 315 56175 <a href="http://www.irseva.lt">http://www.irseva.lt</a> <a href="mailto:irmantas@irseva.lt">irmantas@irseva.lt</a>
Luxembourg			
Representation: Belgium			
Macedonia			
Sales	Skopje	Boznos DOOEL Dime Anicin 2A/7A 1000 Skopje	Tel. +389 23256553 Fax +389 23256554 <a href="http://www.boznos.mk">http://www.boznos.mk</a>
Malaysia			
Assembly Sales Service	Johor	SEW-EURODRIVE SDN BHD No. 95, Jalan Seroja 39, Taman Johor Jaya 81000 Johor Bahru, Johor West Malaysia	Tel. +60 7 3549409 Fax +60 7 3541404 <a href="mailto:sales@sew-eurodrive.com.my">sales@sew-eurodrive.com.my</a>
Mexico			
Assembly Sales Service	Quéretaro	SEW-EURODRIVE MEXICO S.A. de C.V. SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Quéretaro C.P. 76220 Querétaro, México	Tel. +52 442 1030-300 Fax +52 442 1030-301 <a href="http://www.sew-eurodrive.com.mx">http://www.sew-eurodrive.com.mx</a> <a href="mailto:scmexico@seweurodrive.com.mx">scmexico@seweurodrive.com.mx</a>
Sales Service	Puebla	SEW-EURODRIVE MEXICO S.A. de C.V. Calzada Zavaleta No. 3922 Piso 2 Local 6 Col. Santa Cruz Buenavista C.P. 72154 Puebla, México	Tel. +52 (222) 221 248 <a href="http://www.sew-eurodrive.com.mx">http://www.sew-eurodrive.com.mx</a> <a href="mailto:scmexico@seweurodrive.com.mx">scmexico@seweurodrive.com.mx</a>
Mongolia			
Technical Office	Ulaanbaatar	IM Trading LLC Olympic street 28B/3 Sukhbaatar district, Ulaanbaatar 14230, MN	Tel. +976-77109997 Tel. +976-99070395 Fax +976-77109997 <a href="http://imt.mn/">http://imt.mn/</a> <a href="mailto:imt@imt.mn">imt@imt.mn</a>
Morocco			
Sales Service Assembly	Bouskoura	SEW-EURODRIVE Morocco SARL Parc Industriel CFCIM, Lot. 55/59 27182 Bouskoura Grand Casablanca	Tel. +212 522 88 85 00 Fax +212 522 88 84 50 <a href="http://www.sew-eurodrive.ma">http://www.sew-eurodrive.ma</a> <a href="mailto:sew@sew-eurodrive.ma">sew@sew-eurodrive.ma</a>
Namibia			
Sales	Swakopmund	DB MINING & INDUSTRIAL SUPPLIES CC Einstein Street Strauss Industrial Park Unit1 Swakopmund	Tel. +264 64 462 738 Fax +264 64 462 734 <a href="mailto:anton@dbminingnam.com">anton@dbminingnam.com</a>

Netherlands			
Assembly Sales Service	Rotterdam	SEW-EURODRIVE B.V. Industrieweg 175 3044 AS Rotterdam Postbus 10085 3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 Service: 0800-SEWHELP <a href="http://www.sew-eurodrive.nl">http://www.sew-eurodrive.nl</a> <a href="mailto:info@sew-eurodrive.nl">info@sew-eurodrive.nl</a>
New Zealand			
Assembly Sales Service	Auckland	SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 <a href="http://www.sew-eurodrive.co.nz">http://www.sew-eurodrive.co.nz</a> <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 30 Lodestar Avenue, Wigram Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 <a href="mailto:sales@sew-eurodrive.co.nz">sales@sew-eurodrive.co.nz</a>
Nigeria			
Sales	Lagos	Greenpeg Nig. Ltd 64C Toyin Street Opebi-Allen Ikeja Lagos-Nigeria	Tel. +234-701-821-9200-1 <a href="http://www.greenpeg ltd.com">http://www.greenpeg ltd.com</a> <a href="mailto:sales@greenpeg ltd.com">sales@greenpeg ltd.com</a>
Norway			
Assembly Sales Service	Moss	SEW-EURODRIVE A/S Solgaard skog 71 1599 Moss	Tel. +47 69 24 10 20 Fax +47 69 24 10 40 <a href="http://www.sew-eurodrive.no">http://www.sew-eurodrive.no</a> <a href="mailto:sew@sew-eurodrive.no">sew@sew-eurodrive.no</a>
Pakistan			
Sales	Karachi	Industrial Power Drives Al-Fatah Chamber A/3, 1st Floor Central Com- mercial Area, Sultan Ahmed Shah Road, Block 7/8, Karachi	Tel. +92 21 452 9369 Fax +92-21-454 7365 <a href="mailto:seweurodrive@cyber.net.pk">seweurodrive@cyber.net.pk</a>
Paraguay			
Sales	Fernando de la Mora	SEW-EURODRIVE PARAGUAY S.R.L Nu Guazu No. 642 casi Campo Esperanza Santisima Trinidad Asuncion	Tel. +595 991 519695 Fax +595 21 3285539 <a href="mailto:sewpy@sew-eurodrive.com.py">sewpy@sew-eurodrive.com.py</a>
Peru			
Assembly Sales Service	Lima	SEW EURODRIVE DEL PERU S.A.C. Los Calderos, 120-124 Urbanizacion Industrial Vulcano, ATE, Lima	Tel. +51 1 3495280 Fax +51 1 3493002 <a href="http://www.sew-eurodrive.com.pe">http://www.sew-eurodrive.com.pe</a> <a href="mailto:sewperu@sew-eurodrive.com.pe">sewperu@sew-eurodrive.com.pe</a>
Philippines			
Sales	Makati	P.T. Cerna Corporation 4137 Ponte St., Brgy. Sta. Cruz Makati City 1205	Tel. +63 2 519 6214 Fax +63 2 890 2802 <a href="mailto:mech_drive_sys@ptcerna.com">mech_drive_sys@ptcerna.com</a> <a href="http://www.ptcerna.com">http://www.ptcerna.com</a>
Poland			
Assembly Sales Service	Łódź	SEW-EURODRIVE Polska Sp.z.o.o. ul. Techniczna 5 92-518 Łódź	Tel. +48 42 293 00 00 Fax +48 42 293 00 49 <a href="http://www.sew-eurodrive.pl">http://www.sew-eurodrive.pl</a> <a href="mailto:sew@sew-eurodrive.pl">sew@sew-eurodrive.pl</a>
	Service	Tel. +48 42 293 0030 Fax +48 42 293 0043	24 Hour Service Tel. +48 602 739 739 (+48 602 SEW SEW) <a href="mailto:serwis@sew-eurodrive.pl">serwis@sew-eurodrive.pl</a>
Portugal			
Assembly Sales Service	Coimbra	SEW-EURODRIVE, LDA. Av. da Fonte Nova, n.º 86 3050-379 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 <a href="http://www.sew-eurodrive.pt">http://www.sew-eurodrive.pt</a> <a href="mailto:infosew@sew-eurodrive.pt">infosew@sew-eurodrive.pt</a>

Romania			
Sales Service	Bucharest	Sialco Trading SRL str. Brazilia nr. 36 011783 Bucuresti	Tel. +40 21 230-1328 Fax +40 21 230-7170 <a href="http://www.sialco.ro">http://www.sialco.ro</a> <a href="mailto:sialco@sialco.ro">sialco@sialco.ro</a>
Russia			
Assembly Sales Service	St. Petersburg	SAO «СЕВ-ЕВРОДРАЙФ» 188660, Russia, Leningrad Region, Vse- volozhsky District, Korabselki, Aleksandra Nevskogo str. building 4, block 1 P.O. Box 36 195220 St. Petersburg	Tel. +7 812 3332522 / +7 812 5357142 Fax +7 812 3332523 <a href="http://www.sew-eurodrive.ru">http://www.sew-eurodrive.ru</a> <a href="mailto:sew@sew-eurodrive.ru">sew@sew-eurodrive.ru</a>
Senegal			
Sales	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 338 494 770 Fax +221 338 494 771 <a href="http://www.senemeca.com">http://www.senemeca.com</a> <a href="mailto:senemeca@senemeca.sn">senemeca@senemeca.sn</a>
Serbia			
Sales	Belgrade	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor 11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 <a href="mailto:office@dipar.rs">office@dipar.rs</a>
Singapore			
Assembly Sales Service	Singapore	SEW-EURODRIVE PTE. LTD. 9, Tuas Drive 2 Singapore 638644	Tel. +65 68621701 Fax +65 68612827 <a href="http://www.sew-eurodrive.com.sg">http://www.sew-eurodrive.com.sg</a> <a href="mailto:sewsingapore@sew-eurodrive.com">sewsingapore@sew-eurodrive.com</a>
Slovakia			
Sales	Bernolákovo	SEW-Eurodrive SK s.r.o. Priemyselná ulica 6267/7 900 27 Bernolákovo	Tel. +421 2 48 212 800 <a href="http://www.sew-eurodrive.sk">http://www.sew-eurodrive.sk</a> <a href="mailto:sew@sew-eurodrive.sk">sew@sew-eurodrive.sk</a>
Slovenia			
Sales Service	Celje	Pakman - Pogonska Tehnika d.o.o. Ul. XIV. divizije 14 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 <a href="mailto:pakman@siol.net">pakman@siol.net</a>
South Africa			
Assembly Sales Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED 32 O'Connor Place Eurodrive House Aeroton Johannesburg 2190 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 248-7289 <a href="http://www.sew.co.za">http://www.sew.co.za</a> <a href="mailto:info@sew.co.za">info@sew.co.za</a>
	Cape Town	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 <a href="mailto:bggriffiths@sew.co.za">bggriffiths@sew.co.za</a>
	Durban	SEW-EURODRIVE (PROPRIETARY) LIMITED 48 Prospecton Road Isipingo Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 902 3815 Fax +27 31 902 3826 <a href="mailto:cdejager@sew.co.za">cdejager@sew.co.za</a>
	Nelspruit	SEW-EURODRIVE (PROPRIETARY) LIMITED 7 Christie Crescent Vintonia P.O.Box 1942 Nelspruit 1200	Tel. +27 13 752-8007 Fax +27 13 752-8008 <a href="mailto:robermeyer@sew.co.za">robermeyer@sew.co.za</a>

South Korea			
Assembly Sales Service	Ansan	SEW-EURODRIVE Korea Co., Ltd. 7, Dangjaengi-ro, Danwon-gu, Ansan-si, Gyeonggi-do, Zip 425-839	Tel. +82 31 492-8051 Fax +82 31 492-8056 <a href="http://www.sew-eurodrive.kr">http://www.sew-eurodrive.kr</a> <a href="mailto:master.korea@sew-eurodrive.com">master.korea@sew-eurodrive.com</a>
	Busan	SEW-EURODRIVE Korea Co., Ltd. 28, Noksansandan 262-ro 50beon-gil, Gangseo-gu, Busan, Zip 618-820	Tel. +82 51 832-0204 Fax +82 51 832-0230
Assembly Service	Siheung	SEW-EURODRIVE Korea Co., Ltd. 35, Emtibeui 26-ro 58beon-gil, Siheung-si, Gyeonggi-do	<a href="http://www.sew-eurodrive.kr">http://www.sew-eurodrive.kr</a>
Spain			
Assembly Sales Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 <a href="http://www.sew-eurodrive.es">http://www.sew-eurodrive.es</a> <a href="mailto:sew.spain@sew-eurodrive.es">sew.spain@sew-eurodrive.es</a>
Sri Lanka			
Sales	Colombo	SM International (Pte) Ltd 254, Galle Raod Colombo 4, Sri Lanka	Tel. +94 1 2584887 Fax +94 1 2582981
Swaziland			
Sales	Manzini	C G Trading Co. (Pty) Ltd Simunye street Matsapha, Manzini	Tel. +268 7602 0790 Fax +268 2 518 5033 <a href="mailto:charles@cgtrading.co.sz">charles@cgtrading.co.sz</a> <a href="http://www.cgtradingswaziland.com">www.cgtradingswaziland.com</a>
Sweden			
Assembly Sales Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 553 03 Jönköping Box 3100 S-550 03 Jönköping	Tel. +46 36 34 42 00 Fax +46 36 34 42 80 <a href="http://www.sew-eurodrive.se">http://www.sew-eurodrive.se</a> <a href="mailto:jonkoping@sew.se">jonkoping@sew.se</a>
Switzerland			
Assembly Sales Service	Basel	Alfred Imhof A.G. Jurastrasse 10 4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 <a href="http://www.imhof-sew.ch">http://www.imhof-sew.ch</a> <a href="mailto:info@imhof-sew.ch">info@imhof-sew.ch</a>
Taiwan			
Sales	Taipei	Ting Shou Trading Co., Ltd. 6F-3, No. 267, Sec. 2 Tung Huw S. Road Taipei	Tel. +886 2 27383535 Fax +886 2 27368268 Telex 27 245 <a href="mailto:sewtwn@ms63.hinet.net">sewtwn@ms63.hinet.net</a> <a href="http://www.tingshou.com.tw">http://www.tingshou.com.tw</a>
	Nan Tou	Ting Shou Trading Co., Ltd. No. 55 Kung Yeh N. Road Industrial District Nan Tou 540	Tel. +886 49 255353 Fax +886 49 257878 <a href="mailto:sewtwn@ms63.hinet.net">sewtwn@ms63.hinet.net</a> <a href="http://www.tingshou.com.tw">http://www.tingshou.com.tw</a>
Tanzania			
Sales	Daressalam	SEW-EURODRIVE PTY LIMITED TANZANIA Plot 52, Regent Estate PO Box 106274 Dar Es Salaam	Tel. +255 0 22 277 5780 Fax +255 0 22 277 5788 <a href="http://www.sew-eurodrive.co.tz">http://www.sew-eurodrive.co.tz</a> <a href="mailto:info@sew.co.tz">info@sew.co.tz</a>
Thailand			
Assembly Sales Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 <a href="mailto:sewthailand@sew-eurodrive.com">sewthailand@sew-eurodrive.com</a>
Tunisia			
Sales	Tunis	T. M.S. Technic Marketing Service Zone Industrielle Mghira 2 Lot No. 39 2082 Fouchana	Tel. +216 79 40 88 77 Fax +216 79 40 88 66 <a href="http://www.tms.com.tn">http://www.tms.com.tn</a> <a href="mailto:tms@tms.com.tn">tms@tms.com.tn</a>



Turkey			
Assembly Sales Service	Kocaeli-Gebze	SEW-EURODRIVE Ana Merkez Gebze Organize Sanayi Böl. 400 Sok No. 401 41480 Gebze Kocaeli	Tel. +90 262 9991000 04 Fax +90 262 9991009 <a href="http://www.sew-eurodrive.com.tr">http://www.sew-eurodrive.com.tr</a> <a href="mailto:sew@sew-eurodrive.com.tr">sew@sew-eurodrive.com.tr</a>
Ukraine			
Assembly Sales Service	Dnipropetrovsk	SEW-EURODRIVE, LLC Robochya str., bld. 23-B, office 409 49008 Dnipro	Tel. +380 56 370 3211 Fax +380 56 372 2078 <a href="http://www.sew-eurodrive.ua">http://www.sew-eurodrive.ua</a> <a href="mailto:sew@sew-eurodrive.ua">sew@sew-eurodrive.ua</a>
United Arab Emirates			
Drive Technology Center	Dubai	SEW-EURODRIVE FZE PO Box 263835 Jebel Ali Free Zone – South, P.O. Box Dubai, United Arab Emirates	Tel. +971 (0)4 8806461 Fax +971 (0)4 8806464 <a href="mailto:info@sew-eurodrive.ae">info@sew-eurodrive.ae</a>
Uruguay			
Assembly Sales	Montevideo	SEW-EURODRIVE Uruguay, S. A. Jose Serrato 3569 Esquina Corumbe CP 12000 Montevideo	Tel. +598 2 21181-89 Fax +598 2 21181-90 <a href="mailto:sewuy@sew-eurodrive.com.uy">sewuy@sew-eurodrive.com.uy</a>
USA			
Production Sales Service	Southeast Region	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Production +1 864 439-9948 Fax Assembly +1 864 439-0566 Fax Confidential/HR +1 864 949-5557 <a href="http://www.seweurodrive.com">http://www.seweurodrive.com</a> <a href="mailto:cslyman@seweurodrive.com">cslyman@seweurodrive.com</a>
Assembly Sales Service	Northeast Region	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 <a href="mailto:csbridgeport@seweurodrive.com">csbridgeport@seweurodrive.com</a>
	Midwest Region	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 332-0038 <a href="mailto:cstroy@seweurodrive.com">cstroy@seweurodrive.com</a>
	Southwest Region	SEW-EURODRIVE INC. 202 W. Daniieldale Rd. DeSoto, TX 75115	Tel. +1 214 330-4824 Fax +1 214 330-4724 <a href="mailto:csdallas@seweurodrive.com">csdallas@seweurodrive.com</a>
	Western Region	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, CA 94544	Tel. +1 510 487-3560 Fax +1 510 487-6433 <a href="mailto:cshayward@seweurodrive.com">cshayward@seweurodrive.com</a>
	Wellford	SEW-EURODRIVE INC. 148/150 Finch Rd. Wellford, S.C. 29385  SEW-EURODRIVE INC. 220 Finch Rd. Wellford, S.C. 29385-9630	Tel. +1 864 439-7537 Fax +1 864 661 1167 <a href="mailto:IGOrders@seweurodrive.com">IGOrders@seweurodrive.com</a>
Additional addresses for service provided on request!			
Vietnam			
Sales	Ho Chi Minh City	SEW-EURODRIVE PTE. LTD. RO at Hochim- inh City Floor 8, KV I, Loyal building, 151-151 Bis Vo Thi Sau street, ward 6, District 3, Ho Chi Minh City, Vietnam	Tel. +84 937 299 700  <a href="mailto:huytam.phan@sew-eurodrive.com">huytam.phan@sew-eurodrive.com</a>
	Hanoi	MICO LTD Quảng Trị - North Vietnam / All sectors except Construction Materials 8th Floor, Ocean Park Building, 01 Dao Duy Anh St, Ha Noi, Viet Nam	Tel. +84 4 39386666 Fax +84 4 3938 6888 <a href="mailto:nam_ph@micogroup.com.vn">nam_ph@micogroup.com.vn</a> <a href="http://www.micogroup.com.vn">http://www.micogroup.com.vn</a>
Zambia			
Representation: South Africa			



## Index

### A

AD input shaft assembly.....	112
AD../ZR input shaft assembly with centering shoulder.....	113
Additional feature, type designation .....	32
Aligning the shaft axis .....	70
Ambient conditions .....	66
AMS..	
Foot-mounted motor.....	106
Permitted loads .....	102
AMS.. adapter .....	99
Permitted loads .....	102
AMS.. IEC adapter .....	99
AMS.. NEMA adapter .....	99
AMS../DH (Drain Hole)	
Rotational speeds and mass moments of inertia .....	105
AMS/AQS adapter.....	128
AQS..	
Permitted loads .....	110
AQS.. adapter.....	107
AQSA..	
Mounting of motor to adapter AQSA.....	108
AQSH..	
Mounting of motor to adapter AQSH.....	108
Mounting the coupling to the motor shaft .....	108
AR../AL..	
Mounting of third-party motors .....	106
Assembly instructions.....	63

### B

Backstop.....	122
Bearing greases .....	152
Belt pulley .....	79
Breather	
Breather with filter insert /PI .....	58
Desiccant breather filter /DC .....	60
Maintenance.....	141
Standard .....	58
Breather valve .....	63, 116

### C

Centering shoulder tolerance .....	62
Changing the oil .....	134

Check the oil consistency .....	133
Checking and cleaning the venting .....	141
Checking the oil level .....	130
Churning losses.....	38
Coating system	
OS 1 .....	50
OS 2 .....	50
OS 3 .....	50
OS 4 .....	51
Combination of planetary gear unit with primary gear unit .....	35
Components on the input end .....	48
Condensation drain hole .....	105
Copyright notice .....	8
Corrosion .....	63
Couplings .....	97
Mounting tolerance.....	97
Cover AD .....	112, 128
Cover with backstop AD../RS .....	115
Customer service .....	154

### D

Decimal separator .....	8
Desiccant breather filter .....	60
Diameter tolerance .....	62

### E

Embedded safety notes.....	7
ET .....	56
Exterior corrosion protection .....	26

### F

Failure	
Backstop.....	157
Running noise .....	155, 156
Flange-mounted design.....	96
Foot-mounted design .....	68
Foot-mounted design with primary gear unit .....	70

### G

Gear unit	
Shutdown .....	123
Gear unit cover.....	48
Gear unit mounting .....	68
Gear unit oil .....	142

Gear unit with solid shaft .....	79
Grease	
Lubricating grease selection.....	152

## H

Hazard symbols	
Meaning.....	7
Hollow shaft.....	81
Hollow shaft gear unit with torque arm .....	92
Hollow shaft with shrink disk .....	46
Horizontal mounting position .....	18

## I

Input shaft assemblies, type designation .....	32
Inspection .....	125
Inspection intervals.....	127
Inspection work	
AD.. input shaft assembly .....	128
Installation notes .....	63
Internal conservation .....	26

## L

Labels on the gear unit.....	11
Lubricant	
Compatibility with oil seal .....	151
Lubricant change intervals .....	129
Lubricant fill quantities .....	148
Lubricants .....	142
Lubricating greases .....	152

## M

M1...M6.....	36
Maintenance .....	125
AMS.. .....	128
AQS.. .....	128
Maintenance intervals .....	127
Maintenance work	
AD.. input shaft assembly .....	128
Malfunction	
Oil drain leaking.....	155
Oil leaking.....	156
Operating temperature .....	155
Temperature of the bearing.....	155
Venting .....	155, 156
Malfunctions .....	154
Mounting input elements .....	79

Mounting of third-party motors	
AR../AL.. adapter.....	106
Mounting position .....	36
Mounting positions of the primary gear units.....	38
Mounting positions sheets	
P..KF.. .....	44
P..RF.. .....	42
PF..RF.. .....	43
PK..KF.. .....	45

## N

Notes	
Designation in the documentation .....	6
Meaning of the hazard symbols .....	7

## O

Oil	
Filling in .....	75
Oil bath lubrication.....	53
Oil drain plug .....	56
Oil drain valve.....	56
Oil expansion tank.....	53
Filling with oil .....	76
Installation .....	71, 73, 76
Position.....	56
Structure.....	56
Oil seal .....	66
Lubricant compatibility .....	151
Oil seals.....	66
Options .....	32
Output shaft variants .....	46

## P

Packaging.....	26
Permitted loads	
AQS.....	110
Pictographs on the gear unit .....	11
Pinion .....	79
Pivoted mounting position .....	37
Preliminary work.....	18, 66
Preparing for transport	
Vertical mounting position M2 .....	20
Vertical mounting position M4 .....	23
Product names .....	8
Protection devices .....	63
Pt100 .....	61

Pt100 temperature sensor .....	61, 116
Dimensions.....	116
Electrical connection .....	117
Technical data .....	117

## R

Refilling the sealing grease .....	140
Removing the shrink disk .....	85
Rights to claim under limited warranty .....	8
Riser pipe .....	54

## S

Safety notes	
Designation in the documentation .....	6
Meaning of the hazard symbols .....	7
Preliminary information.....	9
Structure of embedded .....	7
Structure of section-related .....	7
Safety symbols on the dimension sheet .....	14
Sealing grease .....	153
Sealing lips .....	66
Section-related safety notes .....	7
Setting up the gear unit .....	67
Shaft axis.....	70
Shrink disk	
Cleaning/Lubrication.....	87
Installation .....	81
Signal words in safety notes.....	6
Solid shaft.....	79
Solid shaft with key.....	46

Splash guard adapter	
Mounting.....	78
Splash lubrication .....	52
Splined hollow shaft .....	89
Startup .....	118
Storage conditions.....	26, 27
Symbols on the gear unit.....	11

## T


Target group .....	10
Temperature sensor .....	61, 117
Tightening torques.....	69
Tightening torques for gear unit mounting.....	68
Tightening torques for the torque arm .....	92
Tolerances.....	62
Tools.....	62
Torque arm .....	57, 92
Trademarks .....	8
Transport .....	16, 18
Transport conditions .....	26
Transportation damage .....	16
Type designation .....	32


## V

Vertical mounting position M2 .....	20
Vertical mounting position M4 .....	24

## W

Warning notes on the gear unit .....	11
Waste disposal .....	161











**SEW-EURODRIVE**  
Driving the world

**SEW**  
**EURODRIVE**

SEW-EURODRIVE GmbH & Co KG  
Ernst-Blickle-Str. 42  
76646 BRUCHSAL  
GERMANY  
Tel. +49 7251 75-0  
Fax +49 7251 75-1970  
sew@sew-eurodrive.com  
→ [www.sew-eurodrive.com](http://www.sew-eurodrive.com)